


Key Reminder and Seat Belt Warning (Double Cab)



Key Reminder and Seat Belt Warning (Double Cab)

System Outline

1. Seat Belt Warning

In case the driver has not fastened the seat belt when the ignition SW is turned ON, a warning light flashes, and the warning buzzer goes on.

2. Key Reminder

In case the driver's door is opened with the key in the key cylinder and the ignition SW at ACC or OFF position, a warning buzzer goes on.

○ : Parts Location

Code		See Page	Code		See Page	Code		See Page
B7	B	76	C5	B	72	J45		74
		78 (*1)	C11	A	72	J49	A	74
	C	76	C12	B	72	J50	B	74
		78 (*1)	D16		76	J82		78 (*1)
B10	B	72	I25	B	73	O10	A	78 (*1)
B11	C	72	J38	A	74	O16	C	79 (*2)
B13	A	78 (*1)	J39	B	74	S13	A	75
B17	B	79 (*2)	J42	A	74	S14	B	75
C4	A	72	J43	B	74	U1		75

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	49	Cowl Wire and Driver Side J/B (Lower Finish Panel)
1E		
1F		
1H		
1J	49	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2C	45	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
3A	52	Cowl Wire and Sub J/B No.3 (Upper the Accelerator Pedal)
3D		
4A	54	Cowl Wire and Sub J/B No.4 (Upper the Accelerator Pedal)
4B		

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
BO2	97 (*2)	Seat No.1 Wire and Floor Wire (Under the Front Passenger's Seat)
BQ2	96 (*1)	Floor No.2 Wire and Seat No.2 Wire (Under the Driver's Seat)
BS1	96 (*1)	Seat No.1 Wire and Floor Wire (Under the Front Passenger's Seat)

▽ : Ground Points

Code	See Page	Ground Points Location
IO	92	Left Kick Panel
BQ	94	Left Side of Center Pillar

* 1 : Captain Seat * 2 : Separate Seat

