

INSPECTION


1. PRETENSIONER IS NOT ACTIVATED

(a) Perform a diagnostic system check (see page [DI-1851](#)).


(b) Perform a visual check which includes the following items with the front seat outer belt removed from the vehicle.

- Standard cab:
Check the quarter trim for cuts, cracks or marked discoloration.
- Access cab:
Check for cuts and cracks in, or marked discoloration on the front door rear scuff plate.
- Double cab:
Check for cuts and cracks in, or marked discoloration on the front door rear scuff plate and front door rear scuff plate and center pillar garnish lower.
- Check for cuts and cracks in wire harness, and for chipping in connectors.


Standard Cab



Access Cab






Double Cab



H11398
H17305

H23509

Standard cab:**Access cab:****Double cab:**H11399
H04116




H23510

- Standard cab:
Check for deformation of the quarter panel.
- Access cab:
Check for deformation of the ELR bracket.
- Double cab:
Check for deformation of the ELR bracket.

CAUTION:

For removal and installation of the front seat outer belt, see page [BO-236](#) and [BO-252](#).

Be sure to follow the correct procedure.



- Check for cuts and miute cracks in wire harness or marked discoloration on the front seat outer belt.




CAUTION:

For removal and installation of the front seat outer belt, see page [BO-236](#) and [BO-252](#).

Be sure to follow the correct procedure.

2. PRETENSIONER IS ACTIVATED

- (a) Perform a diagnostic system check (see page [DI-1851](#)).

Standard cab:**Access cab:****Double cab:**H11399
H04116

H23510

- (b) Perform a visual check which includes the following items with the front seat outer belt removed from the vehicle.
- Standard cab:
Check for deformation of the quarter panel.
 - Access cab:
Check for deformation of the ELR bracket.
 - Check for damage on the connector and wire harness.