


REMOVAL

REMOVE FUEL PRESSURE REGULATOR

- (a) Disconnect the vacuum hose from intake air resonator.
- (b) Disconnect the fuel return hose from the pressure regulator.

CAUTION:

Put a shop towel under the pressure regulator.



- (c) Remove the 2 bolts, and pull out the pressure regulator.
- (d) Remove the O-ring from the pressure regulator.