

## INSPECTION

### 1. VEHICLE NOT INVOLVED IN A COLLISION

Perform a diagnostic system check (see page [DI-1851](#)).

### 2. VEHICLE INVOLVED IN A COLLISION

- (a) Perform a diagnostic system check (see page [DI-1851](#)).
- (b) Even if the airbag was not deployed, perform a visual check for damage to the seat position sensor assembly. If there are any defects mentioned below, replace the occupant classification ECU with a new one:
  - Cracks, dents or chips in the case.
  - Cracks or other damage to the connector.

### CAUTION:

For removal and installation procedures of the occupant classification ECU, see page [RS-154](#) and [RS-157](#). Be sure to follow the correct procedure.