

CAMSHAFT TIMING OIL CONTROL VALVE

ON-VEHICLE INSPECTION

SF1YV-01

1. INSPECT CAMSHAFT TIMING OIL CONTROL VALVE

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch to the ON position.
- (c) Start the engine and warm it up.
- (d) Connect the hand-held tester and select the VVT from the ACTIVE TEST menu.
- (e) Check the engine speed when the OCV is operated by the hand-held tester.

Standard:**VVT system is OFF (OCV is OFF): Normal engine speed****VVT system is ON (OCV is ON): Rough idle or engine stalled**