


REMOVAL

1. DISCONNECT STABILIZER BAR LINKS

Remove the 2 nuts and disconnect the stabilizer bar links from the lower suspension arms.


HINT:

If the ball joint turns together with the nut, use a hexagon (6 mm) wrench to hold the stud.



2. REMOVE STABILIZER BAR

- (a) Remove the 2 bolts, nuts and stabilizer bar with the cushions and brackets.
- (b) Remove the 2 brackets and cushions from the stabilizer bar.



3. REMOVE STABILIZER BAR LINKS

- (a) Hold the stabilizer bar link, and remove the nut.
- (b) Remove the stabilizer bar link, 2 retainers and bushings from the stabilizer bar.
- (c) Use the same procedures described above to the other side.