

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the front airbag sensor with a new one.

- The SRS has been deployed in a collision. (Replace both the left and right airbag sensors.)
- The front airbag sensor has been found to be faulty in troubleshooting.
- The front airbag sensor has been found to be faulty while checking items (see page [RS-102](#)).
- The front airbag sensor has been dropped.

CAUTION:

For removal and installation of the front airbag sensor, see page [RS-101](#) and [RS-104](#). Be sure to follow the correct procedure.