


FUEL PUMP RELAY INSPECTION

SF1XT-01

1. REMOVE RELAY BOX COVER
2. REMOVE FUEL PUMP RELAY (Marking: F/P)




3. INSPECT FUEL PUMP RELAY CONTINUITY

- (a) Using an ohmmeter, check that there is continuity between terminals 1 and 2.

If there is no continuity, replace the relay.

- (b) Check that there is continuity between terminals 3 and 4.
- If there is no continuity, replace the relay.



4. INSPECT FUEL PUMP RELAY OPERATION

- (a) Apply battery positive voltage across terminals 1 and 2.
- (b) Using an ohmmeter, check that there is no continuity between terminals 3 and 4.

If there is continuity, replace the relay.

5. REINSTALL FUEL PUMP RELAY

6. REINSTALL RELAY BOX COVER