

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the side airbag sensor assembly with a new one.

- The side airbag assembly has been deployed in a collision.
- The side airbag sensor assembly has been found to be faulty in troubleshooting.
- The side airbag sensor assembly has been dropped.

CAUTION:

For removal and installation of the side airbag sensor assembly, see page [RS-106](#) and [RS-109](#). Be sure to follow the correct procedure.