


## CIRCUIT OPENING RELAY INSPECTION

SF1XS-01

1. REMOVE RELAY BOX COVER
2. REMOVE CIRCUIT OPENING RELAY  
(Marking: C/O)




### 3. INSPECT CIRCUIT OPENING RELAY CONTINUITY

- (a) Using an ohmmeter, check that there is continuity between terminals 1 and 2.

If there is no continuity, replace the relay.

- (b) Check that there is no continuity between terminals 3 and 5.

If there is continuity, replace the relay.



### 4. INSPECT CIRCUIT OPENING RELAY OPERATION

- (a) Apply battery positive voltage across terminals 1 and 2.
- (b) Using an ohmmeter, check that there is continuity between terminals 3 and 5.

If there is no continuity, replace the relay.

5. REINSTALL CIRCUIT OPENING RELAY
6. REINSTALL RELAY BOX COVER