



REMOVAL

1. FOLDING REAR SEAT LH

- (a) Lower the headrest to the lowest position. Pull the seat-back angle adjusting lever and fold the seatback down.
- (b) Unlock the seat legs by pulling up one of the lever on the seat legs, and swing the seat up and forward.

2. REMOVE REAR SEAT LH

- (a) Using a screwdriver, remove the 2 seat leg covers.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the 4 bolts and rear No.1 seat.

Torque: 37 N·m (380 kgf·cm, 27 ft·lbf)