

REMOVAL

1. **REMOVE SCUFF PLATE LH, COWL SIDE TRIM LH, LOWER FINISH PANEL AND NO. 2 HEATER TO REGISTER DUCT**
2. **REMOVE PARKING BRAKE PEDAL ASSEMBLY**
 - (a) Disconnect the parking brake switch connector.
 - (b) Remove the lock nut and adjusting nut from the parking brake wire.
 - (c) Remove the clip and parking brake wire.
 - (d) Remove the 4 bolts and parking brake pedal assembly.

Torque: 13 N·m (130 kgf·cm, 9 ft·lbf)