

REPLACEMENT

REQUIREMENTS FOR REPLACEMENT

In the following cases, replace the seat belt pretensioner.

- The seat belt pretensioner has been activated.
- The seat belt pretensioner has been found to be faulty during troubleshooting.
- The front seat outer belt has been found to be faulty while checking items 1–(b) or 2–(b) (see page [BO-241](#)).
- The front seat outer belt has been dropped.

CAUTION:

For removal and installation of the seat belt pretensioner, see pages [BO-236](#) and [BO-252](#). Be sure to follow the correct procedure.