

REMOVAL

1. DISCHARGE REFRIGERANT FROM REFRIGERATION SYSTEM

HINT:


At the time of the installation, refer to the following:

- Evacuate air from the refrigeration system.
- Charge the system with refrigerant and inspect for leakage of refrigerant.

Specified amount:

Access cab, Standard cab:

600 ± 50 g (21.16 ± 1.76 oz.)



2. DISCONNECT 2 LIQUID TUBES FROM RECEIVER

Remove the 2 bolts and disconnect both tubes.

Torque: 5.4 N·m (55 kgf·cm, 48 in.-lbf)

NOTICE:

Cap the openings immediately to keep moisture or dirt out of the system.

HINT:

At the time of the installation, refer to the following:

Lubricate 2 new O-rings with compressor oil and install them to the tubes.

3. REMOVE RECEIVER

- (a) Remove the holder bolt and pull the receiver downward.

HINT:

At the time of the installation, refer to the following:

If the receiver is replaced, add compressor oil to the compressor.

Add 20 cc (0.71 fl.oz.)

Compressor oil: ND-OIL 8 or equivalent

- (b) Remove the bolt and holder.