
(IG) 10A ECU-IG NO.2
(BAT) 30A P/SB
Q20 Front Seat Inner Belt Assembly RH
Seat Switch
FB01+
FB02-
FB01
FB02
Front Seat Inner Belt Connector
HR4(A),HT(B) Seat Belt Control ECU
P01 Front Seat Outer Belt Assembly LH
Q21 Front Seat Outer Belt Assembly RH
Front Seat Outer Belt Connector
H87 Yaw Rate Sensor
CANH
CANL
H28 Steering Sensor
H10(A),H10(B) Junction Connector
H113(B) Junction Connector
H150(A) Main Body ECU
Main Body ECU Connector
(BAT) 7.5A ABS NO.1
(BAT) 40A ABS MTR 2
(BAT) 50A ABS MTR 1
(BAT) 10A ABS NO.1
(IG) 10A IGN
A29 Pedal Pedal Stroke Sensor Assembly
VCC4
SIG5
SIG4
GND2
Front Speed Sensors
Rear Speed Sensors
A61 Skid Control ECU with Actuator Assembly
Skid Control ECU Connector
(IG) 10A ECU-IG NO.2
(IG) 10A IGN
Main Body ECU Connector
(BAT) 10A STOP
Stop Light Control ECU Assembly
Stop Light Switch Connector
H5 Driving Support ECU Assembly
Driving Support ECU Connector
H6 Driving Support ECU Assembly
Millimeter Wave Radar Sensor Assembly
Millimeter Wave Radar Connector
Radar Connector
(IG) 10A ECU-IG NO.2
Radar Connector
A8 Millimeter Wave Radar Sensor Assembly
HR4(A),P12(B) Airbag Sensor Assembly
Airbag Connector
Buckle Switch
P13 Front Seat Inner Belt Assembly LH
(BAT) 7.5A ECU-B
(IG) 7.5A SRT
Driver
Multi-Information Display
Meter Connector
Meter Assembly
Gateway ECU
Gateway ECU Connector
Data Link Connector 3