
(BAT)
25A
D-I/R DOOR (LHD)
P-I/R DOOR (RHD)
(IG)
10A
ECU-IG NO.2
(BAT)
25A
P-I/R DOOR (LHD)
D-I/R DOOR (RHD)
(BAT)
7.5A
ECU-B
(BAT)
7.5A
ECU-B
(BAT)
25A
DOOR NO.1
(IG)
10A
ECU-IG1 NO.1
(ACC)
10A
ECU-ACC
H16(AL/H17/B)
Main Body ECU
H16(AL/H17/B)
Main Body ECU
H16(AL/H17/B)
Main Body ECU
H16(AL/H17/B)
Main Body ECU
A19(AL/H35(C),H40)
Power Management Control ECU
A19(AL/H35(C),H40)
Power Management Control ECU
(IG)
10A
GAUGE
(BAT)
40A
PIT-3
i15
Seat Memory Switch LH
i17
Seat Memory Switch RH
K13(AL/6B)
Outer Mirror Control ECU Assembly LH
(R/A)(LT/B)
Outer Mirror Control ECU Assembly RH
H99(AL/H100(B),H101(C),H102(D))
Junction Connector
H136
Outer Mirror
Switch Assembly
Mirror Adjust Switch
L R Select Switch
R137
Headlight Dark Mirror Heater Switch
A19
Integration Relay
H76
No. 1 Shift Lever Position Sensor
H77
No. 2 Shift Lever Position Sensor
X5(B)
Position Control ECU
& Switch Assembly LH
X6(B)
Position Control ECU
& Switch Assembly RH
A5(B)
Outer Rear View Mirror Assembly LH
A7(B)
Outer Rear View Mirror Assembly RH
HALL IC
HALL IC
HALL IC
HALL IC