SERVICE HINTS

I17 IGNITION SW

1–3 : Closed with ignition key at **ON** or **ACC** position
1–2 : Closed with ignition key at **ON** or **ST** position
5–6 : Closed with ignition key at **ON** or **ST** position
5–4 : Closed with ignition key at **ST** position

◯ **: PARTS LOCATION**

Code	See Page	Code	See Page	Code		See Page
I17	131 (RHD)	J7	128 (RHD)	J14	B	131 (RHD)
J3	128 (RHD)	J13	A 131 (RHD)	J24		135 (RHD)

◯ **: RELAY BLOCKS**

Code	See Page	Relay Blocks (Relay Block Location)
1	81	Engine Room No.1 R/B (Engine Compartment Left)
4	85 (RHD)	Fusible Link Block (Engine Compartment Left)

▨ **: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	81	Engine Room Main Wire and Engine Room No.1 J/B (Engine Compartment Left)
1B		
4A	85 (RHD)	Engine Room Main Wire and Fusible Link Block (Engine Compartment Left)
4B		
4C		
4D		
4E		
4F		
DA	99 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
DC		
DE	100 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
DF		
DG		
LA	110	Floor No.2 Wire and Luggage Room J/B (Luggage Room Left)
LL		
PA	106 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
PB		
PC		
PE	105 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
PF		
PG		

▭ **: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	154 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Cowl Side Panel LH)
IE2	156 (RHD)	Engine Room Main Wire and Floor No.2 Wire (Left Kick Panel)
IH2	156 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Cowl Side Panel RH)

▽ **: GROUND POINTS**

Code	See Page	Ground Points Location
ED	152 (RHD)	Under the Fusible Link Block
IH	154 (RHD)	Left Side of Shift Lever
IK	154 (RHD)	Right Side of Instrument Panel
BM	158 (RHD)	Quarter Panel LH

193

LS430 (EWD435F)

POWER SOURCE (RHD)

◯ **: SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E13	152 (RHD)	Engine Room Main Wire			

LS430 (EWD435F)