SRS

Power Source

12 LS 430 (LHD)

LEXUS LS 430 (EWD557E)

12 LS 430 (LHD) (Cont' d)

SRS

J24 Junction Connector

BM Quarter Panel LH

J17(A), J18(B) Junction Connector

SRS

C12 Combination Meter

Right Side of Shift Lever

W–B

W–B

B4 Buckle SW Front LH

Seat Position Airbag Sensor

See Multiplex Communication System (BEAN – Instrument Panel Bus and BEAN – Steering Column Bus)<2–12>

10 (A) LBE+
9 (A) LSP+
17 (A) LSP–

Multiplex Communication System (BEAN – Instrument Panel Bus and BEAN – Steering Column Bus) <2–32>

13 (B) MPX1

Theft Deterrent ECU<3–21>

18 (B) GSW

K7 Knee Airbag Squib RH
20 (B) PK–
19 (B) PK+

K6 Knee Airbag Squib LH
10 (B) DK–
9 (B) DK+

S28 Side Airbag Sensor Front LH
21 (A) ESL
23 (A) SSL–
13 (A) SSL+
19 (A) VUPL

S30 Side Airbag Sensor Rear LH
22 (A) ESCL
20 (A) VUCL

A26(A), A27(B), A28(C) Airbag Sensor Assembly

RBE+ 15 (C)
FSR– 24 (C)
FSR+ 16 (C)

Occupant Detection Sensor

B5 Buckle SW Front RH

Cowl Side Panel RH

ICR– 6 (C)
ICR+ 5 (C)
C19 Curtain Shield Airbag Squib RH

ICL– 3 (A)
ICL+ 4 (A)
C18 Curtain Shield Airbag Squib LH

ESR 20 (C)
SSR– 18 (C)
SSR+ 12 (C)
VUPR 22 (C)
S29 Side Airbag Sensor Front RH

ESCR 19 (C)
VUCR 21 (C)
S31 Side Airbag Sensor Rear RH

LEXUS LS 430 (EWD557E)

173