Power Source

SRS

1 2 3 4

ACC
1 AM1 IG1 2 R–W
5 AM2 IG2 6 B
ST2
I17
IGNITION SW

W–L

B–R

1 IH2

JUNCTION CONNECTOR
A (A)
J13 (A), J14 (B)
E
(B)

7.5A IG2
2 (PG)
1 (PH)
B–O

2 (PG)

P20 PRETENSIONER REAR LH
RL+ RL–
1 2

P21 PRETENSIONER REAR RH
RR+ RR–
1 2

P18 PRETENSIONER FRONT LH
L+ L–
1 2

S42 SIDE AIRBAG SQUIB LH
SFL+ SFL–
1 2

See Multiplex Communication System(J/B ECU)<2–32>

To DLC3<6–7>

B–W B–R

80A D–J/B
140A ALT
30A AM 2

1 (4C) 4
13 (DE) 1 (DA) 6 (DF) 9 (DE) 4 (DH)

W–L B–W R–W Y V–W

7.5A AM1
D–IG1 RELAY
7.5A GAUGE
7.5A MPX–IG

6 (B) 5 (B) 22 (B) 12 (B) 5 (A) 6 (A) 12 (C) 11 (C) 8 (A) 7 (A) 12 (A) 11 (A)
IG1 IG2 MPX2 SIL PLR+ PLR– PRR+ PRR– PL+ PL– SFL+ SFL–

A26 (A), A27 (B), A28 (C) AIRBAG SENSOR ASSEMBLY

E1 D+ D– D2– D2+ P+ P– P2+ P2– +SL –SL +SR –SR PR+ PR– SFR+ SFR–
27 (B) 14(B) 13(B) 17(B) 16(B) 10(B) 11(B) 8(B) 7(B) 15(B) 26(B) 9(B) 20(B) 9(C) 10(C) 5(C) 6(C)

7 (DG) 3 (DH)
W–B
W–B

W–B Y–B Y Y–O Y–V Y–R Y–G Y–GR Y–P W–R BR B–W BR–W Y–B Y Y–R Y–G

1 (IC1) 1 (IC1) 1 (IH1) 2 (IH1)
W–R BR B–W BR–W

A30 AIRBAG SQUIB (Steering Wheel Pad)
A29 AIRBAG SQUIB(Front Passenger Airbag Assembly)
A10 AIRBAG SENSOR FRONT LH
A11 AIRBAG SENSOR FRONT RH
P19 PRETENSIONER FRONT RH
S43 SIDE AIRBAG SQUIB RH

+SL –SL +SR –SR R+ R– SFR+ SFR–

Y–GR Y–P Y–GR Y–P Y–B Y Y–R Y–G

B–L

1 (4A)

BATTERY

IK Right side of instrument panel

– 54 –

SRS

5   6   7   8

A   Y

– 55 –

S30
SIDE AIRBAG
SENSOR
REAR LH

VUCL   ESCL
2   1

R   G

S28
SIDE AIRBAG SENSOR
FRONT LH

VUPL   SSL+   SSL–   ESL
4   3   2   1

LG–B   L–W   P–L   GR–L

To Theft
Deterrent ECU
<3-21>

6 PI

L

2 PH

L

See Multiplex Communication
System(J/B ECU)<2-32>

B 5
BUCKLE SW
FRONT RH

W–B

6   3   2

B   R   W

14 A   13 A   16 A   17 A   20 A   18 A   4 B   24 B   4 C   3 C   14 C
VUCL   ESCL   VUPL   SSL+   SSL–   ESL   GSW   MPX1   RSP–   RSP+   RBE+

A26 A , A27 B , A28 C AIRBAG SENSOR ASSEMBLY

VUCR   ESCR   VUPR   SSR+   SSR–   ESR   ICL+   ICL–   ICR+   ICR–   FSL+   FSL–   LBE+   E2
19 C   20 C   17 C   16 C   13 C   15 C   9 A   10 A   8 C   7 C   4 A   3 A   19 A   28 B

L–B   GR–R   LG   L–Y   P   GR   Y–V   Y–O   Y–V   Y–O   G–W   R–B   G–Y   W–B

2   1   4   3   2   1   1   2   1   2   4   1   2

VUCR   ESCR   VUPR   SSR+   SSR–   ESR   ICL+   ICL–   ICR+   ICR–

B 4
BUCKLE SW FRONT LH

W–B   W–B

S31
SIDE AIRBAG
SENSOR
REAR RH

S29
SIDE AIRBAG SENSOR
FRONT RH

C18
CURTAIN SHIELD
AIRBAG SQUIB
LH

C19
CURTAIN SHIELD
AIRBAG SQUIB
RH

5

7 PJ   4 PH

7 PG   13 PF

W–B   W–B

1

SRS

22

C12
SRS WARNING LIGHT
[COMB. METER]

Y

W–B

Cowl side
panel LH   IG   IH   Left side of
shift lever   IR   Under the
driver's seat   II   Left side of
shift lever