ALPHABETICAL INDEX

Numerics

1ST, 2ND, 4TH, AND 5TH GEAR OUTPUT SHAFT TM-269

Numerics

3RD, 6TH, 7TH, AND REVERSE GEAR OUTPUT SHAFT TM-272

A

A/C AUTO AMP. HAC-30
A/C AUTO AMP., LEFT FRONT DOOR CONTROL UNIT, RIGHT FRONT DOOR CONTROL UNIT DEF-24
A/C CONTROL (A/C AUTO AMP.) HAC-121
ABBREVIATIONS GI-14
ACCELERATOR CONTROL SYSTEM ACC-4
ACTIVATION OF FUEL PUMP EC-191
ACTIVE SOUND ENHANCEMENT AV-57
ADDITIONAL SERVICE WHEN REPLACING (ELECTRONIC IGNITION SWITCH CONTROL UNIT) PCS-23
ADDITIONAL SERVICE WHEN REPLACING (LIGHT & RAIN SENSOR) WW-32
ADDITIONAL SERVICE WHEN REPLACING (OVERHEAD CONTROL PANEL CONTROL UNIT) INL-59
ADDITIONAL SERVICE WHEN REPLACING AIR BAG DIAGNOSIS SENSOR UNIT SRC-54
ADDITIONAL SERVICE WHEN REPLACING AROUND VIEW MONITOR CONTROL UNIT .. AV-298
ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT AV-146
ADDITIONAL SERVICE WHEN REPLACING AWD CONTROL UNIT DLN-27
ADDITIONAL SERVICE WHEN REPLACING BCM BCS-88
ADDITIONAL SERVICE WHEN REPLACING CAN GATEWAY LAN-163
ADDITIONAL SERVICE WHEN REPLACING COMBINATION METER MWI-98
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (A/C AUTO AMP.) HAC-48
ADDITIONAL SERVICE WHEN REPLACING CONTROL VALVE TM-69
ADDITIONAL SERVICE WHEN REPLACING CONTROL VALVE & TCM TM-70
ADDITIONAL SERVICE WHEN REPLACING DISPLAY CONTROL UNIT AV-145
ADDITIONAL SERVICE WHEN REPLACING DUAL CLUTCH TM-77
ADDITIONAL SERVICE WHEN REPLACING ECM EC-183
ADDITIONAL SERVICE WHEN REPLACING ELECTRIC PARKING BRAKE CONTROL MODULE PB-34
ADDITIONAL SERVICE WHEN REPLACING ELECTRIC SHIFT CONTROL UNIT TM-79
ADDITIONAL SERVICE WHEN REPLACING ELECTRONIC STABILITY PROGRAM CONTROL UNIT BRC-84
ADDITIONAL SERVICE WHEN REPLACING EPS CONTROL UNIT STC-21
ADDITIONAL SERVICE WHEN REPLACING FPCM EC-186
ADDITIONAL SERVICE WHEN REPLACING FRONT CAMERA UNIT DAS-59
ADDITIONAL SERVICE WHEN REPLACING FRONT DOOR CONTROL UNIT DLK-100
ADDITIONAL SERVICE WHEN REPLACING GEAR OIL DLN-28
ADDITIONAL SERVICE WHEN REPLACING HEADLAMP CONTROL UNIT EXL-115, EXL-387
ADDITIONAL SERVICE WHEN REPLACING ICC SENSOR BRC-1008, CCS-54
ADDITIONAL SERVICE WHEN REPLACING INTELLIGENT KEY UNIT DLK-99
ADDITIONAL SERVICE WHEN REPLACING LED HEADLAMP CONTROL MODULE EXL-116
ADDITIONAL SERVICE WHEN REPLACING LOW TIRE PRESSURE WARNING CONTROL UNIT WT-31
ADDITIONAL SERVICE WHEN REPLACING NAVI CONTROL UNIT AV-147
ADDITIONAL SERVICE WHEN REPLACING OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT SRC-57
ADDITIONAL SERVICE WHEN REPLACING SEAT CONTROL UNIT ADP-43
ADDITIONAL SERVICE WHEN REPLACING SONAR CONTROL UNIT SN-60
ADDITIONAL SERVICE WHEN REPLACING TCM TM-66
ADDITIONAL SERVICE WHEN REPLACING TCU AV-430
ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY TM-74
AIR BAG DIAGNOSIS SENSOR UNIT SRC-19, SRC-39
AIR CLEANER AND AIR DUCT EM-22
AIR CLEANER FILTER EM-15
AIR CONDITIONER FILTER VTL-15
AIR QUALITY SENSOR HAC-128
ALTERNATOR CHG-35
AM/FM MAIN ANTENNA AV-255

AMBIENT LAMP INL-134
AMBIENT SENSOR HAC-122
ANTENNA FEEDER AV-258
ANTI-PINCH INSPECTION RF-16
AROUND VIEW MONITOR CONTROL UNIT AV-283, AV-347
AROUND VIEW MONITOR SYSTEM AV-267, AV-289, AV-345
AUDIO SYSTEM AV-45
AUTO OPERATION DOES NOT OPERATE . RF-21
AUTOMATIC AIR CONDITIONING SYSTEM HAC-40
AUTOMATIC DRIVE POSITIONER SYSTEM ADP-34
AUTOMATIC SPEED CONTROL DEVICE (ASCD)/ SPEED LIMITER CCS-375
AV BRANCH LINE CIRCUIT LAN-145
AV CONTROL UNIT AV-84, AV-240
AVM BRANCH LINE CIRCUIT LAN-146
AWD CONTROL UNIT DLN-18, DLN-72
AWD SOLENOID DLN-109
AWD SYSTEM DLN-24

B

B TERMINAL CIRCUIT CHG-34, STR-15
B0001 DRIVER AIR BAG MODULE SRC-61
B0002 DRIVER AIR BAG MODULE SRC-64
B0004 KNEE AIR BAG MODULE SRC-67
B0010 PASSENGER AIR BAG MODULE .. SRC-70
B0011 PASSENGER AIR BAG MODULE .. SRC-73
B0012 ACTIVE VENT SRC-76
B0013 KNEE AIR BAG MODULE SRC-80
B0021 CURTAIN AIR BAG MODULE SRC-83
B0029 CURTAIN AIR BAG MODULE SRC-86
B0050 FRONT SEAT BELT BUCKLE SWITCH SRC-88
B0052 FRONT SEAT BELT BUCKLE SWITCH SRC-91
B007E FRONT SEAT BELT PRE-TENSIONER SRC-94
B007F FRONT SEAT BELT PRE-TENSIONER SRC-97
B0082 FRONT SEAT BELT FORCE LIMITER SRC-100
B0090 CRASH ZONE SENSOR SRC-103
B0091 FRONT DOOR SATELLITE SENSOR SRC-106
B0092 B-PILLAR SATELLITE SENSOR .. SRC-109
B0093 REAR DOOR SATELLITE SENSOR SRC-112
B0095 CRASH ZONE SENSOR SRC-115
B0096 FRONT DOOR SATELLITE SENSOR SRC-118
B0097 B-PILLAR SATELLITE SENSOR .. SRC-121
B0098 REAR DOOR SATELLITE SENSOR SRC-124
B0099 AIR BAG DIAGNOSIS SENSOR UNIT SRC-127
B00A0 OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT SRC-128
B00C5 FRONT SEAT POSITION DETECTION SWITCH SRC-131
B00E3 REAR SEAT BELT PRE-TENSIONER SRC-133
B00E4 REAR SEAT BELT PRE-TENSIONER SRC-136
B1030 INTAKE SENSOR HAC-53
B1058 INTAKE DOOR MOTOR HAC-56
B106A REAR WINDOW DEFOGGER RELAY DEF-31
B107A REFRIGERANT PRESSURE SENSOR HAC-60
B107D COOLANT CIRCULATION PUMP .. HAC-63
B108A SEAT HEATER SE-34
B1091 SEAT HEATER LH SE-39
B1095 SEAT HEATER RH SE-43
B10A2 AIR MIX DOOR MOTOR LH HAC-66
B10A9 AIR MIX DOOR MOTOR RH HAC-70
B1107 IN-VEHICLE SENSOR HAC-74
B1109 CAN COMMUNICATION EC-266
B110A CAN COMMUNICATION EC-267
B1127 AIR QUALITY SENSOR HAC-77
B112F BLOWER MOTOR HAC-79
B1135 DOOR MOTOR HAC-83
B1136 DOOR MOTOR HAC-85
B1178 MODE DOOR MOTOR HAC-87
B11C1 SUB BATTERY BCS-90
B11F6 INTERIOR TEMPERATURE SENSOR WITH INTEGRATED FAN HAC-91
B122B SIDE SENSOR [RR] SN-62
B1230 CORNER SENSOR [RR] SN-70
B1235 CENTER SENSOR [RR] SN-79
B123A CENTER SENSOR [RL] SN-88
B1244 SIDE SENSOR [FL] SN-97
B1249 CORNER SENSOR [FL] SN-105
B124E CENTER SENSOR [FL] SN-114
B1253 CENTER SENSOR [FR] SN-123
B1258 CORNER SENSOR [FR] SN-132
B125D SIDE SENSOR [FR] SN-141
B1276 CONFIGURATION MWI-103
B1277 CONFIGURATION MWI-105
B1279 CONFIGURATION MWI-107
B127B CORNER SENSOR [RL] SN-149
B1280 SIDE SENSOR [RL] SN-158
B1285 SENSOR POWER SUPPLY AND GROUND CIRCUIT SN-166
B1286 SENSOR POWER SUPPLY AND GROUND CIRCUIT SN-169
B1289 CONFIGURATION MWI-108
B129F ELECTRONIC STABILITY PROGRAM CONTROL UNIT BCS-96
B130D TCU AV-432

B1310 TCU AV-434
B13D9 TCU AV-435
B13E1 TCU AV-436
B1504 STEERING SWITCH LH MWI-109
B1505 STEERING SWITCH AV-150
B154E REMOTE KEYLESS ENTRY RECEIVER ... DLK-151
B1581 INTELLIGENT KEY UNIT DLK-154
B1600 SUNLOAD SENSOR HAC-92
B1603 SUNLOAD SENSOR HAC-95
B161E INSIDE MIRROR LAMP INL-83
B162A LOW BEAM LH CIRCUIT EXL-388
B162E LOW BEAM RH CIRCUIT EXL-391
B1632 HIGH BEAM LH CIRCUIT EXL-394
B1636 HIGH BEAM RH CIRCUIT EXL-397
B163A FRONT TURN SIGNAL LAMP LH CIRCUIT EXL-400
B163E FRONT TURN SIGNAL LAMP RH CIRCUIT EXL-403
B1642 REAR TURN SIGNAL LAMP LH CIRCUIT.. EXL-118, EXL-406
B1646 REAR TURN SIGNAL LAMP RH CIRCUIT . EXL-120, EXL-408
B164A REAR TURN SIGNAL LAMP LH .. EXL-122, EXL-410
B164B REAR TURN SIGNAL LAMP RH . EXL-125, EXL-413
B164C REAR TURN SIGNAL LAMP LH DIAGNOSTIC CIRCUIT EXL-128, EXL-416
B164D REAR TURN SIGNAL LAMP RH DIAGNOSTIC CIRCUIT EXL-130, EXL-418
B1692 CIRCUIT 58D TM-81
B1692 FRONT DOOR ILLUMINATION INL-61, INL-85
B16AF STOP LAMP LH CIRCUIT EXL-132, EXL-420
B16B3 STOP LAMP RH CIRCUIT EXL-134, EXL-422
B16B7 HI-MOUNTED STOP LAMP CIRCUIT EXL-136, EXL-424
B16F7 FRONT FOG LAMP LH CIRCUIT EXL-139, EXL-427
B16FB FRONT FOG LAMP RH CIRCUIT EXL-141, EXL-429
B1707 BACK-UP LAMP LH CIRCUIT EXL-143, EXL-431
B170B BACK-UP LAMP RH CIRCUIT EXL-145, EXL-433
B170F BACK DOOR LAMP INL-87
B1727 VANITY MIRROR LAMP INL-89
B1734 FRONT MAP LAMP SWITCH INL-92
B1735 FRONT MAP LAMP SWITCH INL-94
B1738 REAR ROOM LAMP SWITCH INL-96
B1739 AMBIENT LAMP (FRONT INSIDE HANDLE) INL-64
B1739 AMBIENT LAMP (REAR INSIDE HANDLE) INL-98
B173D SIDE TURN SIGNAL LAMP CIRCUIT EXL-147, EXL-435
B1749 ROOM LAMP INL-100
B1755 OUTSIDE MIRROR LAMP INL-67
B1759 STEP LAMP INL-72
B1783 LED HEADLAMP CONTROL MODULE EXL-151
B1787 HEADLAMP AIMING MOTOR EXL-157
B178F COMBINATION SWITCH BCS-215
B1795 OUTPUT FOR ILLUMI OF GEAR INDICATOR TM-82
B1797 PARKING LAMP LH 2 CIRCUIT EXL-439
B179B PARKING LAMP RH 2 CIRCUIT ... EXL-441
B17DE AMBIENT LAMP (FRONT DOOR GRIP).... INL-77
B17ED LOW BEAM CIRCUIT EXL-161
B17F7 LICENSE PLATE LAMP CIRCUIT EXL-164, EXL-443
B17FC PARKING LAMP/POSITION LAMP SWITCH EXL-166, EXL-445
B1828 BACK DOOR OPENER ACTUATOR..... DLK-203
B186D BACK DOOR OPENER SWITCH . DLK-206
B18B1 DOOR LOCK ACTUATOR DLK-103
B18B5 POWER WINDOW MAIN SWITCH PWC-27
B18B6 POWER WINDOW MAIN SWITCH PWC-30
B18B7 POWER WINDOW MAIN SWITCH (REAR LH SWITCH) PWC-33
B18B7 REAR POWER WINDOW SWITCH LH PWC-57
B18B8 POWER WINDOW MAIN SWITCH (REAR RH SWITCH) PWC-36
B18B8 REAR POWER WINDOW SWITCH RH PWC-59
B18B9 POWER WINDOW MAIN SWITCH (POWER WINDOW LOCK SWITCH) PWC-39
B18C1 FRONT POWER WINDOW MOTOR HALL SENSOR PWC-42
B18C9 FRONT POWER WINDOW MOTOR HALL SENSOR POWER SUPPLY PWC-47
B18C9 REAR POWER WINDOW MOTOR HALL SENSOR POWER SUPPLY PWC-61
B18CC FUEL FILLER LID LOCK ACTUATOR..... DLK-208
B18E6 FRONT POWER WINDOW SWITCH (PASSENGER SIDE) PWC-50
B18EB REAR DOOR LOCK ACTUATOR . DLK-211
B18F3 REAR DOOR LOCK ACTUATOR .. DLK-214
B1936 DOOR LOCK AND UNLOCK SWITCH..... DLK-108
B1A39 ELECTRONIC IGNITION SWITCH CONTROL UNIT PCS-35
B1A4A FRONT INTELLIGENT KEY DOOR HANDLE LH DLK-155
B1A4B FRONT INTELLIGENT KEY DOOR HANDLE RH DLK-159

B1A4E REAR DOOR INTELLIGENT KEY ANTENNA LH....DLK-163
B1A4F REAR DOOR INTELLIGENT KEY ANTENNA RH....DLK-169
B1A50 FRONT INTELLIGENT KEY ANTENNA....DLK-175
B1A51 REAR INTELLIGENT KEY ANTENNA....DLK-181
B1A7B POWER WINDOW OPERATION..PWC-54
B1A9E REFRIGERANT PRESSURE SENSOR....HAC-98
B1BC7 AIR BAG DIAGNOSIS SENSOR UNIT....SRC-139
B1CE8 CRACH SIGNAL....EC-268
B1D00 OPEN/CLOSE SWITCH....MIR-38
B1D02 INTELLIGENT KEY UNIT....DLK-187
B1D04 MIRROR SWITCH....MIR-40
B1D5E FRONT SEAT SWITCH....ADP-88
B1D6C SLIDING SENSOR....ADP-48
B1D70 LIFTING SENSOR (REAR)....ADP-50
B1D74 LIFTING SENSOR (FRONT)....ADP-52
B1D78 RECLINING SENSOR....ADP-54
B1D9B SLIDING MOTOR....ADP-56
B1DAA LIFTING MOTOR (FRONT)....ADP-58
B1DAC RECLINING MOTOR....ADP-60
B1DD0 DOOR MIRROR DEFOGGER....DEF-35
B1DF3 MIRROR SENSOR....MIR-42
B1DF7 MIRROR SENSOR....MIR-47
B1DFB POWER FOLD UNIT....MIR-52
B1E04 LIFTING MOTOR (REAR)....ADP-62
B1E1B MIRROR ACTUATOR....MIR-57
B1E1F CHANGEOVER SWITCH....MIR-61
B1EAE SEAT CONTROL UNIT....ADP-96
B1EB0 LANE KEEPING ASSIST HAS A MALFUNCTION....DAS-68
B1F01 ENGINE SPEED SIGNAL....AV-151
B1F10 HAZARD SWITCH....EXL-168, EXL-447
B1F24 AMBIENT LAMP....INL-102
B1F45 DISCHARGED BATTERY....CHG-30
B1F4B REAR DOOR LOCK ACTUATOR..DLK-217
B1F4C FRONT WIPER RELAY....WW-34
B1F4D FRONT WIPER HI/LO RELAY....WW-37
B1F4E FOOT LAMP....INL-104
B1F72 HEATED STEERING WHEEL OUTPUT SIG DAS-71
B1FB1 HEADLAMP CONTROL UNIT TEMPERATURE SENSOR 1EXL-169, EXL-448
B1FB2 HEADLAMP CONTROL UNIT TEMPERATURE SENSOR 2EXL-171, EXL-450
B1FB3 HEADLAMP CONTROL UNIT TEMPERATURE SENSOR 3EXL-173, EXL-452
B1FB4 HEADLAMP CONTROL UNIT TEMPERATURE SENSOR 4EXL-175, EXL-454
B1FB5 HEADLAMP CONTROL UNIT TEMPERATURE SENSOR 5EXL-177, EXL-456
B1FB6 LED HEADLAMP CONTROL MODULE TEMPERATURE SENSOR 1....EXL-179
B1FB7 LED HEADLAMP CONTROL MODULE TEMPERATURE SENSOR 2....EXL-181
B1FB8 LED HEADLAMP CONTROL MODULE TEMPERATURE SENSOR 3....EXL-183
B2103 POWER SUPPLY CIRCUIT....SRC-140
B210A BATTERY VOLTAGE....HAC-101, LAN-165
B210A CONTOL UNIT POWER SUPPLY..STC-27, WT-38
B210A CONTROL UNIT POWER SUPPLY DLN-29
B210A ELECTRONIC IGNITION SWITCH CONTROL UNIT....PCS-36
B210A FRONT DOOR CONTROL UNIT....DLK-112
B210A INTELLIGENT KEY UNIT....DLK-188
B210A POWER SUPPLY AND GROUND CIRCUIT SN-172
B210A POWER SUPPLY CIRCUIT....DAS-74, MWI-112, TM-83
B210A STEERING COLUMN CONTROL MODULE BCS-217
B210B BATTERY VOLTAGE....HAC-102, LAN-166
B210B CONTOL UNIT POWER SUPPLY..STC-28, WT-39
B210B CONTROL UNIT POWER SUPPLY DLN-30
B210B ELECTRONIC IGNITION SWITCH CONTROL UNIT....PCS-38
B210B FRONT DOOR CONTROL UNIT....DLK-115
B210B INTELLIGENT KEY UNIT....DLK-190
B210B POWER SUPPLY AND GROUND CIRCUIT SN-174
B210B POWER SUPPLY CIRCUIT....DAS-75, MWI-114, TM-84
B210B STEERING COLUMN CONTROL MODULE BCS-219
B210C BATTERY....BCS-99
B210C FRONT DOOR CONTROL UNIT....DLK-118
B210C POWER SUPPLY AND GROUND CIRCUIT SN-176
B210C POWER SUPPLY CIRCUIT....PB-39
B210C POWER SUPPLY IS OUTSIDE VALID RANGE....TM-85
B210D A/C AUTO AMP. POWER SUPPLYHAC-103
B210D BATTERY POWER SUPPLY....LAN-167
B210D CONTOL UNIT POWER SUPPLY..STC-29, WT-40
B210D ELECTRONIC IGNITION SWITCH CONTROL UNIT....PCS-40
B210D INTELLIGENT KEY UNIT....DLK-192
B210D LOW BEAM POWER SUPPLY....EXL-185
B210D POWER SUPPLY CIRCUIT....MWI-116
B210D SEAT CONTROL UNIT....ADP-64
B210D STEERING COLUMN CONTROL MODULE BCS-221
B210D SUPPLY VOLT OF CPA CONTROL UNIT IS LOW....DAS-77

B210D, B210E FPCM POWER SUPPLY EC-269
B210E A/C AUTO AMP. POWER SUPPLY HAC-104
B210E BATTERY POWER SUPPLY LAN-168
B210E CONTOL UNIT POWER SUPPLY .. STC-30, WT-41
B210E CPA CONTROL UNIT PWR SUP IS NOT OK DAS-83
B210E ELECTRONIC IGNITION SWITCH CONTROL UNIT PCS-42
B210E HIGH BEAM POWER SUPPLY EXL-190
B210E INTELLIGENT KEY UNIT DLK-194
B210E POWER SUPPLY CIRCUIT MWI-118
B210E SEAT CONTROL UNIT ADP-68
B210E STEERING COLUMN CONTROL MODULE BCS-223
B210F POWER SUPPLY CIRCUIT SRC-142
B210F HEADLAMP POWER SUPPLY EXL-195
B2121 INJECTION RELAY BCS-103
B214B LATCHING TERMINAL RELAY 30G BCS-106
B214F LATCHING TERMINAL RELAY 30G BCS-110
B2159 NO-LOAD CURRENT BCS-114
B215F TERMINAL RELAY 15R1 ..... BCS-116
B2163 TERMINAL RELAY 15R2 ..... BCS-119
B217E DOOR MOTOR HAC-105
B217E FRONT DOOR CONTROL UNIT .. DLK-123
B2194 POWER SUPPLY BCS-122
B2195 POWER SUPPLY BCS-125
B21A0 NO-LOAD CURRENT CONSUMPTION MALF DAS-88
B21DC ELECTRONIC IGNITION SWITCH CONTROL UNIT PCS-44
B21DE SUB BATTERY RELAY BCS-128
B21DF DECOUPLING RELAY BCS-132
B21E6 INJECTION RELAY BCS-137
B21E7 IGNITION POWER SUPPLY BCS-140
B21F2 POWER SUPPLY CIRCUIT PB-42
B21F5 POWER SUPPLY BCS-141
B21F6 POWER SUPPLY BCS-144
B21F7 POWER SUPPLY BCS-147
B21F8 POWER SUPPLY BCS-150
B21F9 POWER SUPPLY BCS-153
B21FC AWD SOLENOID DLN-31
B2201 ELECTRONIC IGNITION SWITCH CONTROL UNIT PCS-45
B2205 VIN MISSING/MISSMATCH SRC-144
B2206 VIN MISSING/MISSMATCH SRC-145
B2206 FRONT DOOR CONTROL UNIT ... DLK-127
B2206 VEHICLE IDENTIFICATION NUMBER BCS-156
B2207 AIR BAG DIAGNOSIS SENSOR UNIT SRC-146
B2208 AIR BAG DIAGNOSIS SENSOR UNIT SRC-147
B220B AIR BAG DIAGNOSIS SENSOR UNIT SRC-148
B2213 COMBINATION METER MWI-120
B2215 BCM BCS-158
B221C SEAT CONTROL UNIT ADP-72
B221D LIGHT & RAIN SENSOR WW-40
B2224 ELECTRONIC IGNITION SWITCH CONTROL UNIT PCS-46
B2225 STEERING COLUMN CONTROL MODULE BCS-225
B222D DOOR MOTOR HAC-107
B2232 SONAR CONTROL UNIT SN-179
B2239 HEADLAMP AIMING CONTROL ... EXL-198
B223B BCM BCS-160
B223B FRONT DOOR CONTROL UNIT .. DLK-129
B224F FRONT DOOR CONTROL UNIT ... DLK-131
B2255 AIR BAG DIAGNOSIS SENSOR UNIT SRC-149
B2261 INTELLIGENT KEY UNIT DLK-196
B2266 DRIVE AUTHORIZATION DATA ... MWI-124
B2267 MIRROR DIMMING CIRCUIT MIR-63
B2269 GARAGE DOOR OPENER CONTROL UNIT DLK-221
B226C UPPER CONTROL PANEL CONTROL UNIT BCS-161
B2279 TIRE PRESSURE SENSOR WT-42
B227E MOTOR ELECTRONICS OVER TEMP DAS-89
B2280 CONFIG SETTING SRC-150
B2282 MAIN ODOMETER MWI-126
B2286 CALIBRATION DAS-90
B2286 SEAT CONTROL UNIT ADP-94
B2287 SEAT CONTROL UNIT ADP-95
B229B MULTIFUNCTION CAMERA HAS MALF DAS-91
B229D CONTROL MODULE PB-44
B229F HEATED SEAT SYSTEM LH SE-47
B22A0 HEATED SEAT SYSTEM RH SE-49
B22A3 OVERHEAD CONTROL PANEL CONTROL UNIT INL-107
B22A8 SEAT CONTROL UNIT SE-51
B22E2 MAGNET CLUTCH HAC-108
B22E3 LIGHT & RAIN SENSOR WW-44
B2300 COMBINATION SWITCH BCS-226
B2306 COMBINATION SWITCH BCS-228
B2309 COMBINATION SWITCH BCS-230
B231A REAR WIPER RELAY WW-45
B231E WASHER PUMP WW-48
B2326 WASHER LEVEL SWITCH WW-51
B2330 COMBINATION SWITCH BCS-232
B2335 HORN RERAY HRN-13
B235A BCM BCS-162
B235B SPRAY NOZZLE HOSE HEATER ... WW-53
B2361 WASHER PUMP WW-56
B2364 AMBIENT LAMP INL-110
B2379 FRONT WIPER MOTOR WW-59
B2386 LED HEADLAMP CONTROL MODULE FAN 1 ..... EXL-200

B238A LED HEADLAMP CONTROL MODULE FAN 2 ..... EXL-202
B23A2 WASHER PUMP WW-61
B23A8 OUTPUT FOR WINDOW HEATING HAS MALF DAS-94
B23AA ELECTRIC PARKING BRAKE ACTUATOR MOTOR (LEFT) PB-52
B23AB ELECTRIC PARKING BRAKE ACTUATOR MOTOR (RIGHT) PB-62
B23AC ELECTRIC PARKING BRAKE SWITCH PB-72
B23AF HEATED SEAT SYSTEM LH SE-53
B23B0 HEATED SEAT SYSTEM RH SE-55
B23B3 BRAKE WEAR SENSOR BRC-88
B2517 REAR POWER WINDOW MOTOR LH HALL SENSOR PWC-63
B2519 REAR POWER WINDOW MOTOR RH HALL SENSOR PWC-66
B25A6 SIGNAL ERROR BCS-163
B25AA SLIDING MOTOR ADP-74
B25AB LIFTING MOTOR (FRONT) ADP-77
B25AD RECLINING MOTOR ADP-81
B25AE LIFTING MOTOR (REAR) ADP-84
B25BA AMBIENT LAMP (FRONT DOOR GRIP) INL-80
B2722 ECU LOCK STATUS SRC-151
B2735 PYROFUSE SRC-152
B2750 SIDE AIR BAG MODULE SRC-155
B2751 SIDE AIR BAG MODULE SRC-158
B2800 STOP LAMP LH CIRCUIT EXL-204, EXL-458
B2801 TAIL LAMP LH (BACK DOOR SIDE) CIRCUIT EXL-206, EXL-460
B2802 STOP LAMP RH CIRCUIT EXL-208, EXL-462
B2803 TAIL LAMP RH (BACK DOOR SIDE) CIRCUIT EXL-210, EXL-464
B2808 THE OUTPUT FOR THE WARNING LAMP ”BLIND SPOT ASSIST” HAS A MALFUNCTION DAS-96
B280C THE OUTPUT FOR THE INDICATOR LAMP ”BLIND SPOT ASSIST” HAS A MALFUNCTION DAS-100
B2837 SWIVEL POSITION SENSOR CIRCUIT EXL-212
B2838 SWIIVEL ACTUATOR CIRCUIT EXL-214
B2839 CORNERING LAMP EXL-217
B2844 AMBIENT LAMP (REAR DOOR GRIP/ INSTRUMENT PANEL) INL-112
B284C LIGHT DISTRIBUTION SENSOR . EXL-220
B284D LIGHT DISTRIBUTION ACTUATOR EXL-222
B2853 TAIL LAMP LH (BODY SIDE) CIRCUIT EXL-226, EXL-466
B2854 TAIL LAMP RH (BODY SIDE) CIRCUIT EXL-228, EXL-468
B2856 HIGH BEAM CIRCUIT EXL-230
B2857 POSITION LAMP CIRCUIT EXL-233, EXL-470
B2858 FRONT TURN SIGNAL LAMP CIRCUIT EXL-236
B2859 SIDE MAKER LAMP CIRCUIT EXL-239, EXL-473
B2860 DAYTIME RUNNING LIGHT CIRCUIT EXL-242, EXL-476
B2E33 SOS SWITCH AV-437
B2EF0 TCU AV-438
B3002 DIMMER SIGNAL LAN-169
B3003 ENGINE SPEED SIGNAL LAN-171
B3005 REVERSE SIGNAL LAN-174
B3006 ACC POWER OUTPUT LAN-178
B3007 E-CALL SIGNAL LAN-184
B3008 VEHICLE SPEED SIGNAL LAN-187
B3009 ILLUMINATION CONTROL SIGNAL LAN-191
BACK DOOR DLK-254
BACK DOOR FINISHER EXT-63
BACK DOOR LAMP INL-130
BACK DOOR LOCK DLK-273
BACK DOOR OPENER SWITCH DLK-280
BACK DOOR TRIM INT-43
BACK DOOR WINDOW GLASS GW-32
BATTERY PG-108
BATTERY INSPECTION PG-102
BATTERY SENSOR PG-125
BATTERY TRAY PG-116
BCM BCS-32, BCS-63, BCS-248, BRC-74, CHG-14, HRN-8, MWI-87, WW-22
BCM (BODY CONTROL MODULE) ADP-33, SE-21
BCM - LEFT FRONT DOOR CONTROL UNIT CIRCUIT LAN-143
BCM, ELECTRONIC IGNITION SWITCH CONTROL UNIT DLK-40, SEC-17
BCM, FRONT DOOR CONTROL UNIT EXL-74, EXL-360, INL-23, MIR-27, PWC-13
BCM, OVERHEAD CONTROL PANEL CONTROL UNIT HAC-39
BLOWER MOTOR VTL-14
BLOWER REGULATOR HAC-129
BODY ALIGNMENT BRM-175
BODY CAN COMMUNICATION 1 ..... LAN-65
BODY CAN COMMUNICATION 2 ..... LAN-68
BODY COMPONENT PARTS BRM-107
BODY CONSTRUCTION BRM-125
BODY EXTERIOR PAINT COLOR BRM-95, EXT-13
BODY MAINTENANCE MA-39
BODY SIDE TRIM INT-23
BODY WELDING AND PRECAUTIONS ... BRM-34
BOSE AMP. AV-90, AV-246
BRAKE BOOSTER BR-13, BR-29
BRAKE CONTROL SYSTEM BRC-75
BRAKE FLUID BR-11
BRAKE MASTER CYLINDER BR-26
BRAKE PEDAL BR-10, BR-17
BRAKE PIPING BR-20

BREAKING-IN OF REFRIGERANT COMPRESSOR HAC-51
BSW INDICATOR.....DAS-179

C

C0000 CONTROL UNIT..... BRC-90
C0001 CONTROL UNIT..... BRC-91
C0001 ELECTRONIC STABILITY PROGRAM CONTROL UNIT EC-271
C0002 CONTROL UNIT..... BRC-92
C0002 ELECTRONIC STABILITY PROGRAM CONTROL UNIT EC-272
C0003 CONTROL UNIT..... BRC-93
C0004 CONTROL UNIT..... BRC-94
C0005 CONTROL UNIT..... BRC-95
C0006 CONTROL UNIT..... BRC-97
C0007 CONTROL UNIT..... BRC-99
C0008 CONTROL UNIT..... BRC-101
C0009 CONTROL UNIT..... BRC-102
C000A CONTROL UNIT BRC-103
C000B CONTROL UNIT BRC-104
C000C CONTROL UNIT BRC-105
C000D CONTROL UNIT BRC-106
C000E CONTROL UNIT BRC-107
C000F CONTROL UNIT BRC-108
C0010 CONTROL UNIT..... BRC-109
C0011 CONTROL UNIT BRC-110
C0012 CONTROL UNIT.....BRC-111
C0016 WHEEL SENSOR..... EC-273
C001A WHEEL SENSOR EC-274
C001E WHEEL SENSOR EC-275
C0020 EPS PUMP MOTOR CONTROL EC-276
C0021 BRAKE BOOSTER..... EC-277
C0022 BRAKE BOOSTER..... EC-278
C0024 CONTROL UNIT.....BRC-112
C002B CONTROL UNIT BRC-114
C002C CONTROL UNIT BRC-115
C002D CONTROL UNIT BRC-116
C002E CONTROL UNIT BRC-117
C0030 CONTROL UNIT.....BRC-118
C0030 WHEEL SPEED SENSOR EC-279
C0031 CONTROL UNIT.....BRC-119
C0031 WHEEL SPEED SENSOR EC-280
C0032 CONTROL UNIT..... BRC-120
C0032 WHEEL SPEED SENSOR EC-281
C0033 CONTROL UNIT..... BRC-121
C0033 WHEEL SPEED SENSOR EC-282
C0034 CONTROL UNIT..... BRC-122
C0034 WHEEL SPEED SENSOR EC-283
C0035 CONTROL UNIT..... BRC-123
C0035 WHEEL SPEED SENSOR EC-284
C0036 CONTROL UNIT..... BRC-124
C0036 WHEEL SPEED SENSOR EC-285
C0037 CONTROL UNIT..... BRC-125
C0037 WHEEL SPEED SENSOR EC-286
C0038 CONTROL UNIT..... BRC-126
C0038 WHEEL SPEED SENSOR..... EC-287
C0039 WHEEL SPEED SENSOR..... EC-288
C003A CONTROL UNIT BRC-127
C003A WHEEL SPEED SENSOR EC-289
C003B CONTROL UNIT BRC-128
C003B WHEEL SPEED SENSOR EC-290
C003D CONTROL UNIT BRC-129
C003E CONTROL UNIT BRC-130
C003F CONTROL UNIT..... BRC-131
C0040 CONTROL UNIT..... BRC-132
C0041 CONTROL UNIT..... BRC-133
C0042 CONTROL UNIT..... BRC-134
C0043 CONTROL UNIT..... BRC-136
C0044 CONTROL UNIT..... BRC-138
C0045 CONTROL UNIT..... BRC-140
C0046 CONTROL UNIT..... BRC-142
C0048 BRAKE BOOSTER..... EC-291
C0048 CONTROL UNIT..... BRC-144
C0049 BLAKE FLUID LEVEL SWITCH ... MWI-127
C0049 CONTROL UNIT..... BRC-146
C004A CONTROL UNIT BRC-147
C004B CONTROL UNIT BRC-148
C004D CONTROL UNIT BRC-150
C0071 BRAKE LIGHT SWITCH..... BRC-152
C0073 BRAKE LIGHT SWITCH..... BRC-154
C0075 BRAKE LIGHT SWITCH..... BRC-156
C0076 BRAKE LIGHT SWITCH..... BRC-159
C0077 BRAKE LIGHT SWITCH..... BRC-161
C0078 BRAKE LIGHT SWITCH..... BRC-163
C0080 DISC ROTOR BRC-167
C0081 DISC ROTOR BRC-168
C00B0 STEERING ANGLE SENSOR SYSTEM..... BRC-169
C00B1 AXLE RPM SENSOR..... BRC-171
C00B2 CONTROL UNIT BRC-173
C00C0 ACCELERATION SENSOR BRC-174
C00C1 ACCELERATION SENSOR BRC-176
C00C2 ROTATION RATE SENSOR..... BRC-177
C00C3 ROTATION RATE SENSOR..... BRC-179
C00C4 ROTATION RATE SENSOR..... BRC-181
C00C5 ROTATION RATE SENSOR..... BRC-183
C00C6 ACCELERATION SENSOR BRC-185
C00C9 ROTATION RATE SENSOR..... BRC-186
C00CA ROTATION RATE SENSOR BRC-188
C00CB ACCELERATION SENSOR..... BRC-190
C00CC ROTATION RATE SENSOR..... BRC-191
C00CD ROTATION RATE SENSOR..... BRC-193
C00D0 CONTROL UNIT BRC-195
C0100 POWER SUPPLY CIRCUIT..... BRC-197
C0105 POWER SUPPLY CIRCUIT..... BRC-198
C0106 VALVE RELAY/VALVE BRC-199
C0111 POWER SUPPLY CIRCUIT BRC-201
C0112 POWER SUPPLY CIRCUIT..... BRC-202
C0114 CONTROL UNIT BRC-204
C0116 CONTROL UNIT BRC-205
C0117 CONTROL UNIT BRC-206

C0120 POWER SUPPLY CIRCUIT BRC-208
C0130 PRESSURE SENSOR (FRONT LEFT) BRC-210
C0131 PRESSURE SENSOR (FRONT LEFT) BRC-212
C0133 PRESSURE SENSOR (FRONT LEFT) BRC-214
C0134 CONTROL UNIT BRC-216
C0140 PRESSURE SENSOR (FRONT RIGHT) BRC-217
C0142 PRESSURE SENSOR (FRONT RIGHT) BRC-218
C0143 PRESSURE SENSOR (FRONT RIGHT) BRC-220
C0144 CONTROL UNIT BRC-222
C0150 PRESSURE SENSOR (MASTER CYLINDER) BRC-223
C0151 PRESSURE SENSOR (MASTER CYLINDER) BRC-225
C0152 PRESSURE SENSOR (MASTER CYLINDER) BRC-227
C0160 PRESSURE SENSOR (REAR LEFT) BRC-229
C0161 PRESSURE SENSOR (REAR LEFT) BRC-231
C0163 PRESSURE SENSOR (REAR LEFT) BRC-233
C0164 CONTROL UNIT BRC-235
C0170 MAIN SHIFTER SHAFT POSITION SENSOR BRC-237
C0171 MAIN SHIFTER SHAFT POSITION SENSOR BRC-238
C0180 AXLE RPM SENSOR BRC-239
C0181 AXLE RPM SENSOR BRC-241
C0185 AXLE RPM SENSOR BRC-243
C0191 MOTOR RELAY BRC-244
C0195 RETURN PUMP BRC-245
C0196 RETURN PUMP BRC-246
C0197 RETURN PUMP BRC-247
C0198 RETURN PUMP BRC-249
C019C CONTROL UNIT BRC-250
C019D RETURN PUMP BRC-251
C019E RETURN PUMP BRC-252
C019F RETURN PUMP BRC-253
C01A0 RETURN PUMP BRC-255
C01A1 RETURN PUMP BRC-256
C01A2 RETURN PUMP BRC-258
C01A3 RETURN PUMP BRC-260
C01A4 RETURN PUMP BRC-262
C01A5 RETURN PUMP BRC-264
C01A6 RETURN PUMP BRC-266
C01A7 RETURN PUMP BRC-268
C01A8 RETURN PUMP BRC-270
C01A9 MOTOR RELAY BRC-272
C01AA RETURN PUMP BRC-274
C01AB RETURN PUMP BRC-276
C01C0 BRAKE VACUUM SENSOR BRC-278
C01C1 BRAKE VACUUM SENSOR BRC-280
C01C2 BRAKE VACUUM SENSOR BRC-282
C01C3 BRAKE VACUUM SENSOR BRC-285
C01C4 BRAKE VACUUM SENSOR BRC-288
C01C5 BRAKE VACUUM SENSOR BRC-289
C01C6 CONTROL UNIT BRC-290
C01D0 VALVE RELAY BRC-291
C01D1 VALVE RELAY BRC-293
C01D2 VALVE RELAY BRC-295
C01D3 VALVE RELAY BRC-297
C01D4 VALVE RELAY BRC-299
C01D5 VALVE RELAY BRC-301
C01D6 VALVE RELAY BRC-303
C01D7 VALVE RELAY BRC-304
C01F0 CONTROL UNIT BRC-306
C0200 ACCELERATION SENSOR BRC-308
C0201 ACCELERATION SENSOR BRC-310
C0220 CAN COMMUNICATION BRC-312
C0221 CAN COMMUNICATION BRC-314
C0224 CAN COMMUNICATION BRC-316
C0225 CAN COMMUNICATION BRC-317
C0240 EXHAUST VALVE (FRONT LEFT) BRC-318
C0241 EXHAUST VALVE (FRONT LEFT) BRC-319
C0242 EXHAUST VALVE (FRONT LEFT) BRC-320
C0243 EXHAUST VALVE (FRONT LEFT) BRC-321
C0244 EXHAUST VALVE (FRONT LEFT) BRC-322
C0245 EXHAUST VALVE (FRONT LEFT) BRC-323
C0246 EXHAUST VALVE (FRONT LEFT) BRC-324
C0250 EXHAUST VALVE (FRONT RIGHT) BRC-325
C0251 EXHAUST VALVE (FRONT RIGHT) BRC-326
C0252 EXHAUST VALVE (FRONT RIGHT) BRC-327
C0253 EXHAUST VALVE (FRONT RIGHT) BRC-328
C0254 EXHAUST VALVE (FRONT RIGHT) BRC-329
C0255 EXHAUST VALVE (FRONT RIGHT) BRC-330
C0256 EXHAUST VALVE (FRONT RIGHT) BRC-331
C0260 EXHAUST VALVE (REAR LEFT) .. BRC-332
C0261 EXHAUST VALVE (REAR LEFT) .. BRC-333
C0262 EXHAUST VALVE (REAR LEFT) .. BRC-334
C0263 EXHAUST VALVE (REAR LEFT) .. BRC-335
C0264 EXHAUST VALVE (REAR LEFT) .. BRC-336
C0265 EXHAUST VALVE (REAR LEFT) .. BRC-337
C0266 EXHAUST VALVE (REAR LEFT) .. BRC-338
C0270 YAW RATE SENSOR BRC-339
C0271 EXHAUST VALVE (REAR RIGHT) BRC-341
C0272 EXHAUST VALVE (REAR RIGHT) BRC-342
C0273 EXHAUST VALVE (REAR RIGHT) BRC-343
C0274 EXHAUST VALVE (REAR RIGHT) BRC-344
C0275 EXHAUST VALVE (REAR RIGHT) BRC-345
C0276 EXHAUST VALVE (REAR RIGHT) BRC-346
C0280 ADMISSION VALVE (FRONT LEFT) BRC-347
C0281 ADMISSION VALVE (FRONT LEFT) BRC-348
C0282 ADMISSION VALVE (FRONT LEFT) BRC-349

C0283 ADMISSION VALVE (FRONT LEFT)..... BRC-350
C0284 ADMISSION VALVE (FRONT LEFT)..... BRC-351
C0286 ADMISSION VALVE (FRONT LEFT)..... BRC-352
C0287 ADMISSION VALVE (FRONT LEFT)..... BRC-353
C0289 ADMISSION VALVE (FRONT LEFT)..... BRC-354
C0290 ADMISSION VALVE (FRONT RIGHT) BRC-355
C0291 ADMISSION VALVE (FRONT RIGHT) BRC-356
C0292 ADMISSION VALVE (FRONT RIGHT) BRC-357
C0293 ADMISSION VALVE (FRONT RIGHT) BRC-358
C0294 ADMISSION VALVE (FRONT RIGHT) BRC-359
C0296 ADMISSION VALVE (FRONT RIGHT) BRC-360
C0297 ADMISSION VALVE (FRONT RIGHT) BRC-361
C0298 ADMISSION VALVE (FRONT RIGHT) BRC-362
C02A0 ADMISSION VALVE (REAR LEFT)BRC-363
C02A1 ADMISSION VALVE (REAR LEFT)BRC-364
C02A2 ADMISSION VALVE (REAR LEFT)BRC-365
C02A3 ADMISSION VALVE (REAR LEFT)BRC-366
C02A4 ADMISSION VALVE (REAR LEFT)BRC-367
C02A6 ADMISSION VALVE (REAR LEFT)BRC-368
C02A7 ADMISSION VALVE (REAR LEFT)BRC-369
C02A8 ADMISSION VALVE (REAR LEFT)BRC-370
C02B0 ADMISSION VALVE (REAR RIGHT) BRC-371
C02B1 ADMISSION VALVE (REAR RIGHT) BRC-372
C02B2 ADMISSION VALVE (REAR RIGHT) BRC-373
C02B3 ADMISSION VALVE (REAR RIGHT) BRC-374
C02B4 ADMISSION VALVE (REAR RIGHT) BRC-375
C02B6 ADMISSION VALVE (REAR RIGHT) BRC-376
C02B7 ADMISSION VALVE (REAR RIGHT) BRC-377
C02B8 ADMISSION VALVE (REAR RIGHT) BRC-378
C02C0 VALVE DRIVER BRC-379
C02C1 VALVE BRC-380
C02C2 VALVE BRC-381
C02C3 VALVE BRC-382
C02C5 VALVE DRIVER BRC-383
C02C6 VALVE DRIVER BRC-384
C02C7 VALVE DRIVER BRC-385
C02C8 VALVE DRIVER BRC-386
C02C9 VALVE DRIVER BRC-387
C02CA VALVE DRIVER BRC-388
C02CB VALVE DRIVER BRC-389
C02CC VALVE DRIVER BRC-390
C02CD VALVE BRC-391
C02CE VALVE BRC-392
C02CF VALVE DRIVER BRC-393
C02D0 HIGH PRESSURE VALVE 1 ..... BRC-394
C02D1 HIGH PRESSURE VALVE 1 ..... BRC-395
C02D2 HIGH PRESSURE VALVE 1 ..... BRC-396
C02D3 HIGH PRESSURE VALVE 1 ..... BRC-397
C02D4 HIGH PRESSURE VALVE 1 ..... BRC-399
C02D5 HIGH PRESSURE VALVE 1 ..... BRC-400
C02D6 HIGH PRESSURE VALVE 1 ..... BRC-401
C02D7 HIGH PRESSURE VALVE 1 ..... BRC-402
C02E0 HIGH PRESSURE VALVE 2..... BRC-403
C02E1 HIGH PRESSURE VALVE 2..... BRC-404
C02E2 HIGH PRESSURE VALVE2..... BRC-405
C02E3 HIGH PRESSURE VALVE 2..... BRC-406
C02E4 HIGH PRESSURE VALVE 2..... BRC-408
C02E5 HIGH PRESSURE VALVE 2..... BRC-409
C02E6 HIGH PRESSURE VALVE 2..... BRC-410
C02E7 HIGH PRESSURE VALVE 2.....BRC-411
C02F0 SWITCHING VALVE 1 ..... BRC-412
C02F1 SWITCHING VALVE 1 ..... BRC-413
C02F2 SWITCHING VALVE 1 ..... BRC-414
C02F3 SWITCHING VALVE 1 ..... BRC-415
C02F4 SWITCHING VALVE 1 ..... BRC-417
C02F5 SWITCHING VALVE 1 ..... BRC-418
C02F6 SWITCHING VALVE 1 ..... BRC-419
C02F7 SWITCHING VALVE 1 ..... BRC-421
C02F8 SWITCHING VALVE 1 ..... BRC-422
C0300 SWITCHING VALVE 2 ..... BRC-423
C0301 SWITCHING VALVE 2 ..... BRC-424
C0302 SWITCHING VALVE 2 ..... BRC-425
C0303 SWITCHING VALVE 2 ..... BRC-426
C0304 SWITCHING VALVE 2 ..... BRC-428
C0305 SWITCHING VALVE 2 ..... BRC-429
C0306 SWITCHING VALVE 2 ..... BRC-431
C0307 SWITCHING VALVE 2 ..... BRC-432
C0308 SWITCHING VALVE 2 ..... BRC-433
C0310 CONTROL UNIT BRC-434
C0311 CONTROL UNIT BRC-436
C0313 CONTROL UNIT BRC-437
C0314 AXLE RPM SENSOR BRC-438
C0315 POWER SUPPLY CIRCUIT..... BRC-440
C0320 YAW RATE SENSOR BRC-442
C0321 YAW RATE SENSOR BRC-443
C0323 YAW RATE SENSOR BRC-444
C0325 YAW RATE SENSOR BRC-445
C0326 YAW RATE SENSOR BRC-446
C0327 YAW RATE SENSOR BRC-448
C0328 YAW RATE SENSOR BRC-450
C0329 YAW RATE SENSOR BRC-452

C032A YAW RATE SENSOR BRC-454
C032B YAW RATE SENSOR BRC-456
C032C YAW RATE SENSOR BRC-458
C032D YAW RATE SENSOR BRC-460
C032E YAW RATE SENSOR BRC-462
C0330 LONGITUDINAL ACCELERATION SENSOR BRC-464
C0331 LONGITUDINAL ACCELERATION SENSOR BRC-466
C0332 LONGITUDINAL ACCELERATION SENSOR BRC-468
C0333 LONGITUDINAL ACCELERATION SENSOR BRC-470
C0334 LONGITUDINAL ACCELERATION SENSOR BRC-472
C0340 LATERAL ACCELERATION SENSOR BRC-474
C0341 LATERAL ACCELERATION SENSOR BRC-476
C0342 LATERAL ACCELERATION SENSOR BRC-477
C0343 LATERAL ACCELERATION SENSOR BRC-479
C0344 LATERAL ACCELERATION SENSOR BRC-481
C0350 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM..... BRC-482
C0351 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM..... BRC-483
C0352 FRONT RIGHT DOOR SYSTEM.. BRC-484
C0353 FRONT LEFT DOOR SYSTEM BRC-485
C0354 BACK DOOR SYSTEM..... BRC-486
C0356 TRANSMISSION SYSTEM BRC-487
C0360 ENGINE SYSTEM BRC-488
C0361 ENGINE SYSTEM BRC-489
C0370 TRANSMISSION SYSTEM BRC-490
C0375 ENGINE SYSTEM BRC-491
C0380 ENGINE SYSTEM BRC-492
C0381 ENGINE SYSTEM BRC-493
C0382 ENGINE SYSTEM BRC-494
C0383 ENGINE SYSTEM BRC-495
C0384 ENGINE SYSTEM BRC-497
C0385 ENGINE SYSTEM BRC-498
C0390 ENGINE SYSTEM BRC-499
C0391 ENGINE SYSTEM BRC-500
C0392 ENGINE SYSTEM BRC-501
C0393 ENGINE SYSTEM BRC-502
C0394 ENGINE SYSTEM BRC-503
C03A0 ENGINE SYSTEM BRC-504
C03A1 ENGINE SYSTEM BRC-505
C03A2 ENGINE SYSTEM BRC-506
C03A3 ENGINE SYSTEM BRC-507
C03A4 ENGINE SYSTEM BRC-508
C03A5 ENGINE SYSTEM BRC-510
C03A6 ENGINE SYSTEM BRC-512
C03B0 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM..... BRC-514
C03B1 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM..... BRC-515
C03B2 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM..... BRC-516
C03B3 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM..... BRC-517
C03C0 ELECTRIC PARKING BRAKE SYSTEM..... BRC-518
C03C1 ELECTRIC PARKING BRAKE SYSTEM..... BRC-519
C03C2 ELECTRIC PARKING BRAKE SYSTEM..... BRC-520
C03C3 ELECTRIC PARKING BRAKE SYSTEM..... BRC-521
C03C4 ELECTRIC PARKING BRAKE SYSTEM..... BRC-522
C03D0 COMBINATION METER SYSTEMBRC-523
C03D1 COMBINATION METER SYSTEMBRC-524
C03E0 COMBINATION METER SYSTEMBRC-525
C03E1 COMBINATION METER SYSTEMBRC-526
C03E2 COMBINATION METER SYSTEMBRC-527
C03E3 COMBINATION METER SYSTEMBRC-528
C03E4 COMBINATION METER SYSTEMBRC-529
C03F0 COMBINATION METER SYSTEMBRC-530
C03F1 COMBINATION METER SYSTEMBRC-531
C03F2 COMBINATION METER SYSTEMBRC-532
C0400 STEERING COLUMN CONTROL MODULE SYSTEM..... BRC-533
C0401 STEERING COLUMN CONTROL MODULE SYSTEM..... BRC-534
C0403 STEERING COLUMN CONTROL MODULE SYSTEM..... BRC-535
C0404 STEERING COLUMN CONTROL MODULE SYSTEM..... BRC-536
C0410 AXLE RPM SENSOR..... BRC-537
C0420 AXLE RPM SENSOR..... BRC-539
C0430 AXLE RPM SENSOR..... BRC-541
C0451 STEERING ANGLE SENSOR SYSTEM..... BRC-543
C0452 STEERING ANGLE SENSOR SYSTEM..... BRC-545
C0453 STEERING ANGLE SENSOR SYSTEM..... BRC-547
C0454 STEERING ANGLE SENSOR SYSTEM..... BRC-549
C0456 STEERING ANGLE SENSOR SYSTEM..... BRC-551
C0457 STEERING ANGLE SENSOR SYSTEM..... BRC-553
C045A STEERING ANGLE SENSOR SYSTEM BRC-555
C045B STEERING ANGLE SENSOR SYSTEM BRC-557

C0460 FRONT LEFT AXLE RPM SENSOR BRC-559
C0470 FRONT RIGHT AXLE RPM SENSOR..... BRC-561
C0480 REAR LEFT AXLE RPM SENSORBRC-563
C0490 REAR RIGHT AXLE RPM SENSOR BRC-565
C04A0 FRONT LEFT AXLE RPM SENSOR..... BRC-567
C04A1 FRONT LEFT AXLE RPM SENSOR..... BRC-569
C04A2 FRONT LEFT AXLE RPM SENSOR..... BRC-571
C04A3 FRONT LEFT AXLE RPM SENSOR..... BRC-573
C04A4 FRONT LEFT AXLE RPM SENSOR..... BRC-575
C04A6 FRONT LEFT AXLE RPM SENSOR..... BRC-576
C04A7 FRONT LEFT AXLE RPM SENSOR..... BRC-578
C04AA FRONT LEFT AXLE RPM SENSOR BRC-580
C04AB FRONT LEFT AXLE RPM SENSOR BRC-582
C04AC FRONT LEFT AXLE RPM SENSOR BRC-584
C04AD FRONT LEFT AXLE RPM SENSOR BRC-586
C04AE FRONT LEFT AXLE RPM SENSOR BRC-588
C04AF FRONT LEFT AXLE RPM SENSOR BRC-590
C04B0 FRONT LEFT AXLE RPM SENSOR..... BRC-592
C04B1 FRONT LEFT AXLE RPM SENSOR..... BRC-594
C04B3 FRONT LEFT AXLE RPM SENSOR..... BRC-596
C04B4 FRONT LEFT AXLE RPM SENSOR..... BRC-598
C04B5 FRONT LEFT AXLE RPM SENSOR..... BRC-600
C04C0 FRONT RIGHT AXLE RPM SENSOR BRC-602
C04C1 FRONT RIGHT AXLE RPM SENSOR BRC-604
C04C2 FRONT RIGHT AXLE RPM SENSOR BRC-606
C04C3 FRONT RIGHT AXLE RPM SENSOR BRC-608
C04C4 FRONT RIGHT AXLE RPM SENSOR BRC-610
C04C6 FRONT RIGHT AXLE RPM SENSOR BRC-611
C04C7 FRONT RIGHT AXLE RPM SENSOR BRC-613
C04CA FRONT RIGHT AXLE RPM SENSOR..... BRC-615
C04CB FRONT RIGHT AXLE RPM SENSOR..... BRC-617
C04CC FRONT RIGHT AXLE RPM SENSOR..... BRC-619
C04CD FRONT RIGHT AXLE RPM SENSOR..... BRC-621
C04CE FRONT RIGHT AXLE RPM SENSOR..... BRC-623
C04CF FRONT RIGHT AXLE RPM SENSOR BRC-625
C04D0 FRONT RIGHT AXLE RPM SENSOR BRC-627
C04D1 FRONT RIGHT AXLE RPM SENSOR BRC-629
C04D3 FRONT RIGHT AXLE RPM SENSOR BRC-631
C04D4 FRONT RIGHT AXLE RPM SENSOR BRC-633
C04D5 FRONT RIGHT AXLE RPM SENSOR BRC-635
C04E0 REAR LEFT AXLE RPM SENSORBRC-637
C04E1 REAR LEFT AXLE RPM SENSORBRC-639
C04E2 REAR LEFT AXLE RPM SENSORBRC-641
C04E3 REAR LEFT AXLE RPM SENSORBRC-643
C04E4 REAR LEFT AXLE RPM SENSORBRC-645
C04E6 REAR LEFT AXLE RPM SENSORBRC-646
C04E7 REAR LEFT AXLE RPM SENSORBRC-648
C04EA REAR LEFT AXLE RPM SENSORBRC-650
C04EB REAR LEFT AXLE RPM SENSORBRC-652
C04EC REAR LEFT AXLE RPM SENSORBRC-654
C04ED REAR LEFT AXLE RPM SENSORBRC-656
C04EE REAR LEFT AXLE RPM SENSORBRC-658
C04EF REAR LEFT AXLE RPM SENSORBRC-660
C04F0 REAR LEFT AXLE RPM SENSORBRC-662
C04F1 REAR LEFT AXLE RPM SENSORBRC-664
C04F3 REAR LEFT AXLE RPM SENSORBRC-666
C04F4 REAR LEFT AXLE RPM SENSORBRC-668
C04F5 REAR LEFT AXLE RPM SENSORBRC-670
C0500 REAR RIGHT AXLE RPM SENSOR BRC-672
C0501 REAR RIGHT AXLE RPM SENSOR BRC-674
C0502 REAR RIGHT AXLE RPM SENSOR BRC-676
C0503 REAR RIGHT AXLE RPM SENSOR BRC-678
C0504 REAR RIGHT AXLE RPM SENSOR BRC-680
C0506 REAR RIGHT AXLE RPM SENSOR BRC-681
C0507 REAR RIGHT AXLE RPM SENSOR BRC-683

C050A REAR RIGHT AXLE RPM SENSOR BRC-685
C050B REAR RIGHT AXLE RPM SENSOR BRC-687
C050C REAR RIGHT AXLE RPM SENSOR BRC-689
C050D REAR RIGHT AXLE RPM SENSOR BRC-691
C050E REAR RIGHT AXLE RPM SENSOR BRC-693
C050F REAR RIGHT AXLE RPM SENSOR BRC-695
C0510 REAR RIGHT AXLE RPM SENSOR BRC-697
C0511 REAR RIGHT AXLE RPM SENSOR BRC-699
C0513 REAR RIGHT AXLE RPM SENSOR BRC-701
C0514 REAR RIGHT AXLE RPM SENSOR BRC-703
C0540 ELECTRIC SHIFT SELECTOR SYSTEM BRC-705
C0541 ELECTRIC SHIFT SELECTOR SYSTEM BRC-706
C0542 ELECTRIC SHIFT SELECTOR SYSTEM BRC-707
C0543 ENGINE SYSTEM BRC-708
C0560 ENGINE SYSTEM BRC-709
C0561 ENGINE SYSTEM BRC-710
C0570 COMBINATION METER SYSTEM BRC-711
C0571 COMBINATION METER SYSTEM BRC-712
C0572 COMBINATION METER SYSTEM BRC-713
C0573 COMBINATION METER SYSTEM BRC-714
C0580 COMBINATION METER SYSTEM BRC-715
C0581 COMBINATION METER SYSTEM BRC-716
C0582 COMBINATION METER SYSTEM BRC-717
C05C0 AIR BAG DIAGNOSIS SENSOR UNIT SYSTEM BRC-718
C05C1 AIR BAG DIAGNOSIS SENSOR UNIT SYSTEM BRC-719
C05C2 DRIVER SEAT BUCKLE SWITCH SYSTEM BRC-720
C05D0 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-721
C05D1 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-723
C05D2 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-725
C05D3 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-727
C05D4 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-729
C05E0 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-731
C05E1 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-733
C05F0 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-735
C05F1 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-736
C05F3 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-737
C05F6 REAR RIGHT AXLE RPM SENSOR BRC-738
C0600 STEERING COLUMN CONTROL MODULE SYSTEM BRC-740
C0601 STEERING COLUMN CONTROL MODULE SYSTEM BRC-741
C0610 STEERING COLUMN CONTROL MODULE SYSTEM BRC-742
C0611 STEERING COLUMN CONTROL MODULE SYSTEM BRC-743
C0612 STEERING COLUMN CONTROL MODULE SYSTEM BRC-744
C0613 STEERING COLUMN CONTROL MODULE SYSTEM BRC-745
C0614 STANDSTILL CONTROL (SSC) ... BRC-746
C0630 STEERING CONTROL SYSTEM . BRC-747
C0631 STEERING CONTROL SYSTEM . BRC-748
C0632 STEERING CONTROL SYSTEM . BRC-749
C0633 STEERING CONTROL SYSTEM . BRC-750
C0640 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-751
C0641 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-752
C0642 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-753
C0650 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-754
C0651 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-755
C0652 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-756
C0656 COMBINATION METER SYSTEM BRC-757
C0660 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-758
C0661 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-759
C0662 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-760
C0663 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-761
C0664 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-762
C0665 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-763
C0670 BCM SYSTEM BRC-764
C0671 BCM SYSTEM BRC-765
C0672 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-766
C0690 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-767

C0691 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-768
C06A0 ENGINE/TRANSMISSION SYSTEM BRC-769
C06A1 ENGINE/TRANSMISSION SYSTEM BRC-770
C06A3 ENGINE/TRANSMISSION SYSTEM BRC-772
C06A5 ENGINE/4WD SYSTEM..... BRC-773
C06A6 ENGINE/4WD SYSTEM..... BRC-774
C06AA SONAR CONTROL UNIT SYSTEM BRC-776
C06AB SONAR CONTROL UNIT SYSTEM BRC-777
C06AC SONAR CONTROL UNIT SYSTEM BRC-778
C06AD SONAR CONTROL UNIT SYSTEM BRC-779
C06AE SONAR CONTROL UNIT SYSTEM BRC-780
C06AF SONAR CONTROL UNIT SYSTEMBRC-781
C06B0 ACCELERATION SENSOR BRC-782
C06B1 ACCELERATION SENSOR BRC-783
C06B2 ACCELERATION SENSOR BRC-784
C06B3 ACCELERATION SENSOR BRC-786
C06B4 ACCELERATION SENSOR BRC-787
C06B5 ACCELERATION SENSOR BRC-789
C06B6 ACCELERATION SENSOR BRC-790
C06B7 ACCELERATION SENSOR BRC-791
C06B8 ACCELERATION SENSOR BRC-792
C06B9 ACCELERATION SENSOR BRC-794
C06BA ACCELERATION SENSOR..... BRC-796
C06BB ACCELERATION SENSOR..... BRC-797
C06BC ACCELERATION SENSOR..... BRC-798
C06BD ACCELERATION SENSOR..... BRC-799
C06BE ACCELERATION SENSOR..... BRC-800
C06BF ACCELERATION SENSOR BRC-801
C06C0 ACCELERATION SENSOR BRC-802
C06C1 ACCELERATION SENSOR BRC-803
C06D0 YAW RATE SENSOR..... BRC-804
C06D1 YAW RATE SENSOR..... BRC-805
C06D2 YAW RATE SENSOR..... BRC-806
C06D3 YAW RATE SENSOR..... BRC-807
C06D4 YAW RATE SENSOR..... BRC-808
C06D5 YAW RATE SENSOR..... BRC-810
C06D6 YAW RATE SENSOR.....BRC-811
C06E0 YAW RATE SENSOR..... BRC-812
C06E1 YAW RATE SENSOR/ACCELERATION SENSOR..... BRC-813
C06E2 ACCELERATION SENSOR BRC-814
C06F0 STEERING ANGLE SENSOR SYSTEM..... BRC-815
C06F1 COMBINATION METER SYSTEMBRC-816
C06F2 COMBINATION METER SYSTEMBRC-817
C06F3 RAIN/LIGHT SENSOR..... BRC-818
C0730 BRAKE FLUID LEAKAGE BRC-820
C0731 TRANSMISSION SYSTEM..... BRC-821
C0732 ELECTRIC SHIFT SELECTOR SYSTEM ... BRC-823
C0733 BATTERY SYSTEM..... BRC-825
C0734 EXCEEDED MAXIMUM HOLDING TIME.... BRC-827
C0735 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-828
C0736 COMBINATION METER SYSTEM BRC-830
C0739 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-832
C073A ELECTRIC SHIFT SELECTOR SYSTEM ... BRC-834
C073B ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-836
C073C BRAKE FLUID LEAKAGE..... BRC-837
C073D TRANSMISSION SYSTEM..... BRC-838
C0741 CONTROL UNIT..... BRC-840
C0742 CONTROL UNIT..... BRC-841
C0743 CONTROL UNIT..... BRC-842
C0744 CAN COMMUNICATION BRC-843
C0745 CONTROL UNIT..... BRC-844
C0746 CONTROL UNIT..... BRC-845
C0747 CONTROL UNIT..... BRC-846
C0748 CONTROL UNIT..... BRC-847
C0749 CONTROL UNIT..... BRC-848
C074B CONTROL UNIT BRC-849
C0751 SWITCHING VALVE BRC-850
C0765 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-851
C0766 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-853
C0767 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-855
C0769 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-857
C076A ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-859
C076B ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-861
C0810 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-863
C0811 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-865
C0820 DOOR (DRIVER SIDE) SYSTEM. BRC-867
C0830 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-868
C0831 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-869
C0832 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-870
C0833 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-871
C0834 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-872

C0835 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-873
C0840 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-874
C0841 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-875
C0950 AXLE RPM SENSOR BRC-876
C0951 AXLE RPM SENSOR BRC-878
C0960 VALVE BRC-880
C0961 VALVE DRIVER BRC-881
C0962 VALVE BRC-882
C0963 VALVE DRIVER BRC-883
C0971 ELECTRIC PARKING BRAKE SYSTEM BRC-884
C0972 ELECTRIC PARKING BRAKE SYSTEM BRC-885
C0973 ELECTRIC PARKING BRAKE SYSTEM BRC-886
C0990 BRAKE FLUID LEAKAGE BRC-887
C0991 BRAKE FLUID LEAKAGE BRC-888
C09A0 ATTENTION ASSIST BRC-889
C09A1 LINEAR REGULATOR BRC-891
C0A00 BATTERY SYSTEM BRC-893
C0A01 BATTERY SYSTEM BRC-894
C0A02 BATTERY SYSTEM BRC-895
C0A03 BCM SYSTEM BRC-896
C0A04 ELECTRIC SHIFT SELECTOR SYSTEM ... BRC-897
C0A05 COMBINATION METER SYSTEM BRC-898
C0A06 BCM SYSTEM BRC-899
C0A07 BCM SYSTEM BRC-900
C0A08 BCM SYSTEM BRC-901
C0A09 BCM SYSTEM BRC-903
C0A0A BCM SYSTEM BRC-905
C0A0B ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-906
C0A30 EXCEEDED MAXIMUM HOLDING TIME ... BRC-907
C107D ELECTRONIC STABILITY PROGRAM CONTROL UNIT BCS-165
C10C5 TEMPERATURE SENSOR PB-75
C1101 RADAR SENSOR 5 HAS A MALFUNCTION DAS-103
C1111 RADAR SENSOR 5 IS DISRUPTED DAS-108
C1241 STEERING ANGLE SENSOR BCS-212
C1245 STEERING ANGLE SENSOR BCS-213
C151C TIRE PRESSURE SENSOR WT-43
C151E FRONT HEIGHT SENSOR EXL-245
C1526 REAR HEIGHT SENSOR EXL-249
C1580 TIRE PRESSURE SENSOR WT-44
C1581 TIRE PRESSURE SENSOR WT-46
C1592 EPS MOTOR STC-31
C1593 TORQUE SENSOR STC-34
C1599 TIRE PRESSURE SENSOR POWER SUPPLY WT-47
C1A03 VEHICLE SPEED SENSOR AV-308
C1A04 ABS/TCS/VDC SYSTEM AV-310
C1A39 STEERING ANGLE SENSOR AV-312
C2060 DYNAMOMETER MODE BRC-908
C2200 CAN MESSAGE ERROR (TRANSMISSION) CCS-72
C2201 CHASSIS CAN BUS OFF MALFUNCTION . CCS-73
C2202 CAN MESSAGE ERROR (TRANSMISSION) CCS-74
C2203 CAN MESSAGE ERROR (TRANSMISSION) CCS-75
C2204 RADAR IS MALFUNCTION CCS-76
C2205 RADAR IS MALFUNCTION CCS-77
C2205 STEERING ANGLE SENSOR BCS-214
C2206 RADAR IS MALFUNCTION CCS-78
C2207 RADAR IS MALFUNCTION CCS-79
C2208 RADAR IS MALFUNCTION CCS-80
C2209 CONTROL UNIT WT-48
C2209 RADAR IS MALFUNCTION CCS-81
C220A RADAR IS MALFUNCTION CCS-82
C220B RADAR IS MALFUNCTION CCS-83
C220E RADAR IS MALFUNCTION CCS-84
C220F RADAR IS MALFUNCTION CCS-85
C2210 RADAR IS MALFUNCTION CCS-86
C2211 RADAR IS MALFUNCTION CCS-87
C2212 RADAR IS MALFUNCTION CCS-88
C2214 RADAR IS MALFUNCTION CCS-89
C2215 RADAR IS MALFUNCTION CCS-90
C2216 RADAR IS MALFUNCTION CCS-91
C2217 RADAR IS MALFUNCTION CCS-92
C2218 RADAR IS MALFUNCTION CCS-93
C2219 RADAR IS MALFUNCTION CCS-94
C221A RADAR IS MALFUNCTION CCS-95
C221B RADAR IS MALFUNCTION CCS-96
C221C RADAR IS MALFUNCTION CCS-97
C221D RADAR IS MALFUNCTION CCS-98
C221E RADAR IS MALFUNCTION CCS-99
C221F RADAR IS MALFUNCTION CCS-100
C2220 RADAR IS MALFUNCTION CCS-101
C2221 RADAR IS MALFUNCTION CCS-102
C2222 RADAR IS MALFUNCTION CCS-103
C2223 RADAR IS MALFUNCTION CCS-104
C2224 RADAR IS MALFUNCTION CCS-105
C2225 RADAR IS MALFUNCTION CCS-106
C2226 RADAR IS MALFUNCTION CCS-107
C2227 RADAR IS MALFUNCTION CCS-108
C2228 RADAR IS MALFUNCTION CCS-109
C2229 RADAR IS MALFUNCTION CCS-110
C222A RADAR IS MALFUNCTION CCS-111
C222B RADAR IS MALFUNCTION CCS-112
C222C RADAR IS MALFUNCTION CCS-113
C222D RADAR IS BLOCKED BY DIRT/FOREIGN OBJECT CCS-114
C222E CRUISE FUNC IS TEMPORARILY UNAVAILABLE CCS-115

C2233 RADAR SENSOR IS MALADJUSTED CCS-116
C2235 RADAR SENSOR IS MALADJUSTED CCS-117
C2236 RADAR SENSOR IS MALADJUSTED CCS-118
C2237 INVALID DATA RECEIVED FROM VDCM .. CCS-119
C2238 INVALID DATA RECEIVED FROM VDCM .. CCS-120
C2239 INVALID DATA RECEIVED FROM VDCM .. CCS-121
C223A INVALID DATA RECEIVED FROM VDCM .. CCS-122
C223B INVALID DATA RECEIVED FROM VDCM .. CCS-123
C223C INVALID DATA RECEIVED FROM VDCM .. CCS-124
C223D RADAR IS MALFUNCTION CCS-125
C223E RADAR IS MALFUNCTION CCS-126
C223F RADAR IS MALFUNCTION CCS-127
C2240 RADAR IS MALFUNCTION..... CCS-128
C2241 RADAR IS MALFUNCTION..... CCS-129
C2242 RADAR IS MALFUNCTION..... CCS-130
C2243 RADAR IS MALFUNCTION..... CCS-131
C2244 RADAR IS MALFUNCTION..... CCS-132
C2245 POWER SUPPLY OF RADAR IS NOT OK . CCS-133
C2246 POWER SUPPLY OF RADAR IS NOT OK . CCS-134
C2247 POWER SUPPLY OF RADAR IS NOT OK . CCS-135
C2248 POWER SUPPLY OF RADAR IS NOT OK . CCS-136
C2249 POWER SUPPLY OF RADAR IS NOT OK . CCS-137
C224A RADAR IS MALFUNCTION CCS-138
C224B RADAR IS MALFUNCTION CCS-139
C224C RADAR IS MALFUNCTION CCS-140
C224D RADAR IS MALFUNCTION CCS-141
C224E RADAR IS MALFUNCTION CCS-142
C224F RADAR IS MALFUNCTION CCS-143
C2250 RADAR IS MALFUNCTION..... CCS-144
C2251 RADAR IS MALFUNCTION..... CCS-145
C2252 RADAR IS MALFUNCTION..... CCS-146
C2253 RADAR IS MALFUNCTION..... CCS-147
C2254 RADAR IS MALFUNCTION..... CCS-148
C2255 RADAR IS MALFUNCTION..... CCS-149
C2256 CONT MODULE INTERNAL TEMP A..... CCS-150
C2257 CONT MODULE INTERNAL TEMP A..... CCS-151
C2258 CONT MODULE INTERNAL TEMP A..... CCS-152
C2259 RADAR IS MALFUNCTION..... CCS-153
C225A INTERNAL CONTROL MODULE CCS-154
C225B NO CAN SIG RECEIVED FROM MOTOR ELEC CCS-155
C225C NO CAN SIG RECEIVED FROM MOTOR ELEC CCS-156
C225D NO CAN SIG RECEIVED FROM MOTOR ELEC CCS-157
C225E NO CAN SIG RECEIVED FROM MOTOR ELEC CCS-158
C2260 NO CAN SIGNAL RECEIVED FROM ESP . CCS-159
C2261 NO CAN SIGNAL RECEIVED FROM ESP . CCS-160
C2262 NO CAN SIGNAL RECEIVED FROM ESP . CCS-161
C2263 NO CAN SIGNAL RECEIVED FROM ESP . CCS-162
C2264 NO CAN SIGNAL RECEIVED FROM ESP . CCS-163
C2265 COMMUNICATION ERROR (INVALID)..... CCS-164
C2266 COMMUNICATION ERROR (INVALID)..... CCS-165
C2267 NO CAN SIG RECEIVED FROM COMB METER..... CCS-166
C2268 NO CAN SIGNAL RECEIVED FROM IGN LOCK CCS-167
C2269 ENGINE TORQUE REQUEST SIG IMPLAUSIBLE..... CCS-168
C226A INVALID DATA RECEIVED FROM VDCM .. CCS-169
C226C INVALID DATA RECEIVED FROM ECM/ PCM A..... CCS-170
C226D INVALID DATA RECEIVED FROM ECM/ PCM A..... CCS-171
C226E INVALID DATA RECEIVED FROM ECM/ PCM A..... CCS-172
C226F INVALID DATA RECEIVED FROM ECM/ PCM A..... CCS-173
C2271 INVALID DATA RECEIVED FROM VDCM .. CCS-174
C2272 INVALID DATA RECEIVED FROM VDCM .. CCS-175
C2273 INVALID DATA RECEIVED FROM VDCM .. CCS-176
C2274 INVALID DATA RECEIVED FROM VDCM .. CCS-177
C2275 INVALID DATA RECEIVED FROM VDCM .. CCS-178
C2276 CAN SIGNAL FROM SCCM IS MALFUNCTION CCS-179
C2277 CAN SIGNAL FROM SCCM IS MALFUNCTION CCS-180
C2278 CAN SIGNAL FROM COMB METER IS MALF..... CCS-181
C2279 CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-182

C227A INVALID DATA RECEIVED FROM ECM/ PCM A CCS-183
C227B INVALID DATA RECEIVED FROM ECM/ PCM A CCS-184
C227C INVALID DATA RECEIVED FROM ECM/ PCM A CCS-185
C227D INVALID DATA RECEIVED FROM ECM/ PCM A CCS-186
C227F INVALID DATA RECEIVED FROM VDCM .. CCS-187
C2280 INVALID DATA RECEIVED FROM VDCM... CCS-188
C2281 INVALID DATA RECEIVED FROM VDCM... CCS-189
C2282 INVALID DATA RECEIVED FROM VDCM... CCS-190
C2283 CAN SIGNAL FROM SCCM IS MALFUNCTION CCS-191
C2284 CAN SIGNAL FROM SCCM IS MALFUNCTION CCS-192
C2285 INVALID DATA RECEIVED FROM ECM/ PCM A CCS-193
C2286 INVALID DATA RECEIVED FROM ECM/ PCM A CCS-194
C2287 INVALID DATA RECEIVED FROM ECM/ PCM A CCS-195
C2288 INVALID DATA RECEIVED FROM ECM/ PCM A CCS-196
C228A INVALID DATA RECEIVED FROM VDCM .. CCS-197
C228B INVALID DATA RECEIVED FROM VDCM .. CCS-198
C228C INVALID DATA RECEIVED FROM VDCM .. CCS-199
C228D CAN SIGNAL FROM SCCM IS MALFUNCTION CCS-200
C228E CAN SIGNAL FROM SCCM IS MALFUNCTION CCS-201
C2291 VEHICLE SPEED SIGNAL IS IMPLAUSIBLE CCS-202
C2293 STATIC ENGINE TORQUE SIG IS IMPLAUSIBLE CCS-203
C2294 MAX ENGINE TORQUE SIG IS IMPLAUSIBLE CCS-204
C2295 MIN ENGINE TORQUE SIG IS IMPLAUSIBLE CCS-205
C2296 REQUESTED ENG TORQUE IS IMPLAUSIBLE CCS-206
C2297 ENGINE SPEED SIGNAL IS IMPLAUSIBLE CCS-207
C2299 CRANKSHAFT SIGNAL IS IMPLAUSIBLE . CCS-208
C229B ACTUAL GEAR SIGNAL IS IMPLAUSIBLE CCS-209
C229D INVALID DATA RECEIVED FROM VDCM .. CCS-210
C229E REQ BRK TRQ SIGNAL IS IMPLAUSIBLE. CCS-211
C229F CRUISE SHUTOFF SIGNAL IS IMPLAUSIBLE CCS-212
C22A1 LONGITUDINAL ACCELERATION IMPLAUSIBLE CCS-213
C22A2 YAW RATE SIG FROM ESP IS IMPLAUSIBLE CCS-214
C22A3 STRG SENSOR SIGNAL IS IMPLAUSIBLE CCS-215
C22A4 STRG SENSOR SIGNAL IS IMPLAUSIBLE CCS-216
C22A5 STEERING WHEEL ANGLE IS IMPLAUSIBLE CCS-217
C22A6 STEERING ANGLE SPEED IS IMPLAUSIBLE CCS-218
C22A7 PULSE COUNTER SIGNAL IS IMPLAUSIBLE CCS-219
C22A8 WHEEL SPEED FROM ESP IS IMPLAUSIBLE CCS-220
C22A9 WHL ROTATION DIRECTION SIG IMPLAUSIBLE CCS-221
C22AA STATUS SIGNAL FROM METER IS IMPLAUSIBLE CCS-222
C22AB VHCL SPD DISP SIGNAL IS IMPLAUSIBLE CCS-223
C22AC ACCEL PEDAL SENSOR SIG IS IMPLAUSIBLE CCS-224
C22AD BRAKE PEDAL POSITION SIG IS IMPLAUSIBLE CCS-225
C22AE BRAKE PEDAL POSITION SIG IS IMPLAUSIBLE CCS-226
C22AF CRUISE CONTROL LEVER SIG IS IMPLAUSIBLE CCS-227
C22B0 CRUISE CONT SIG FROM SCM IMPLAUSIBLE CCS-228
C22B1 TURN SIGNAL SW STATUS SIG IMPLAUSIBLE CCS-229
C22B2 OUTSIDE TEMPERATURE SIG IS IMPLAUSIBLE CCS-230
C22B3 OUTSIDE TEMPERATURE SIG IS IMPLAUSIBLE CCS-231
C22B6 ODO SIGNAL FROM METER IS IMPLAUSIBLE CCS-232
C22B7 ODO SIGNAL FROM METER IS IMPLAUSIBLE CCS-233
C22BB NO CAN SIGNAL RECEIVED FROM ESP . CCS-234
C22BC NO CAN SIG RECEIVED FROM COMB METER CCS-235
C22BE NO CAN SIGNAL RECEIVED FROM IGN LOCK CCS-236
C22BF INVALID DATA RECEIVED FROM VDCM .. CCS-237
C22C0 CAN SIGNAL FROM COMB METER IS MALF CCS-238

C22C2 CAN SIGNAL FROM IGN LOCK IS MALF . CCS-239
C22C3 INVALID DATA RECEIVED FROM VDCM.. CCS-240
C22C4 INVALID DATA RECEIVED FROM VDCM.. CCS-241
C22C6 CAN SIGNAL FROM IGN LOCK IS MALF . CCS-242
C22C7 BRAKE SIGNAL FROM ESP IS IMPLAUSIBLE CCS-243
C22C8 RADAR IS CURRENTLY NONFUNCTIONAL CCS-244
C22C9 RADAR IS CURRENTLY NONFUNCTIONAL CCS-245
C22CA RADAR IS CURRENTLY NONFUNCTIONAL CCS-246
C22CB RADAR IS MALFUNCTION..... CCS-247
C22CD RADAR IS BLOCKED BY DIRT/FOREIGN OBJECT CCS-248
C22CE DYNAMIC BRAKING MODE SIG IMPLAUSIBLE CCS-249
C22CF DYNAMIC BRAKING MODE SIG IMPLAUSIBLE CCS-250
C22D0 NO CAN SIGNAL RECEIVED FROM E-PKB CCS-251
C22D1 CAN SIGNAL FROM E-PKB IS MALFUNCTION CCS-252
C22D2 CAN SIGNAL FROM E-PKB IS MALFUNCTION CCS-253
C22D3 CAN SIGNAL FROM E-PKB IS MALFUNCTION CCS-254
C22D4 NO CAN SIGNAL RECEIVED FROM IGN LOCK CCS-255
C22D5 CAN SIGNAL FROM IGN LOCK IS MALF . CCS-256
C22D6 CAN SIGNAL FROM IGN LOCK IS MALF . CCS-257
C22D7 COUNTRY CODE SIGNAL IS IMPLAUSIBLE CCS-258
C22D9 FL TUMBLER SW STATUS IS IMPLAUSIBLE CCS-259
C22DA FR TUMBLER SW STATUS IS IMPLAUSIBLE CCS-260
C22DB RL TUMBLER SW STATUS IS IMPLAUSIBLE CCS-261
C22DC RR TUMBLER SW STATUS IS IMPLAUSIBLE CCS-262
C22DD CRUISE SHUTOFF SIGNAL IS IMPLAUSIBLE CCS-263
C22DE BRAKE SIGNAL FROM ESP IS IMPLAUSIBLE CCS-264
C22DF BRAKING TORQUE SIGNAL IS IMPLAUSIBLE CCS-265
C22E0 TARGET GEAR SIGNAL IS IMPLAUSIBLE CCS-266
C22E1 COMMUNICATION ERROR (INVALID) CCS-267
C22E2 CAN SIGNAL FROM SCCM IS MALFUNCTION CCS-268
C22E3 CAN SIGNAL FROM SCCM IS MALFUNCTION CCS-269
C22E4 CAN SIGNAL FROM SCCM IS MALFUNCTION CCS-270
C22E5 STEERING WHEEL ANGLE IS IMPLAUSIBLE..... CCS-271
C22E6 STEERING WHEEL ANGLE IS IMPLAUSIBLE..... CCS-272
C22E7 LONGITUDINAL ACCELERATION IMPLAUSIBLE..... CCS-273
C22E8 CAN SIGNAL FROM COMB METER IS MALF..... CCS-274
C22EA CRUISE SHUTOFF SIGNAL IS IMPLAUSIBLE..... CCS-275
C22EB VIN SIGNAL FROM IGN LOCK IS IMPLAUSIBLE..... CCS-276
C22EC SCN CODING OF RADAR IS MALFUNCTION CCS-277
C22ED RADAR SENSOR IS MALADJUSTED CCS-278
C22EE INVALID DATA RECEIVED FROM ECM/ PCM A..... CCS-279
C22EF INVALID DATA RECEIVED FROM ECM/ PCM A..... CCS-280
C22F0 INVALID DATA RECEIVED FROM ECM/ PCM A..... CCS-281
C22F1 INVALID DATA RECEIVED FROM ECM/ PCM A..... CCS-282
C22F2 NO CAN SIG RECEIVED FROM MOTOR ELEC..... CCS-283
C22F3 NO CAN SIG RECEIVED FROM MOTOR ELEC..... CCS-284
C22F4 NO CAN SIGNAL RECEIVED FROM IGN LOCK CCS-285
C22F5 CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-286
C22F6 CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-287
C22F7 CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-288
C22F9 CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-289
C22FA NO CAN SIGNAL RECEIVED FROM IGN LOCK CCS-290
C22FB STEERING VARIANT SIGNAL IS IMPLAUSIBLE..... CCS-291
C22FC STEERING VARIANT SIGNAL IS IMPLAUSIBLE..... CCS-292
C22FD ELECTRIC PKB SIGNAL IS IMPLAUSIBLE CCS-293
C22FF STATUS SIGNAL FROM ESP IS IMPLAUSIBLE..... CCS-294

C2303 RADAR IS MALFUNCTION CCS-295
C2304 WHEEL SPEED FROM ESP IS IMPLAUSIBLE CCS-296
C2305 WHEEL SPEED FROM ESP IS IMPLAUSIBLE CCS-297
C2306 NO CAN SIGNAL RECEIVED FROM IGN LOCK CCS-298
C2307 NO CAN SIGNAL RECEIVED FROM ESP .. CCS-299
C2308 NO CAN SIGNAL RECEIVED FROM IGN LOCK CCS-300
C2309 NO CAN SIGNAL RECEIVED FROM IGN LOCK CCS-301
C230A CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-302
C230B CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-303
C230C CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-304
C230D INVALID DATA RECEIVED FROM VDCM .. CCS-305
C230E CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-306
C230F T/M MODE SIGNAL IS IMPLAUSIBLE CCS-307
C2310 T/M MODE SIGNAL IS IMPLAUSIBLE CCS-308
C2311 BRAKING TORQUE SIGNAL IS IMPLAUSIBLE CCS-309
C2312 DRIVER BELT BUCKLE SIGNAL IS IMPLAUSIBLE CCS-310
C2313 DRIVER BELT BUCKLE SIGNAL IS IMPLAUSIBLE CCS-311
C2314 MAX SPEED LIMIT SIGNAL IS IMPLAUSIBLE CCS-312
C2315 INVALID DATA RECEIVED FROM VDCM... CCS-313
C2316 INVALID DATA RECEIVED FROM VDCM... CCS-314
C2317 NO CAN SIGNAL RECEIVED FROM ESP .. CCS-315
C2318 NO CAN SIGNAL RECEIVED FROM ESP .. CCS-316
C2319 NO CAN SIG RECEIVED FROM PARKING SYS CCS-317
C231A INVALID DATA RECEIVED FROM VDCM .. CCS-318
C231B INVALID DATA RECEIVED FROM VDCM .. CCS-319
C231C CAN SIGNAL FROM SONAR IS MALF CCS-320
C231E INVALID DATA RECEIVED FROM VDCM .. CCS-321
C231F INVALID DATA RECEIVED FROM VDCM .. CCS-322
C2320 INVALID DATA RECEIVED FROM VDCM... CCS-323
C2321 INVALID DATA RECEIVED FROM VDCM... CCS-324
C2322 BRAKE STATUS FROM ESP IS IMPLAUSIBLE CCS-325
C2323 BODY VARIANT SIGNAL IS IMPLAUSIBLE CCS-326
C2324 MODEL SERIES SIGNAL IS IMPLAUSIBLE CCS-327
C2325 BRAKE STATUS FROM ESP IS IMPLAUSIBLE CCS-328
C232C NO CAN SIGNAL RECEIVED FROM IGN LOCK CCS-329
C232D CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-330
C232E CAN SIGNAL FROM IGN LOCK IS MALF .. CCS-331
C2330 NO CAN SIG RECEIVED FROM MOTOR ELEC CCS-332
C2331 INVALID DATA RECEIVED FROM ECM/ PCM A CCS-333
C2332 NO CAN SIGNAL RECEIVED FROM ESP .. CCS-334
C2333 INVALID DATA RECEIVED FROM VDCM... CCS-335
C2334 T/M MODE SIGNAL IS IMPLAUSIBLE CCS-336
C2335 T/M MODE SIGNAL IS IMPLAUSIBLE CCS-337
C2336 T/M MODE SIGNAL IS IMPLAUSIBLE CCS-338
C3201 ENGINE SYSTEM BRC-909
C3209 ENGINE SYSTEM BRC-910
C3212 ENGINE SYSTEM BRC-911
C3220 ENGINE SYSTEM BRC-912
C3221 ENGINE SYSTEM BRC-913
C3235 COMBINATION METER SYSTEM BRC-914
C3250 STEERING COLUMN CONTROL MODULE SYSTEM BRC-915
C3254 STEERING COLUMN CONTROL MODULE SYSTEM BRC-916
C3256 STEERING COLUMN CONTROL MODULE SYSTEM BRC-917
C3260 CONTROL UNIT BRC-918
C3261 CONTROL UNIT BRC-919
C3263 ENGINE SYSTEM BRC-921
C3275 CONTROL UNIT BRC-922
C3285 ENGINE SYSTEM BRC-924
C3289 ELECTRONIC IGNITION SWITCH CONTROL UNIT SYSTEM BRC-925
C328A ELECTRIC PARKING BRAKE SYSTEM BRC-926
C3295 CONTROL UNIT BRC-927
C3296 CONTROL UNIT BRC-929
C3297 CONTROL UNIT BRC-931

C3298 CONTROL UNIT BRC-933
C3299 CONTROL UNIT BRC-935
C329B CONTROL UNIT BRC-937
C3334 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-939
C3340 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-940
C3341 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-941
C3342 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-942
C3343 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-943
C3344 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-944
C3345 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-945
C3346 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-946
C3347 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-947
C3348 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-948
C3349 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-949
C334A ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-950
C334C ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-951
C3385 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-952
C3386 ICC SENSOR/DISTANCE SENSOR SYSTEM BRC-953
C3500 SONAR CONTROL UNIT SYSTEMBRC-954
C3600 TRAILER VIBRATION DAMPING FUNCTION BRC-955
C3601 VEHICLE DYNAMICS CONTROL (VDC) FUNCTION BRC-957
C3604 YAW MOMENT INTERFACE FUNCTION ... BRC-959
C3605 HYDRAULICAL BRAKE ASSISTANT FUNCTION BRC-961
C3606 ANTI-LOCK BRAKING SYSTEM (ABS) FUNCTION BRC-963
CALIBRATING CAMERA IMAGE (AROUND VIEW MONITOR) AV-302
CALIBRATION OF ACCELERATION SENSOR..... BRC-86
CALIBRATION OF ELECTRIC PARKING BRAKE CONTROL MODULE PB-37
CALIBRATION OF ELECTRIC POWER STEERING TORQUE SENSOR STC-23
CAMERA AIMING ADJUSTMENT DAS-60
CAMERA IMAGE SIGNAL CIRCUIT AV-343, AV-396
CAMERA POWER SUPPLY CIRCUIT AV-394
CAMSHAFT EM-63
CAMSHAFT REFERENCE ADAPTATION .. EC-193
CAN GATEWAY LAN-154, LAN-218
CAN GATEWAY SYSTEM LAN-158
CAN PDEC (BODY) - A/C AUTO AMP. CIRCUIT ... LAN-121
CAN PDEC (BODY) - BCM (BODY CONTROL MODULE) CIRCUIT LAN-123
CAN PDEC (BODY) - CAN GATEWAY CIRCUIT ... LAN-125
CAN PDEC (BODY) - COMBINATION METER CIRCUIT LAN-127
CAN PDEC (BODY) - DRIVER SEAT CONTROL UNIT CIRCUIT LAN-129
CAN PDEC (BODY) - ELECTRONIC IGNITION SWITCH CONTROL UNIT CIRCUIT .. LAN-131
CAN PDEC (BODY) - INTELLIGENT KEY UNIT CIRCUIT LAN-133
CAN PDEC (BODY) - PASSENGER SEAT CONTROL UNIT CIRCUIT LAN-135
CAN PDEC (BODY) - RIGHT FRONT DOOR CONTROL UNIT CIRCUIT LAN-137
CAN PDEC (CHASSIS) - AIR BAG DIAGNOSIS SENSOR UNIT CIRCUIT LAN-97
CAN PDEC (CHASSIS) - CAN GATEWAY CIRCUIT LAN-99
CAN PDEC (CHASSIS) - COMBINATION METER CIRCUIT LAN-101
CAN PDEC (CHASSIS) - ECM CIRCUIT .. LAN-103
CAN PDEC (CHASSIS) - ELECTRIC PARKING BRAKE CONTROL MODULE CIRCUIT LAN-105
CAN PDEC (CHASSIS) - ELECTRONIC IGNITION SWITCH CONTROL UNIT CIRCUIT .. LAN-107
CAN PDEC (CHASSIS) - ELECTRONIC STABILITY PROGRAM CONTROL UNIT CIRCUIT LAN-109
CAN PDEC (CHASSIS) - EPS CONTROL UNIT CIRCUIT LAN-111
CAN PDEC (CHASSIS) - ICC SENSOR CIRCUIT . LAN-113
CAN PDEC (CHASSIS) - LOW TIRE PRESSURE WARNING CONTROL UNIT CIRCUIT LAN-115
CAN PDEC (CHASSIS) - SONAR CONTROL UNIT CIRCUIT LAN-117
CAN PDEC (CHASSIS) - STEERING COLUMN CONTROL MODULE CIRCUIT LAN-119
CAN PDEC (FRONT END) - ELECTRONIC IGNITION SWITCH CONTROL UNIT CIRCUIT LAN-85
CAN PDEC (FRONT END) - FRONT CAMERA UNIT CIRCUIT LAN-87
CAN PDEC (FRONT END) - FRONT COMBINATION LAMP LH CIRCUIT LAN-89
CAN PDEC (FRONT END) - FRONT COMBINATION LAMP RH CIRCUIT LAN-91
CAN PDEC (FRONT END) - SIDE RADAR LH CIRCUIT LAN-93

CAN PDEC (FRONT END) - SIDE RADAR RH CIRCUIT LAN-95
CAN PDEC (POWERTRAIN) - 4WD CONTROL UNIT CIRCUIT LAN-75
CAN PDEC (POWERTRAIN) - ECM CIRCUIT LAN-77
CAN PDEC (POWERTRAIN) - ELECTRIC SHIFT CONTROL UNIT CIRCUIT LAN-79
CAN PDEC (POWERTRAIN) - FUEL PUMP CONTROL MODULE CIRCUIT LAN-81
CAN PDEC (POWERTRAIN) - TCM CIRCUIT LAN-83
CAN SYSTEM (WITH 1.6L TURBO GASOLINE ENGINE) LAN-45
CAN SYSTEM (WITH 2.0L TURBO GASOLINE ENGINE) LAN-29
CENTER CONSOLE ASSEMBLY IP-21
CENTER SQUAWKER AV-249
CHARGE AIR COOLER EM-37
CHARGE AIR MANIFOLD EM-28
CHARGING SYSTEM CHG-15
CHARGING SYSTEM PRELIMINARY INSPECTION CHG-27
CHASSIS CAN COMMUNICATION LAN-69
CHASSIS MAINTENANCE MA-27
CHILD SEAT ANCHOR SE-87
CLUTCH HOUSING TM-260
COLLISION DIAGNOSIS SR-13
COMBINATION METER MWI-81, MWI-155
COMPRESSION PRESSURE EM-11
COMPRESSOR HA-25
CONDENSER DEF-46, HA-33
CONFIGURATION CCS-70, DAS-66, EC-188
CONFIGURATION (A/C AUTO AMP.) HAC-49
CONFIGURATION (AIR BAG DIAGNOSIS SENSOR UNIT) SRC-58
CONFIGURATION (AROUND VIEW MONITOR CONTROL UNIT) AV-299
CONFIGURATION (BCM) BCS-89
CONFIGURATION (CAN GATEWAY) LAN-164
CONFIGURATION (COMBINATION METER) MWI-99
CONFIGURATION (DISPLAY CONTROL UNIT) AV-148
CONFIGURATION (ELECTRIC PARKING BRAKE CONTROL MODULE) PB-32
CONFIGURATION (ELECTRONIC IGNITION SWITCH CONTROL UNIT) PCS-24
CONFIGURATION (ELECTRONIC STABILITY PROGRAM CONTROL UNIT) BRC-85
CONFIGURATION (FRONT DOOR CONTROL UNIT) DLK-102
CONFIGURATION (FRONT SEAT CONTROL UNIT) ADP-44
CONFIGURATION (INTELLIGENT KEY UNIT) DLK-101
CONFIGURATION (LIGHT & RAIN SENSOR) WW-33
CONFIGURATION (OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT) SRC-59
CONFIGURATION (OVERHEAD CONTROL PANEL CONTROL UNIT) INL-60
CONFIGURATION (SONAR CONTROL UNIT) SN-61
CONFIGURATION (TCM) TM-78
CONFIGURATION (TIRE PRESSURE MONITORING SYSTEM) WT-37
CONSULT/GST CHECKING SYSTEM GI-64
CONTROL VALVE, TCM, ELECTRIC OIL PUMP ... TM-253
COOLANT CIRCULATION PUMP HA-43
COOLER PIPE AND HOSE HA-27
COOLING FAN CO-16
CORROSION PROTECTION BRM-115
COWL TOP EXT-35
CRANKCASE VENTILATION SYSTEM EC-959
CRASH ZONE SENSOR SR-34
CURTAIN AIR BAG MODULE SR-31
CYLINDER HEAD EM-70
CYLINDER HEAD COVER EM-59

D

DATA LINK CONNECTOR - CAN GATEWAY CIRCUIT LAN-141
DATA LINK CONNECTOR - ELECTRONIC IGNITION SWITCH CONTROL UNIT CIRCUIT LAN-139
DEFOGGER DEF-25
DIAGNOSIS AND REPAIR WORK FLOW . AV-428, BRC-1007, CCS-53, CCS-378, CHG-21, DAS-58, DAS-216, MWI-97, PWC-23, RF-12, STR-10, TM-64
DIAGNOSIS SENSOR UNIT SR-41
DIAGNOSIS SYSTEM (A/C AUTO AMP.) . DEF-11, HAC-25
DIAGNOSIS SYSTEM (AIR BAG DIAGNOSIS SENSOR UNIT) SRC-16
DIAGNOSIS SYSTEM (AROUND VIEW MONITOR CONTROL UNIT) AV-280
DIAGNOSIS SYSTEM (AWD CONTROL UNIT) DLN-16
DIAGNOSIS SYSTEM (BCM) BCS-24, BRC-52, CHG-8, MIR-21, MWI-74
DIAGNOSIS SYSTEM (CAN GATEWAY) . LAN-153
DIAGNOSIS SYSTEM (COMBINATION METER) ... MWI-68
DIAGNOSIS SYSTEM (DISPLAY CONTROL UNIT) AV-60, AV-363
DIAGNOSIS SYSTEM (ECM) EC-97
DIAGNOSIS SYSTEM (ELECTRIC PARKING BRAKE CONTROL MODULE) PB-18
DIAGNOSIS SYSTEM (ELECTRIC SHIFT) . TM-41

DIAGNOSIS SYSTEM (ELECTRONIC IGNITION SWITCH CONTROL UNIT)....PCS-8
DIAGNOSIS SYSTEM (ELECTRONIC STABILITY PROGRAM CONTROL UNIT)BRC-49, CCS-354
DIAGNOSIS SYSTEM (EPS CONTROL UNIT)..... STC-12
DIAGNOSIS SYSTEM (FPCM)..... EC-117
DIAGNOSIS SYSTEM (FRONT CAMERA UNIT)... DAS-29
DIAGNOSIS SYSTEM (FRONT SEAT CONTROL UNIT) ADP-16, SE-17
DIAGNOSIS SYSTEM (GARAGE DOOR OPENER CONTROL UNIT)..... DLK-39
DIAGNOSIS SYSTEM (HEADLAMP CONTROL UNIT LH)..... EXL-64, EXL-354
DIAGNOSIS SYSTEM (HEADLAMP CONTROL UNIT RH) EXL-67, EXL-357
DIAGNOSIS SYSTEM (ICC SENSOR)... BRC-993, CCS-38
DIAGNOSIS SYSTEM (INTELLIGENT KEY)DLK-29
DIAGNOSIS SYSTEM (LED HEADLAMP CONTROL MODULE LH) EXL-70
DIAGNOSIS SYSTEM (LED HEADLAMP CONTROL MODULE RH)..... EXL-72
DIAGNOSIS SYSTEM (LEFT FRONT DOOR CONTROL UNIT).... DAS-34, DEF-16, DLK-31, MIR-13
DIAGNOSIS SYSTEM (LIGHT & RAIN SENSOR) . WW-21
DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)..... WT-20
DIAGNOSIS SYSTEM (OCCUPANT CLASSIFICATION SYSTEM)..... SRC-18
DIAGNOSIS SYSTEM (OVERHEAD CONTROL PANEL CONTROL UNIT) INL-22
DIAGNOSIS SYSTEM (RIGHT FRONT DOOR CONTROL UNIT).... DAS-38, DEF-20, DLK-35, MIR-17
DIAGNOSIS SYSTEM (SIDE RADAR LH) .DAS-31
DIAGNOSIS SYSTEM (SIDE RADAR RH).DAS-32
DIAGNOSIS SYSTEM (SONAR CONTROL UNIT) DAS-197, SN-30
DIAGNOSIS SYSTEM (STEERING COLUMN CONTROL MODULE)AV-74, BCS-30, CCS-40, CCS-357, DAS-33, MWI-80
DIAGNOSIS SYSTEM (TCM) TM-36
DIAGNOSIS SYSTEM (TCU)..... AV-415
DIAGNOSIS SYSTEM (UPPER CONTROL PANEL CONTROL UNIT).....BCS-31
DIAGNOSTIC CAN COMMUNICATION LAN-59
DIFFERENTIAL SIDE OIL SEAL TM-219
DISK EJECT SIGNAL CIRCUIT..... AV-207
DISPLAY CONTROL UNIT AV-75, AV-239, AV-377
DOOR & LOCK SYSTEM DLK-73
DOOR LOCK AND UNLOCK SWITCH..... DLK-279
DOOR MIRROR.....MIR-28, MIR-68
DOOR MIRROR REMOTE CONTROL SWITCH.... MIR-79
DOOR MOTOR HAC-130
DOOR OUTSIDE MOLDING.....EXT-53
DOOR SASH COVER EXT-51
DOOR SASH MOLDING EXT-50
DRIVE BELT..... EM-13
DRIVE BELT AUTO TENSIONER AND IDLER PULLEY EM-26
DRIVE PINION OIL SEAL DLN-104
DRIVE PLATE EM-100
DRIVER AIR BAG MODULE.....SR-20
DRIVER ASSISTANCE SYSTEMS DAS-52
DRIVER SEAT CONTROL UNIT.... ADP-20, SE-22
DRIVER SIDE POWER WINDOW DOES NOT OPERATE PWC-78
DUAL CLUTCH TM-250
DUCT AND GRILLE VTL-5

E

ELECTRIC PARKING BRAKE CONTROL MODULE PB-21, PB-130
ELECTRIC PARKING BRAKE SWITCH PB-134
ELECTRIC PARKING BRAKE SYSTEM..... PB-26
ELECTRIC SHIFT CONTROL UNIT TM-49
ELECTRIC SHIFT SELECTOR.....TM-227
ELECTRIC SHIFT SYSTEM TM-60
ELECTRICAL CONTACT ACTUATOR/BRAKE CLEARANCE SETTING..... PB-36
ELECTRONIC IGNITION SWITCH CONTROL UNIT PCS-10, PCS-47
ELECTRONIC STABILITY PROGRAM CONTROL UNIT.....BRC-58, BRC-975, CCS-358
ENABLING OF ENGINE START AFTER CRASH EVENT EC-199
ENGINE ASSEMBLY EM-95
ENGINE CONTROL SYSTEM EC-163
ENGINE COOLANT CO-7
ENGINE COVER..... EM-20
ENGINE MAINTENANCE MA-16
ENGINE OIL..... LU-7
ENGINE STAND SETTING EM-99
ENGINE UNABLE TO BE STARTED AFTER COLLISION EC-960
EPS CONTROL UNIT STC-15, STC-57
ERECTRIC PARKING BRAKE ACTUATOR MOTOR PB-131
EVAP CANISTER.....FL-13
EVAP PURGE CONTROL VALVE.....FL-15
EVAPORATIVE EMISSION SYSTEM EC-961
EXHAUST MANIFOLD AND TURBOCHARGER ASSEMBLY EM-41
EXHAUST SYSTEM..... EX-4, EX-5
EXTERIOR LIGHTING SYSTEMEXL-100, EXL-372
EXTERNAL DATA INPUT BOX (SD CARD) AV-245
EXTERNAL DATA INPUT BOX (USB) AV-244

F

FENDER PROTECTOR EXT-41
FILLET MOLDING EXT-37
FINAL DRIVE TM-275
FLOOR SIDE FAIRING EXT-43
FLOOR TRIM INT-29
FOOT LAMP INL-123
FORWARD EMERGENCY BRAKING BRC-1003
FRONT BUMPER EXT-17
FRONT CAMERA AV-348
FRONT CAMERA UNIT DAS-42, DAS-176
FRONT COIL SPRING AND STRUT FSU-10
FRONT COMBINATION LAMP EXL-289, EXL-513
FRONT DISC BRAKE BR-6, BR-14, BR-34
FRONT DOOR DLK-242
FRONT DOOR CONTROL UNIT ADP-32, DAS-51, DLK-286, SEC-18
FRONT DOOR FINISHER INT-13
FRONT DOOR GLASS GW-41
FRONT DOOR LOCK DLK-264
FRONT DOOR MODULE ASSEMBLY GW-45
FRONT DOOR SPEAKER AV-247
FRONT DRIVE SHAFT FAX-9, FAX-15
FRONT END CAN COMMUNICATION LAN-62
FRONT FENDER DLK-239
FRONT FOG LAMP EXL-292, EXL-516
FRONT FOG LAMP AIMING ADJUSTMENT EXL-287, EXL-511
FRONT GRILLE EXT-32
FRONT INSIDE KEY ANTENNA DLK-281
FRONT LOWER LINK RSU-17
FRONT OR REAR SENSOR LOCALIZATION WAS UNSUCCESSFUL WT-35
FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE PWC-79
FRONT POWER WINDOW SWITCH (PASSENGER SIDE) PWC-71, PWC-90
FRONT SEAT SE-63
FRONT SEAT ADJUSTMENT SWITCH GROUP ADP-114
FRONT SEAT BELT SB-7
FRONT STABILIZER FSU-17
FRONT SUSPENSION ASSEMBLY FSU-7
FRONT SUSPENSION MEMBER FSU-19
FRONT TWEETER AV-248
FRONT WASHER WW-73
FRONT WHEEL HUB AND KNUCKLE FAX-8, FAX-10
FRONT WIPER WW-64
FUEL FILLER LID OPENER DLK-275
FUEL INJECTOR EM-49
FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY FL-17
FUEL PRESSURE EC-200
FUEL PUMP CONTROL MODULE (FPCM) EC-156, EC-964
FUEL SYSTEM FL-5
FUEL TANK FL-7
FUSE INSPECTION PG-106
FUSE, FUSIBLE LINK AND RELAY BOX PG-72
FUSIBLE LINK INSPECTION PG-107

G

GARAGE DOOR OPENER SYSTEM DLK-86
GENERAL MAINTENANCE MA-4
GLASS ROOF GW-27
GLOVE BOX LAMP INL-121
GPS ANTENNA AV-257
GROUND DISTRIBUTION PG-53

H

HANDLING PRECAUTION AV-58, AV-279, AV-362, AV-414, BRC-992, CCS-36, CCS-353, DAS-26, DAS-196
HANDS-FREE PHONE SYSTEM AV-55
HARNESS LAYOUT PG-74
HAZARD SWITCH EXL-297, EXL-521
HEADLAMP AIMING ADJUSTMENT EXL-285, EXL-509
HEADLAMP CONTROL UNIT LH EXL-75, EXL-361
HEADLAMP CONTROL UNIT RH EXL-88, EXL-367
HEADLINING INT-31
HEATED SEAT SWITCH SE-91
HEATED SEAT SYSTEM SE-30
HEATER & COOLING UNIT ASSEMBLY HA-36
HEIGHT SENSOR EXL-300
HIGH PRESSURE FUEL PUMP AND FUEL HOSE EM-44
HIGH PRESSURE FUEL PUMP TOTAL STARTS COUNTER RESET EC-198
HIGH-MOUNTED STOP LAMP EXL-308, EXL-529
HOLLOW SHAFT TM-268
HOOD DLK-230
HOOD LOCK DLK-261
HORN HRN-9, HRN-15
HOW TO ERASE PERMANENT DTC EC-205, TM-80
HOW TO FOLLOW TROUBLE DIAGNOSES .. GI-6
HOW TO READ WIRING DIAGRAMS GI-9
HOW TO SET SRT CODE EC-201
HOW TO USE THIS MANUAL GI-3
HOW TO USE THIS SECTION LAN-5

I

ICC SENSOR BRC-995, BRC-1009, CCS-41, CCS-340
ICC SENSOR ALIGNMENT CCS-58
ICC SENSOR INITIAL VERTICAL ALIGNMENT CCS-55
IDENTIFICATION INFORMATION GI-51

IGNITION COIL EM-58
ILLUMINATION INL-44
IN-VEHICLE SENSOR HAC-123
INFINITI INTOUCH AV-24, AV-224
INFINITI INTOUCH (BASE AUDIO WITHOUT NAVIGATION) AV-95
INFINITI INTOUCH (BOSE AUDIO WITH NAVIGATION) AV-125
INFINITI INTOUCH (BOSE AUDIO WITHOUT NAVIGATION) AV-108
INJECTOR INJECTION QUANTITY ADJUSTMENT EC-189
INPUT SHAFT TM-267
INSIDE MIRROR MIR-35, MIR-66
INSIDE MIRROR LAMP INL-132
INSTRUCTIONS FOR RELEASING PARKING BRAKE WHERE PARKING BRAKE SWITCH CANNOT BE USED PB-33
INSTRUMENT PANEL ASSEMBLY IP-12
INTAKE SENSOR HAC-126
INTELLIGENT CRUISE CONTROL CCS-50
INTELLIGENT KEY BATTERY DLK-287
INTELLIGENT KEY UNIT DLK-41, DLK-285
INTERIOR ROOM LAMP CONTROL SYSTEM INL-26
INTERIOR TEMPERATURE SENSOR WITH INTEGRATED FAN HAC-124

J

JUMP-STARTING CONNECTION POINT WITH FUSIBLE LINK PG-122

K

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE PWC-82
KEYLESS POWER WINDOW UP DOES NOT OPERATE PWC-84
KNEE AIR BAG MODULE SR-26

L

L TERMINAL CIRCUIT (OPEN) CHG-32
L TERMINAL CIRCUIT (SHORT) CHG-33
LANCHESTER BALANCER EM-79
LAP PRE-TENSIONER SR-40
LED HEADLAMP CONTROL MODULE LH EXL-98
LED HEADLAMP CONTROL MODULE RH EXL-99
LEFT FRONT DOOR CONTROL UNIT DLK-50, DLK-88
LICENSE PLATE LAMP EXL-310, EXL-531
LIFTING POINT GI-46
LIGHT & RAIN SENSOR EXL-299, EXL-523, WW-23, WW-81
LIGHTING & TURN SIGNAL SWITCH EXL-296, EXL-520
LOCATION OF PLASTIC PARTS BRM-191
LOW TIRE PRESSURE WARNING CONTROL UNIT WT-24, WT-72
LUBRICANT HA-18
LUGGAGE ROOM LAMP INL-128
LUGGAGE TRIM INT-36
LUMBAR SUPPORT CONTROL UNIT SE-24, SE-89
LUMBAR SUPPORT SWITCH SE-88
LUMBAR SUPPORT SYSTEM SE-26

M

MAINTENANCE RESET PROCEDURE MWI-102
MEMORY STORING ADP-47
METER MWI-89
MICROPHONE AV-253, AV-460
MICROPHONE SIGNAL CIRCUIT AV-210
MULTIFUNCTION MEDIA CAN COMMUNICATION LAN-60
MULTIFUNCTION SWITCH AV-243

N

NAVI CONTROL UNIT AV-88, AV-241
NAVIGATION SYSTEM AV-49
NOISE HA-24
NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING BR-9, DLN-70, DLN-84, DLN-101, FSU-6, RAX-14, RSU-5, ST-7, WT-66
NOISE, VIBRATION, AND HARSHNESS(NVH) TROUBLESHOOTING RAX-5
NORMAL OPERATING CONDITION AV-229, AV-346, AV-400, AV-458
NORMALIZATION OF ACTUATOR MOTORS HAC-52

O

OCCUPANT CLASSIFICATION SYSTEM CONTROL UNIT SRC-25
OIL FILTER LU-10
OIL FILTER HOUSING LU-11
OIL PAN EM-76
OIL PAN, ELECTRIC OIL PUMP & CONTROL VALVE & TCM TM-216
OIL PUMP LU-14
OIL SEAL EM-84
ON BOARD DIAGNOSTIC (OBD) SYSTEM EC-94, TM-35
OPERATION BRC-48, BRC-990, CCS-32, CCS-351, DAS-24, DAS-195, EC-93, HAC-23, MWI-67, WT-19
OPTION HARNESS PG-67
OUTSIDE KEY ANTENNA DLK-283
OUTSIDE MIRROR LAMP INL-133
OVERHEAD CONTROL PANEL CONTROL UNIT INL-24, INL-114

P

P0001 QUANTITY CONTROL VALVE EC-292
P0003 QUANTITY CONTROL VALVE EC-294
P0004 QUANTITY CONTROL VALVE EC-296
P0008 CRANKSHAFT POSITION CONTROL EC-298
P000E QUANTITY CONTROL VALVE EC-301
P0010 INTAKE CAMSHAFT ACTUATOR ...EC-303
P0011 INTAKE CAMSHAFT CONTROL EC-305
P0012 INTAKE CAMSHAFT CONTROL EC-306
P0013 EXHAUST CAMSHAFT ACTUATOREC-307
P0014 EXHAUST CAMSHAFT CONTROL .EC-309
P0015 EXHAUST CAMSHAFT CONTROL .EC-310
P0016 CKP - CMP CORRELATION EC-311
P0017 CKP-CMP CORRELATION EC-312
P001A INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-313
P001B INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-316
P001C INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-318
P002A INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-320
P002B INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-322
P002C INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-324
P0030, P0031, P0032 A/F SENSOR HEATER EC-326
P0033 DIVERT AIR SWITCHOVER VALVEEC-328
P0034 DIVERT AIR SWITCHOVER VALVEEC-330
P0035 DIVERT AIR SWITCHOVER VALVEEC-332
P0036, P0037, P0038 O2 SENSOR HEATER EC-334
P0039 DIVERT AIR SWITCH OVER VALVEEC-336
P003C INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-338
P003D INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-340
P0040 A/F SENSOR EC-342
P0041 O2 SENSOR EC-344
P005A INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-346
P005B INTAKE CAMSHAFT VALVE LIFT SWITCHOVER ACTUATOR.....EC-348
P0068 MANIFOLD PRESSURE - THROTTLE POSITION CORRELATION.....EC-350
P0070 AMBIENT SENSOR EC-353, HAC-110
P0071 AMBIENT SENSOR EC-354
P0072 AMBIENT SENSOR EC-355
P0073 AMBIENT SENSOR EC-356
P007A CHARGE AIR TEMPERATURE SENSOR .. EC-357
P007B CHARGE AIR TEMPERATURE SENSOR UPSTREAM OF THROTTLE VALVE EC-359
P007C CHARGE AIR TEMPERATURE SENSOR UPSTREAM OF THROTTLE VALVE.... EC-362
P007E CHARGE AIR TEMPERATURE SENSOR UPSTREAM OF THROTTLE VALVE.... EC-364
P0087 FUEL SYSTEM EC-366
P0088 FUEL PRESSURE EC-373
P0089 QUANTITY CONTROL VALVE..... EC-375
P008A LOW FUEL PRESSURE CONTROL SYSTEM..... EC-380
P008B LOW FUEL PRESSURE CONTROL SYSTEM..... EC-383
P0096 CHARGE AIR TEMPERATURE SENSOR DOWNSTREAM OF THROTTLE VALVEEC-384
P0099 CHARGE AIR TEMPERATURE SENSOR DOWNSTREAM OF THROTTLE VALVEEC-386
P0106 PRESSURE SENSOR DOWNSTREAM OF THROTTLE VALVE..... EC-388
P0107 PRESSURE SENSOR DOWNSTREAM OF THROTTLE VALVE..... EC-389
P0108 PRESSURE SENSOR DOWNSTREAM OF THROTTLE VALVE..... EC-392
P0115 ENGINE COOLANT TEMPERATURE SENSOR EC-395
P0116 ENGINE COOLANT TEMPERATURE SENSOR EC-399
P0117, P0118 ENGINE COOLANT TEMPERATURE SENSOR EC-403
P0119 ENGINE COOLANT TEMPERATURE SENSOR EC-407
P0122 THROTTLE POSITION SENSOR ... EC-409
P0123 THROTTLE POSITION SENSOR ... EC-412
P0128 THERMOSTAT FUNCTION..... EC-415
P0130 A/F SENSOR..... EC-419
P0133 A/F SENSOR..... EC-421
P0135 A/F SENSOR HEATER EC-423
P0136 O2 SENSOR EC-425
P0137 O2 SENSOR EC-427
P0138 O2 SENSOR EC-429
P013A O2 SENSOR..... EC-431
P013B O2 SENSOR..... EC-433
P013E O2 SENSOR..... EC-435
P013F O2 SENSOR..... EC-437
P0140 O2 SENSOR EC-439
P0141 HO2S2 HEATER EC-441
P0170 AIR-FUEL RATIO EC-443
P0171 AIR-FUEL RATIO EC-444
P0172 AIR-FUEL RATIO EC-445
P0181 FUEL TEMPERATURE SENSOR ... EC-446
P0182 FUEL TEMPERATURE SENSOR ... EC-449
P0183 FUEL TEMPERATURE SENSOR ... EC-452
P0184 FUEL TEMPERATURE SENSOR ... EC-455
P0190 FUEL RAIL PRESSURE SENSOR . EC-458
P0191 FUEL RAIL PRESSURE SENSOR . EC-461
P0192 FUEL RAIL PRESSURE SENSOR . EC-464
P0193 FUEL RAIL PRESSURE SENSOR . EC-467

P0196 ENGINE OIL TEMPERATURE SENSOR EC-470
P0197 ENGINE OIL TEMPERATURE SENSOR EC-471
P0198 ENGINE OIL TEMPERATURE SENSOR EC-472
P0201 FUEL INJECTOR (CYLINDER 1) EC-473
P0202 FUEL INJECTOR (CYLINDER 2) EC-476
P0203 FUEL INJECTOR (CYLINDER 3) EC-479
P0204 FUEL INJECTOR (CYLINDER 4) EC-482
P0217 ENGINE OVER TEMPERATURE EC-485
P0218 T/M FLUID TEMPERATURE SENSOR A TM-87
P0219 ENGINE SPEED EC-486
P0222, P0223 THROTTLE POSITION SENSOR ... EC-487
P0234 TURBOCHARGER BOOST PRESSURE EC-490
P0236 PRESSURE SENSOR UPSTREAM OF THROTTLE VALVE EC-493
P0237, P0238 PRESSURE SENSOR UPSTREAM OF THROTTLE VALVE EC-494
P0243 BOOST PRESSURE CONTROL VACUUM TRANSDUCER EC-496
P0245 BOOST PRESSURE CONTROL VACUUM TRANSDUCER EC-498
P0246 BOOST PRESSURE CONTROL VACUUM TRANSDUCER EC-500
P0262 FUEL INJECTOR (CYLINDER 1) EC-502
P0265 FUEL INJECTOR (CYLINDER 2) EC-504
P0268 FUEL INJECTOR (CYLINDER 3) EC-506
P026A TC SYSTEM EC-508
P0271 FUEL INJECTOR (CYLINDER 4) EC-509
P0299 TC SYSTEM EC-511
P0300, P0301, P0302, P0303, P0304 MISFIRE EC-514
P0324 KNOCK CONTROL EC-515
P0327 KNOCK SENSOR 1 ..... EC-516
P0328 KNOCK SENSOR 1 ..... EC-518
P032C KNOCK SENSOR 2 ..... EC-520
P032D KNOCK SENSOR 2 ..... EC-522
P0335 CRANKSHAFT POSITION SENSOR EC-524
P0339 CRANKSHAFT POSITION SENSOR EC-527
P0341 INTAKE CAMSHAFT POSITION SENSOR. EC-530
P0342 INTAKE CAMSHAFT POSITION SENSOR. EC-531
P0343 INTAKE CAMSHAFT POSITION SENSOR. EC-533
P0351 IGNITION COIL (CYLINDER 1) EC-535
P0352 IGNITION COIL (CYLINDER 2) EC-538
P0353 IGNITION COIL (CYLINDER 3) EC-541
P0354 IGNITION COIL (CYLINDER 4) EC-544
P0363 MISFIRE EC-547
P0366 EXHAUST CAMSHAFT POSITION SENSOR EC-548
P0367 EXHAUST CAMSHAFT POSITION SENSOR EC-549
P0368 EXHAUST CAMSHAFT POSITION SENSOR EC-551
P0420 EFFICIENCY OF THE CATALYTIC CONVERTER EC-553
P0442 EVAP CONTROL SYSTEM EC-556
P0444 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE EC-557
P0446 EVAP CANISTER VENT CONTROL VALVE EC-560
P0447 EVAP CANISTER VENT CONTROL VALVE EC-562
P0448 EVAP CANISTER VENT CONTROL VALVE EC-564
P0451 FUEL PRESSURE SENSOR EC-566
P0452 FUEL PRESSURE SENSOR EC-567
P0453 FUEL PRESSURE SENSOR EC-568
P0455 EVAP CONTROL SYSTEM EC-569
P0456 EVAP CONTROL SYSTEM EC-570
P0457 EVAP SYSTEM LEAK EC-571
P0458 EVAP PURGE CONTROL VALVE ... EC-572
P0459 EVAP PURGE CONTROL VALVE ... EC-575
P0460 FUEL LEVEL SENSOR .. EC-578, MWI-129
P0461 FUEL LEVEL SENSOR EC-579
P0461 FUEL LEVEL SENSOR LH MWI-131
P0463 FUEL LEVEL SENSOR EC-580
P0480 COOLING FAN EC-581
P0483 COOLING FAN EC-584
P0484 COOLING FAN EC-587
P0485 COOLING FAN EC-590
P0496 EVAP PURGE CONTROL VALVE ... EC-593
P0497 EVAP PURGE CONTROL VALVE ... EC-596
P0498 EVAP CANISTER VENT CONTROL VALVE EC-599
P0499 EVAP CANISTER VENT CONTROL VALVE EC-601
P04DB CRANKCASE VENTILATION SYSTEM EC-603
P04F0 EVAP SYS HIGH PRESSURE PURGE LINE EC-604
P0500 VEHICLE SPEED SIGNAL EC-606
P0505 IDLE SPEED CONTROL EC-607
P0506 IDLE SPEED CONTROL EC-608
P0507 IDLE SPEED CONTROL EC-610
P050A COLD START IDLE SPEED CONTROL EC-612
P050B IGNITION TIMING EC-613
P050D COLD START ROUGH IDLE EC-614
P0511 ..... EC-615
P0512 STARTER REQUEST CIRCUIT EC-616
P0513 IMMOBILIZER EC-617, TM-88
P052A INTAKE CAMSHAFT POSITION CONTROL EC-618
P052E VENT LINE HEATER ELEMENT EC-619

P0536 A/C EVAPORATOR TEMPERATURE SENSOR EC-620
P0537 A/C EVAPORATOR TEMPERATURE SENSOR EC-621
P0538 A/C EVAPORATOR TEMPERATURE SENSOR EC-622
P053A VENT LINE HEATER ELEMENT EC-623
P053B VENT LINE HEATER ELEMENT EC-626
P053C VENT LINE HEATER ELEMENT EC-629
P053F COLD START FUEL PRESSURE PERFORMANCE EC-632
P054A EXHAUST CAMSHAFT POSITION CONTROL EC-637
P0562 CONTROL UNIT POWER SUPPLY DLN-33
P0562 POWER SUPPLY EC-638
P0562 SYSTEM VOLTAGE TM-89
P0563 CONTROL UNIT POWER SUPPLY DLN-34
P0563 POWER SUPPLY EC-639
P0563 SYSTEM VOLTAGE TM-90
P0571 BRAKE SWITCH EC-640
P0575 CRUISE CONTROL EC-641
P0579 CRUISE CONTROL LEVER BCS-210
P0597 COOLANT THERMOSTAT HEATER ELEMENT EC-642
P0598 COOLANT THERMOSTAT HEATER ELEMENT EC-645
P0599 COOLANT THERMOSTAT HEATER ELEMENT EC-648
P0602 CONTROL MODULE PROGRAMMING ERROR TM-91
P0604 ECM EC-651
P0606 ECM EC-652
P0607 AWD CONTROL UNIT DLN-35
P0607 CAN GATEWAY LAN-194
P0607 CONTROL MODULE EC-653, TM-92
P060A CONTROL MODULE TM-93
P060B ECM EC-654
P060C ECM EC-655
P060D ECM EC-656
P0610 CONTROL MODULE VEHICLE OPTIONS ERROR TM-94
P0611 ECM EC-657
P0615 STARTER RELAY EC-660
P0616 STARTER RELAY EC-661
P0617 STARTER RELAY EC-662
P061A ECM EC-663
P061B CONTROL MODULE TM-95
P061B ECM EC-664
P061C ECM EC-665
P061D ECM EC-666
P0627 FUEL PUMP CONTROL EC-667
P0628 FUEL PUMP CONTROL EC-670
P0629 FUEL PUMP CONTROL EC-673
P062A FUEL PUMP CONTROL EC-676
P062B ECM EC-679
P062C ECM EC-680
P062F ECM EC-681
P0634 CONT MODULE INTERNAL TEMP A TM-96
P0634 ECM TEMPERATURE EC-682
P0635 CONTROL UNIT STC-37
P0638 THROTTLE VALVE ACTUATOR CONTROL EC-683
P063E THROTTLE VALVE ACTUATOR CONTROL EC-685
P0641 SENSOR POWER SUPPLY EC-687
P0642 SENSOR POWER SUPPLY EC-688
P0643 SENSOR POWER SUPPLY EC-689
P064D ECM EC-690
P0651 SENSOR POWER SUPPLY 2 ..... EC-691
P065B ALTERNATOR EC-692
P065B ALTERNATOR MALFUNCTION CHG-28
P0666 CONT MODU INTERNAL TEMP SEN A TM-97
P0667 CONT MODULE INTERNAL TEMP SEN A TM-98
P0667 CONTROL MODULE INTERNAL TEMPERATURE SENSOR EC-693
P0691 COOLING FAN EC-694
P0692 COOLING FAN EC-697
P0697 SENSOR POWER SUPPLY 3 ..... EC-700
P06A6 SENSOR REFERENCE VOLTAGE A TM-99
P06A7 SENSOR REFERENCE VOLTAGE B TM-100
P06A8 SENSOR REFERENCE VOLTAGE C TM-101
P06A9 SENSOR REFERENCE VOLTAGE D TM-102
P06AB CONTROL MODULE INTERNAL TEMP SENSOR B TM-103
P06AF ECM EC-701
P06D5 SENSOR REFERENCE VOLTAGE E TM-104
P06DA OIL PUMP VALVE EC-702
P06DB OIL PUMP VALVE EC-704
P06DC OIL PUMP VALVE EC-706
P0702 TRANSMISSION CONTROL SYSTEM EC-708, TM-105
P0710 T/M FLUID TEMPERATURE SENSOR A TM-106
P0711 T/M FLUID TEMPERATURE SENSOR A TM-107
P0714 T/M FLUID TEMPERATURE SENSOR A TM-108
P0715 ..... EC-709
P0715 INPUT SPEED SENSOR A TM-109
P0716 ..... EC-710
P0716 INPUT SPEED SENSOR A TM-111
P0717 ..... EC-711
P0718 ..... EC-712
P0730 TRANSMISSION GEAR RATIO EC-713
P0740 ..... EC-714
P0743 ..... EC-715
P0745 FUEL PRESSURE REGULATOR 1 TM-112
P0746 PRESSURE CONTROL SOLENOID A TM-113
P0748 ..... EC-716

P0753 ..... EC-717
P0758 ..... EC-718
P0760 SHIFT SOLENOID C TM-114
P0763 ..... EC-719
P0763 SHIFT SOLENOID C TM-115
P0775 PRESSURE CONTROL SOLENOID B TM-116
P0776 PRESSURE CONTROL SOLENOID B TM-117
P0778 ..... EC-720
P0791 INTERMEDIATE SHAFT SPEED SENSOR A TM-118
P0792 INTERMEDIATE SHAFT SPEED SENSOR A TM-119
P0795 PRESSURE CONTROL SOLENOID C TM-120
P0798 ..... EC-721
P079A TRANSMISSION FRICTION ELEMENT A.. TM-121
P079B TRANSMISSION FRICTION ELEMENT B.. TM-122
P07A3 TRANSMISSION FRICTION ELEMENT A.. TM-123
P07A5 TRANSMISSION FRICTION ELEMENT B.. TM-125
P07A7 TRANSMISSION FRICTION ELEMENT C . TM-126
P07B5 T/M PARK POSITION SENSOR/SWITCH A TM-127
P07E4 UNABLE TO ENGAGE PARK TM-129
P07E6 UNABLE TO ENGAGE PARK TM-130
P081C PARK INPUT CIRCUIT TM-131
P0840 T/M FLUID PRESSURE SENSOR/SWITCH A TM-132
P0841 T/M FLUID PRESSURE SENSOR/SWITCH A TM-133
P0845 T/M FLUID PRESSURE SENSOR/SWITCH B TM-134
P0846 T/M FLUID PRESSURE SENSOR/SWITCH B TM-135
P0850 PARK/NEUTRAL SWITCH TM-136
P0897 OIL DLN-37
P0921 GEAR SHIFT FORWARD ACTUATOR TM-138
P0925 GEAR SHIFT REVERSE ACTUATOR..... TM-139
P0960 AWD SOLENOID DLN-38
P0961 AWD SOLENOID DLN-40
P0962 AWD SOLENOID DLN-45
P0963 AWD SOLENOID DLN-47
P0A0F THE ENGINE DOES NOT START .. EC-722
P0A1E EC-723
P0A7C FPCM TEMPERATURE EC-724
P0B01 BRAKE CALIPER ASSEMBLY POSITION . PB-77
P0B02 POWER SUPPLY CIRCUIT PB-78
P0B09 ELECTRIC/AUXILIARY T/M FLUID PUMP A TM-140
P0B0D ELCTRC/AUX T/M FLUID PMP MTR CNTRL MDL TM-141
P0C2A ELECTRIC/AUXILIARY T/M FLUID PUMP A TM-142
P1188 PRESSURE SENSOR DOWNSTREAM OF AIR FILTER EC-727
P1189 PRESSURE SENSOR DOWNSTREAM OF AIR FILTER EC-729
P1190 PRESSURE SENSOR DOWNSTREAM OF AIR FILTER EC-731
P1240 CAN COMM CIRCUIT ... EXL-253, EXL-479
P1240 FPCM EC-733
P126F STOP/START SYSTEM BCS-167
P126F STOP/START: HOT START SIGNAL EC-734
P13AC POWER ELECTRONIC CONTROL UNIT .. EC-735
P13AD POWER ELECTRONIC CONTROL UNIT .. EC-736
P13AE POWER ELECTRONIC CONTROL UNIT .. EC-737
P13AF ECM EC-738
P13B0 ECM EC-739
P13B1 ECM EC-740
P13B2 IGNITION COIL POWER SUPPLY .. EC-741
P13B3 IGNITION COIL POWER SUPPLY .. EC-742
P13C5, P13C6 ENGINE KNOCKING EC-743
P13EA IGNITION TIMING EC-744
P1522 EVAP PURGE CONTROL VALVE ... EC-745
P1523 EVAP PURGE CONTROL VALVE ... EC-748
P1524 EVAP PURGE CONTROL VALVE ... EC-751
P1525 EVAP CONTROL SYSTEM CHECK VALVE EC-754
P1611 FPCM POWER SUPPLY EC-757
P1614 AWD CONTROL UNIT DLN-49
P1614 ECM EC-759
P162A FPCM EC-758
P1644 CHECK CODINGS IN ELECTRONIC IGN LOCK DAS-111
P1644 CONFIGURATION INCORRECT EC-760
P1644 CONTROL UNIT STC-42, WT-49
P1670 CALIBRATION ERROR EC-761
P167B CRASH SIGNAL EC-762
P172C ELECTRONIC IGNITION SWITCH CONTROL UNIT PCS-33
P1800 CONTROL MODULE PB-79
P1801 CONTROL MODULE PB-81
P1802 CONTROL MODULE PB-88
P1805 HARDWARE MONITOR DETECTED MALF DAS-113
P1CCF HIGH PRESSURE FUEL SYSTEM EC-763
P1CD8 EXHAUST LEAKAGE EC-768
P1CDE STOP/START SYSTEM EC-769
P1CDF STOP/START SYSTEM EC-770
P1CE0 STOP/START SYSTEM EC-771

P1CE1 STOP/START SYSTEM EC-772
P1CE2 STOP/START SYSTEM EC-773
P1CE3 FUEL INJECTOR INJECTION EC-774
P1CE4 FUEL INJECTOR INJECTION EC-775
P1CE5 FUEL INJECTOR INJECTION EC-776
P1CE6 FUEL INJECTOR INJECTION EC-777
P1CE7 INTAKE AIR LEAK EC-778
P1CEF FUEL INJECTOR INJECTION EC-779
P1CF0 FUEL INJECTOR INJECTION EC-780
P1CF1 FUEL INJECTOR INJECTION EC-781
P1CF2 FUEL INJECTOR INJECTION EC-782
P1CF3 FUEL INJECTOR INJECTION EC-783
P1CF4 FUEL INJECTOR INJECTION EC-784
P1D01 CRANKCASE VENTILATION SYSTEM EC-785
P1D02 CRANKCASE VENTILATION SYSTEM EC-786
P1D03 CRANKCASE VENTILATION SYSTEM EC-787
P1D04 STOP/START SYSTEM EC-788
P1D05 STOP/START SYSTEM EC-789
P1D06 STOP/START SYSTEM EC-790
P1D07 STOP/START SYSTEM EC-791
P1D68 CRANKCASE VENTILATION SYSTEM EC-792
P2065 FUEL LEVEL SENSOR ... EC-793, MWI-110
P2066 FUEL LEVEL SENSOR EC-794
P2066 FUEL LEVEL SENSOR RH MWI-132
P2067 FUEL LEVEL SENSOR EC-795
P2068 FUEL LEVEL SENSOR EC-796
P2072 MAP/MAF-THROTTLE POSITION CORRELATION EC-797
P2088 INTAKE CAMSHAFT ACTUATOR ... EC-798
P2089 INTAKE CAMSHAFT ACTUATOR ... EC-800
P2090 EXHAUST CAMSHAFT ACTUATOR EC-802
P2091 EXHAUST CAMSHAFT ACTUATOR EC-804
P2096 AIR-FUEL RATIO EC-806
P2097 AIR-FUEL RATIO EC-807
P2101 THROTTLE VALVE ACTUATOR EC-808
P2102 THROTTLE VALVE ACTUATOR EC-810
P2103 THROTTLE VALVE ACTUATOR EC-812
P2111 THROTTLE VALVE ACTUATOR EC-814
P2119 THROTTLE VALVE EC-816
P2122 ACCELERATOR PEDAL POSITION SENSOR 1 ..... EC-818
P2123 ACCELERATOR PEDAL POSITION SENSOR 1 ..... EC-820
P2127 ACCELERATOR PEDAL POSITION SENSOR 2 ..... EC-822
P2128 ACCELERATOR PEDAL POSITION SENSOR 2 ..... EC-824
P2135 THROTTLE VALVE POSITION SENSOR EC-826
P2136 THROTTLE VALVE POSITION SENSOR EC-828
P2137 THROTTLE VALVE POSITION SENSOR EC-830
P2138 ACCELERATOR PEDAL POSITION SENSOR EC-832
P2176 THROTTLE VALVE ACTUATOR EC-834
P2177 AIR-FUEL RATIO EC-836
P2178 AIR-FUEL RATIO EC-837
P2187 AIR-FUEL RATIO EC-838
P2188 AIR-FUEL RATIO EC-839
P2195 A/F SENSOR EC-840
P2196 A/F SENSOR EC-842
P219C AIR-FUEL RATIO IMBALANCE (CYLINDER 1) EC-844
P219D AIR-FUEL RATIO IMBALANCE (CYLINDER 2) EC-845
P219E AIR-FUEL RATIO IMBALANCE (CYLINDER 3) EC-846
P219F AIR-FUEL RATIO IMBALANCE (CYLINDER 4) EC-847
P2227 BAROMETRIC PRESSURE SENSOR EC-848
P2228 BAROMETRIC PRESSURE SENSOR EC-849
P2229 BAROMETRIC PRESSURE SENSOR EC-850
P2230 BAROMETRIC PRESSURE SENSOR EC-851
P2231 A/F SENSOR EC-852
P2237 A/F SENSOR EC-854
P2243 A/F SENSOR EC-856
P2251 A/F SENSOR EC-858
P2263 TC BOOST CONTROL SYSTEM EC-860
P2270 O2 SENSOR EC-863
P2271 O2 SENSOR EC-865
P2279 INTAKE AIR SYSTEM EC-867
P2280 INTAKE AIR SYSTEM EC-868
P2300 IGNITION COIL CONTROL (CYLINDER 1). EC-869
P2301 IGNITION COIL CONTROL (CYLINDER 1). EC-871
P2303 IGNITION COIL CONTROL (CYLINDER 2). EC-873
P2304 IGNITION COIL CONTROL (CYLINDER 2). EC-875
P2306 IGNITION COIL CONTROL (CYLINDER 3). EC-877
P2307 IGNITION COIL CONTROL (CYLINDER 3). EC-879
P2309 IGNITION COIL CONTROL (CYLINDER 4). EC-881
P230A AIR-FUEL RATIO IMBALANCE (CYLINDER 1) EC-885
P230B AIR-FUEL RATIO IMBALANCE (CYLINDER 2) EC-886
P230C AIR-FUEL RATIO IMBALANCE (CYLINDER 3) EC-887

P230D AIR-FUEL RATIO IMBALANCE (CYLINDER 4)..... EC-888
P2310 IGNITION COIL CONTROL (CYLINDER 4) EC-883
P2336, P2337, P2338, P2339 ENGINE KNOCKING EC-889
P2414 A/F SENSOR..... EC-890
P2421 EVAP CANISTER VENT CONTROL VALVE EC-892
P2422 EVAP CANISTER VENT CONTROL VALVE EC-894
P24D5 EVAP CONTROL SYSTEM PRESSURE SENSOR..... EC-896
P24D6 EVAP CONTROL SYSTEM PRESSURE SENSOR..... EC-898
P24D7 EVAP CONTROL SYSTEM PRESSURE SENSOR..... EC-900
P24D8 EVAP CONTROL SYSTEM PRESSURE SENSOR..... EC-902
P2505 ECM POWER SUPPLY EC-904
P250B OIL LEVEL SENSOR EC-905
P250E ENGINE OIL LEVEL SENSOR EC-907
P252B EC-909
P2539 FUEL PRESSURE SENSOR..... EC-910
P2540 FUEL PRESSURE SENSOR..... EC-913
P2541 FUEL PRESSURE SENSOR..... EC-916
P2542 FUEL PRESSURE SENSOR..... EC-919
P2556 COOLANT LEVEL SWITCH MWI-122
P257D ENGINE HOOD SWITCH EC-922
P2600 COOLANT PUMP EC-924
P2602 COOLANT PUMP EC-926
P2603 COOLANT PUMP EC-928
P2610 ENGINE OFF TIME EC-930
P2611 COMPRESSOR HAC-113
P2614 INTAKE CAMSHAFT VALVE LIFT SWITCHOVER POSITION SENSOR ... EC-931
P2615 INTAKE CAMSHAFT VALVE LIFT SWITCHOVER POSITION SENSOR ... EC-933
P2616 INTAKE CAMSHAFT VALVE LIFT SWITCHOVER POSITION SENSOR ... EC-935
P2617 CRANKSHAFT POSITION SENSOREC-937
P261A COOLANT PUMP SWITCHOVER VALVE .. EC-940
P261B ENGINE COOLANT PUMP SWITCHOVER VALVE EC-942
P261C ENGINE COOLANT PUMP SWITCHOVER VALVE EC-944
P261D ENGINE COOLANT PUMP SWITCHOVER VALVE EC-946
P2626 A/F SENSOR EC-948
P267F CONTROL MODULE INTERNAL TEMP SENSOR A TM-143
P2711 UNEXPECTED MECHANICAL GEAR..... TM-144
P2713 PRESSURE CONTROL SOLENOID D TM-145
P2716 ..... EC-950
P2725 ..... EC-951
P2734 ..... EC-952
P2745 INTERMEDIATE SHAFT SPEED SENSOR B TM-146
P2746 INTERMEDIATE SHAFT SPEED SENSOR B TM-147
P2757 ..... EC-953
P2759 ..... EC-954
P2766 ..... EC-955
P2767 ..... EC-956
P2768 ..... EC-957
P2775 PADDLE SHIFTER TM-148
P2779 PADDLE SHIFTER TM-149
P2787 CLUTCH TEMPERATURE TM-150
P2787 MULTIPLE DISK CLUTCH..... DLN-51
P2807 PRESSURE CONTROL SOLENOID G TM-151
P2810 ..... EC-958
P2816 PRESSURE CONTROL SOLENOID H TM-152
P281F PRESSURE CONTROL SOLENOID J TM-153
P2828 PRESSURE CONTROL SOLENOID K..... TM-154
P2831 SHIFT FORK A TM-155
P2832 SHIFT FORK A TM-156
P2836 SHIFT FORK B TM-157
P2837 SHIFT FORK B TM-158
P283B SHIFT FORK C..... TM-159
P283C SHIFT FORK C TM-160
P2840 SHIFT FORK D TM-161
P2841 SHIFT FORK D TM-162
P284D SHIFT FORK A..... TM-163
P2857 CLUTCH A TM-164
P2859 CLUTCH A TM-165
P287C ADAPTATION WAS NOT COMPLETED SUCCESSFULLY. TM-166
PARK ASSIST DAS-209
PASSENGER AIR BAG MODULE SR-24
PASSENGER SEAT CONTROL UNIT ADP-26, SE-23
PERFORMANCE TEST HA-20
PERIODIC MAINTENANCE..... MA-8
POWER DISTRIBUTION SYSTEM..... PCS-13
POWER SOCKET PWO-7, PWO-9
POWER STEERING CONTROL SYSTEM .STC-17
POWER SUPPLY ROUTING CIRCUIT.....PG-15
POWER WINDOW MAIN SWITCH..... PWC-70, PWC-89
POWER WINDOW MOTOR..... PWC-74
POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE..... PWC-86
POWER WINDOW SYSTEM PWC-14
POWERTRAIN CAN COMMUNICATION....LAN-72

PRECAUTIONS ACC-2, ADP-4, AV-9, AV-260, AV-351, AV-403, BCS-5, BR-3, BRC-25, BRC-978, BRM-99, CCS-14, CCS-342, CHG-2, CO-2, DAS-7, DAS-180, DEF-2, DLK-7, DLN-4, DLN-81, DLN-96, EC-22, EM-3, EX-2, EXL-13, EXL-313, EXT-3, FAX-2, FL-2, FSU-2, GI-23, GW-3, HA-3, HAC-4, HRN-2, INL-4, INT-3, IP-2, LAN-6, LAN-148, LU-2, MIR-3, MWI-4, PB-4, PCS-3, PG-3, PWC-4, PWO-2, RAX-2, RAX-10, RF-3, RSU-2, SB-2, SBC-2, SE-3, SEC-2, SN-3, SR-3, SRC-4, ST-2, STC-3, STR-2, TM-9, VTL-2, WCS-2, WT-3, WW-3
PREDICTIVE COURSE LINE CENTER POSITION ADJUSTMENT AV-301
PRESET SWITCH AV-242
PYROFUSE SR-43

R

RADIAL SHAFT OIL SEAL DLN-76
RADIATOR CO-12, CO-13
RADIATOR CORE SUPPORT DLK-236
RE LEARNING MWI-100, PB-38, STC-24
REAR BUMPER EXT-25
REAR CAMERA AV-350
REAR COIL SPRING AND SHOCK ABSORBER ... RSU-9
REAR COMBINATION LAMP EXL-303, EXL-524
REAR DIFFERENTIAL GEAR OIL DLN-102
REAR DISC BRAKE BR-7, BR-15, BR-41
REAR DOOR DLK-248
REAR DOOR FINISHER INT-19
REAR DOOR GLASS GW-49
REAR DOOR LOCK DLK-269
REAR DOOR MODULE ASSEMBLY GW-54
REAR DOOR SPEAKER AV-250
REAR DRIVE SHAFT RAX-16, RAX-21
REAR FENDER COVER EXT-57
REAR FINAL DRIVE ASSEMBLY DLN-111
REAR INSIDE KEY ANTENNA DLK-282
REAR LH SIDE POWER WINDOW DOES NOT OPERATE PWC-80
REAR LOWER LINK RSU-13
REAR MAP LAMP INL-120
REAR PILLAR SQUAWKER AV-251
REAR POWER WINDOW SWITCH PWC-72, PWC-91
REAR PROPELLER SHAFT DLN-85, DLN-86
REAR REFLEX REFLECTOR ... EXL-311, EXL-532
REAR RH SIDE POWER WINDOW DOES NOT OPERATE PWC-81
REAR SEAT SE-78
REAR SEAT BELT SB-14
REAR SPOILER EXT-59
REAR STABILIZER RSU-19
REAR SUSPENSION ASSEMBLY RSU-6
REAR SUSPENSION MEMBER RSU-23
REAR VIEW CAMERA AV-401
REAR VIEW MONITOR SYSTEM AV-357, AV-386, AV-399
REAR WASHER WW-77
REAR WHEEL HUB AND HOUSING RAX-6, RAX-7, RAX-15, RAX-17
REAR WINDOW DEFOGGER DEF-43
REAR WINDOW DEFOGGER DOES NOT OPERATE BUT BOTH DOOR MIRROR DEFOGGERS OPERATE DEF-45
REAR WIPER WW-69
RECOMMENDED FLUIDS AND LUBRICANTS MA-12
REFRIGERANT HA-15
REFRIGERANT PRESSURE SENSOR ... HAC-127
REFRIGERATION SYSTEM SYMPTOMS ... HA-22
REMOTE KEYLESS ENTRY RECEIVER DLK-284
REPAIRING HIGH STRENGTH STEEL .. BRM-100
REPAIRING MATERIAL BRM-105
REPAIRING PROCEDURES AND PRECAUTIONS BRM-53
REPLACEMENT OPERATIONS BRM-129
RESET OF CODING STC-22
RESETTING CENTER POSITION OF STEERING . STC-25
RESETTING OF ADAPTATION VALUES ... EC-195
RETROFITTING DAS-67
REVERSE SIGNAL CIRCUIT AV-209, AV-344, AV-398
RIGHT FRONT DOOR CONTROL UNIT .. DLK-62, DLK-94
ROAD WHEEL WT-67
ROAD WHEEL TIRE ASSEMBLY WT-70
ROOF RAIL EXT-46
ROOF SIDE MOLDING EXT-47
ROOM LAMP INL-118
ROTARY LIGHT SWITCH EXL-298, EXL-522

S

S CONNECTOR CIRCUIT STR-16
SAFETY AND HEALTH BRM-48
SATELLITE RADIO ANTENNA AV-256
SATELLITE SENSOR SR-36
SEAL DLN-114
SEAT BELT PRE-TENSIONER SR-39
SEAT BELT WARNING LAMP CONTROL SYSTEM SBC-8
SEAT CONTROL UNIT ADP-113
SECURITY CONTROL SYSTEM SEC-19
SENSOR INITIALIZE EXL-117
SENSOR ROTOR BRC-971
SENSOR UNLOCK CCS-71
SERVICE AFTER REPLACING OR REMOVING ENGINE PARTS EC-182

SERVICE DATA AND SPECIFICATIONS (SDS) BR-54, CHG-38, CO-23, DLN-80, DLN-95, DLN-116, EM-102, EXL-312, EXL-533, FL-22, FSU-22, HA-44, INL-142, LU-17, MA-40, PG-127, RSU-31, ST-18, STR-19, TM-276, VTL-17, WT-76
SERVICE INFORMATION FOR ELECTRICAL INCIDENT GI-55
SET AUTO LOCATION DISABLE WT-34
SHEET METAL WORK BRM-4
SIDE CAMERA AV-349
SIDE OIL SEAL DLN-107
SIDE RADAR DAS-177
SIDE RADAR LH DAS-46
SIDE RADAR RH DAS-48
SIDE TURN SIGNAL LAMP EXL-295, EXL-519
SILL COVER EXT-55
SONAR CONTROL UNIT DAS-199, SN-32, SN-200
SONAR SENSOR SN-202
SONAR SYSTEM (FRONT 6 & REAR 4 SENSORS) SN-42
SONAR SYSTEM (FRONT 6 & REAR 6 SENSORS WITH PARK ASSIST) SN-50
SONAR SYSTEM SWITCH SN-201
SOUND SIGNAL CIRCUIT AV-214
SPARK PLUG EM-18
SQUEAK AND RATTLE TROUBLE DIAGNOSES .. DLK-224, EXT-7, GW-7, INT-7, IP-6, RF-23, SE-57
SRS AIR BAG SYSTEM SRC-26
STARTER MOTOR STR-18
STARTER OPERATION COUNTER CLEAR EC-197
STARTING SYSTEM STR-7
STEERING COLUMN ST-9
STEERING COLUMN CONTROL MODULE AV-94, BCS-59, BCS-85, BCS-250, CCS-49, CCS-374, DAS-50, MWI-88, TM-52
STEERING GEAR AND LINKAGE ST-13
STEERING SHAFT ST-11
STEERING SWITCH AV-254, MWI-157
STEERING WHEEL ST-6, ST-8
STEP LAMP INL-126
STRUCTURE AND OPERATION DLN-11, DLN-100, EC-47, TM-21
SUNLOAD SENSOR HAC-125
SUNSHADE DOES NOT OPERATE ANTI-PINCH FUNCTION RF-22
SUNSHADE DOES NOT OPERATE PROPERLY .. RF-20
SUNSHADE MOTOR ASSEMBLY RF-9
SUNSHADE SWITCH RF-18, RF-31
SUNSHADE SYSTEM RF-10
SUNSHADE UNIT ASSEMBLY RF-29
SYSTEM INITIALIZATION ADP-46, PWC-26, RF-15

T

TCM TM-44
TCU AV-417, AV-459
TCU BRANCH LINE CIRCUIT LAN-147
TEACH IN OF CAMSHAFT POSITION EC-194
TEACH IN OF THROTTLE VALVE STOP ... EC-192
TEACH IN PROCESS SENSOR ROTOR ADAPTATION EC-190
TEACH-IN OF ACTUATOR MOTORS HAC-50
TEL VOICE SIGNAL CIRCUIT AV-219
TELEMATICS ANTENNA AV-462
TELEMATICS SWITCH AV-461
TELEMATICS SYSTEM AV-422, AV-456
TEST DRIVE STC-26
THERMOSTAT CO-21
TIGHTENING TORQUE OF STANDARD BOLTS ... GI-20
TIMING CHAIN EM-88
TIRE PRESSURE MONITORING SYSTEM WT-29
TIRE PRESSURE SENSOR WT-73
TOW TRUCK TOWING GI-48
TRACTION SYSTEM HYDRAULIC UNIT BRC-972
TRAILING ARM RSU-15
TRANSAXLE ASSEMBLY TM-228, TM-230
TRANSAXLE CASE TM-263
TRANSAXLE COOLING MODULE TM-223
TRANSAXLE FLUID TM-212
TRANSAXLE FLUID CHARGING PIPE TM-221
TRANSAXLE FLUID COOLER SYSTEM TM-225
TRANSFER ASSEMBLY DLN-74
TRANSFER OIL DLN-71
TRANSMISSION CONTROL SYSTEM TM-53
TRANSVERSE LINK FSU-14
TROUBLE DIAGNOSIS LAN-26

U

U0001 CAN COMMUNICATION STC-44
U0001 DRIVETRAIN CAN COMMUNICATION TM-167
U0002 POWERTRAIN CAN COMMUNICATION EC-211
U0010 COMMUNICATION WITH CAN HAS MALF DAS-114
U0019 BODY CAN COMMUNICATION 1 . LAN-196
U0019 COMMUNICATION ERROR BCS-169
U0019 CONTROL UNIT (CAN) HAC-115
U0019 INTELLIGENT KEY UNIT DLK-198
U0019 INTERIOR CAN MWI-133
U0028 POWERTRAIN CAN COMMUNICATION EC-213
U0037 CAN COMM CIRCUIT SN-182
U0037 CAN COMMUNICATION EC-215
U0037 CHASSIS CAN COMMUNICATION LAN-197
U0046 CAN COMMUNICATION EC-216
U0073 CAN COMMUNICATION DLN-52

U0100 CAN COMM CIRCUIT SN-184
U0100 CAN COMMUNICATION..... DLN-53
U0100 COMMUNICATION ERROR BCS-170, EXL-255, EXL-481, TM-169
U0100 ECM LAN-198
U0100 ECM COMMUNICATION PB-90
U0100 ENGINE SYSTEM STC-45, WT-50
U0100 LOST COMMUNICATION WITH ECM/PCM A DAS-115
U0100 POWERTRAIN CAN COMMUNICATION (ECM) EC-217
U0101 CAN COMM CIRCUIT SN-186
U0101 CAN COMMUNICATION..... DLN-54
U0101 POWERTRAIN CAN COMMUNICATION (TCM) EC-219
U0101 TCM MWI-134
U0101 TCM COMMUNICATION PB-93
U0102 COMMUNICATION ERROR (LOST) TM-170
U0103 CAN COMMUNICATION..... EC-220
U0103 COMMUNICATION ERROR (LOST) TM-171
U0104 LOST COMM (CRUISE CONTROL MODULE) TM-172
U0108 COMMUNICATION ERROR (LOST) EC-221
U0109 POWERTRAIN CAN COMMUNICATION (FPCM) EC-222
U010F COMMUNICATION ERROR (LOST) TM-173
U0111 CAN COMMUNICATION (BCM)..... EC-224
U0111 COMMUNICATION ERROR (LOST) TM-174
U0115 COMMUNICATION ERROR (LOST) TM-175
U0120 LIN COMMUNICATION (ALTERNATOR)..... EC-225
U0121 CAN COMMUNICATION (ELECTRONIC STABILITY PROGRAM CONTROL UNIT)..... EC-226
U0121 COMMUNICATION ERROR BCS-171, EXL-258, EXL-484
U0121 COMMUNICATION ERROR (LOST) TM-176
U0121 ELECTRONIC STABILITY PROGRAM CONTROL UNIT COMMUNICATION..... PB-95
U0122 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) AV-314
U0122 CAN COMM CIRCUIT SN-188
U0122 CAN COMMUNICATION... DLN-55, PCS-25
U0122 CAN COMMUNICATION (ELECTRONIC STABILITY PROGRAM CONTROL UNIT)..... EC-228
U0122 ELECTRIC STABILITY PROGRAM (ESP) SYSTEM..... STC-46
U0122 ELECTRONIC STABILITY PROGRAM CONTROL UNIT LAN-199
U0122 LOST COMMUNICATION WITH VDCM..... DAS-118
U0126 COMMUNICATION ERROR BCS-172
U0127 TIRE PRESSURE MONITORING SYSTEM MWI-135
U0128 CAN COMM CIRCUIT SN-190
U0128 CAN COMMUNICATION (ELECTRIC PARKING BRAKE CONTROL MODULE) EC-230
U0128 COMMUNICATION ERROR (LOST) TM-177
U0128 ELECTRIC PARKING BRAKE MWI-136
U0129 LOST COMM (BRAKE SYSTEM CONT MODULE) TM-178
U0131 CAN COMM CIRCUIT..... SN-192
U0131 POWER STEERING MWI-137
U0140 BCM MWI-138
U0141 BCM DLK-133, LAN-200
U0141 CAN COMMUNICATION..... PCS-27
U0141 COMMUNICATION ERROR BCS-234, DAS-121
U0141 LOST COMM (BODY CONTROL MODULE A) TM-179
U0142 LOST COMMUNICATION WITH BCM B DAS-122
U0143 COMMUNICATION ERROR BCS-173
U0146 CENTRAL GATEWAY MWI-140
U0146 COMMUNICATION ERROR BCS-236, EXL-261, EXL-487
U0146 COMMUNICATION ERROR (LOST)..... DAS-124, TM-180
U0146 COMMUNICATION WITH CENTRAL GATEWAY SRC-161
U0146 ELECTRONIC IGNITION SWITCH CONTROL UNIT COMMUNICATION..... PB-99
U0147 DISPLAY CONTROL UNIT LAN-201
U0151 CAN COMMUNICATION (AIR BAG DIAGNOSIS SENSOR UNIT)..... EC-231
U0151 COMMUNICATION ERROR BCS-174
U0151 SRS AIRBAG CONTROL SYSTEM MWI-141
U0155 CAN COMM CIRCUIT..... SN-194
U0155 CAN COMMUNICATION..ADP-98, DLN-56, EXL-264
U0155 CAN COMMUNICATION (COMBINATION METER)..... EC-232, SRC-163
U0155 COMBINATION METER LAN-202
U0155 COMBINATION METER COMMUNICATION PB-101
U0155 COMBINATION METER SYSTEM. STC-47, WT-51
U0155 COMMUNICATION ERROR BCS-175, BCS-238, EXL-490
U0155 COMMUNICATION ERROR (LOST) TM-181
U0155 LOST COMMUNICATION (COMBINATION METER)..... HAC-116
U0155 LOST COMMUNICATION WITH IPCCM DAS-126
U0159 COMMUNICATION ERROR BCS-176
U0159 SONAR CONTROL UNIT LAN-203
U0163 NAVI CONTROL UNIT LAN-204
U0164 A/C AMP. LAN-205
U0164 CAN COMMUNICATION (A/C AUTO AMP.) EC-234
U0164 COMMUNICATION ERROR BCS-177

U0167 COMMUNICATION ERROR.....BCS-178
U0168 CAN COMM CIRCUIT SN-196
U0168 CAN COMMUNICATIONADP-101, DLN-57, EC-235
U0168 COMMUNICATION ERROR.....BCS-179, BCS-240, EXL-267, EXL-493
U0168 COMMUNICATION ERROR (LOST)TM-182
U0168 ELECTRIC IGNITION LOCK SYSTEM PB-103, STC-48
U0168 ELECTRONIC IGNITION SWITCHMWI-142
U0168 ELECTRONIC IGNITION SWITCH CONTROL UNIT LAN-206
U0168 FRONT DOOR CONTROL UNIT .. DLK-136
U0168 INTELLIGENT KEY UNIT..... DLK-199
U0168 LOST COMMUNICATION WITH VSCM..... DAS-129
U0169 COMMUNICATION ERROR.....BCS-180
U0198 TCU LAN-207
U0203 COMMUNICATION ERROR.....BCS-181
U0203 FRONT DOOR CONTROL UNIT .. DLK-139
U0203 LOST COMMUNICATION (LEFT FRONT DOOR CONTROL UNIT) HAC-117
U0204 COMMUNICATION ERROR.....BCS-182
U0204 FRONT DOOR CONTROL UNIT .. DLK-141
U0204 LOST COMMUNICATION (RIGHT FRONT DOOR CONTROL UNIT) HAC-118
U0210 SEAT CONTROL UNIT ADP-110
U0212 CAN COMM CIRCUIT SN-198
U0212 CAN COMMUNICATION DLN-58
U0212 CAN COMMUNICATION (STEERING COLUMN CONTROL MODULE) EC-237
U0212 COMMUNICATION ERROR..... EXL-270, EXL-496
U0212 LOST COMMUNICATION WITH SCCM..... DAS-132
U0212 STEERING COLUMN CONTROL MODULE LAN-208, STC-49
U0212 STEERING COLUMN CONTROL MODULE COMMUNICATION PB-105
U0212 STEERING COLUMN MODULE ...MWI-143
U0213 COMMUNICATION ERROR.....BCS-183
U0215 LIN COMMUNICATION DLK-143
U0231 COMMUNICATION ERROR.....BCS-185
U0252 LOST COMMUNICATION WITH LCM REAR B.....DAS-136
U0252 TRAILER RECOGNITION CONTROL UNIT LAN-209
U0255 DISPLAY CONTROL UNIT..... LAN-210
U025D LOST COMM (FR CNTRLS INTERFACE MODL B) TM-183
U0291 COMMUNICATION ERROR (LOST)TM-184
U029E CAN COMMUNICATION..... EC-238
U0401 CAN COMMUNICATION EC-239
U0401 COMMUNICATION DATA.....DLN-59
U0401 COMMUNICATION ERROR.....BCS-187
U0401 ECM SIGNAL PB-107
U0401 ENGINE SYSTEM STC-50
U0401 INVALID DATA RECEIVED FROM ECM/ PCM A..... DAS-138
U0402 CAN COMMUNICATION EC-241
U0402 COMMUNICATION DATA.....DLN-61
U0402 INVALID DATA RECEIVED FROM TCM DAS-141
U0402 TCM SIGNAL..... PB-110
U0404 COMMUNICATION ERROR (INVALID)..... TM-185
U0404 POWERTRAIN CAN COMMUNICATION (ELECTRIC SHIFT CONTROL UNIT)... EC-242
U0405 CAN COMMUNICATION EC-243
U040A CAN COMMUNICATION (A/C AUTO AMP.) EC-244
U0415 ELECTRONIC STABILITY PROGRAM CONTROL UNIT SIGNAL PB-112
U0416 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)..... AV-316
U0416 CAN COMMUNICATION EC-245
U0416 COMMUNICATION DATA.....DLN-63
U0416 COMMUNICATION ERROR..... BCS-188
U0416 COMMUNICATION ERROR (INVALID)..... TM-186
U0416 ELECTRIC STABILITY PROGRAM (ESP) SYSTEM STC-51
U0416 INVALID DATA RECEIVED FROM VDCM .. DAS-143
U0417 CAN COMMUNICATION (ELECTRIC PARKING BRAKE CONTROL MODULE)EC-246
U0423 CAN COMMUNICATION (COMBINATION METER) EC-247
U0423 COMBINATION METER SIGNAL.... PB-116
U0423 COMBINATION METER SYSTEM .STC-53, WT-52
U0423 COMMUNICATION DATA.....DLN-65
U0423 COMMUNICATION ERROR (INVALID)..... TM-187
U0423 INVALID DATA RECEIVED FROM IPCCM . DAS-146
U0424 CAN COMMUNICATION (A/C AUTO AMP.) EC-248
U0427 CAN COMMUNICATION EC-249
U0427 CHECK CODINGS IN ELECTRONIC IGN LOCK DAS-148
U0427 COMMUNICATION DATA.....DLN-66
U0427 COMMUNICATION ERROR..... BCS-189
U0427 COMMUNICATION ERROR (INVALID)..... TM-188
U0427 ELECTRIC IGNITION LOCK SYSTEM STC-54
U0427 ELECTRONIC IGNITION SWITCH CONTROL UNIT DLK-201
U0427 ELECTRONIC IGNITION SWITCH CONTROL UNIT SIGNAL PB-117

U0428 INVALID DATA RCVD FRM STRG ANGL SEN MDL TM-189
U0428 STEERING ANGLE SENSOR AV-318
U0429 CAN COMMUNICATION (STEERING COLUMN CONTROL MODULE)..... EC-251
U0429 COMMUNICATION DATA DLN-68
U0429 COMMUNICATION ERROR (INVALID)..... TM-190
U0429 INVALID DATA RECEIVED FROM SCCM... DAS-150
U0429 STEERING COLUMN CONTROL MODULE STC-55
U0429 STEERING COLUMN CONTROL MODULE SIGNAL PB-119
U0447 ELECTRONIC IGNITION SWITCH CONTROL UNIT SIGNAL PB-121
U0452 CAN COMMUNICATION (AIR BAG DIAGNOSIS SENSOR UNIT)..... EC-252
U0452 COMMUNICATION ERROR BCS-190
U0469 LIN COMMUNICATION (ALTERNATOR)..... EC-253
U0504 COMMUNICATION ERROR BCS-191, DAS-153, TM-191
U0505 COMMUNICATION ERROR BCS-192, DAS-155, TM-192
U1000 CAN COMM CIRCUIT AV-153, AV-319, AV-439
U1008 COMMUNICATION ERROR BCS-193, BCS-242
U1008 CONTROL UNIT (LIN) HAC-119
U1008 LIN COMMUNICATION. DLK-147, SRC-165
U1008 LIN COMMUNICATION ERROR.... EXL-273
U1009 COMMUNICATION ERROR BCS-196
U1010 CONTROL UNIT (CAN) AV-155, AV-321, AV-440
U1027 CAN COMMUNICATION..... PB-123
U1032 CAN COMMUNICATION..... PB-125, WT-53
U1032 CHASSIS CAN..... MWI-144
U1032 CHASSIS CAN COMMUNICATION SRC-167
U1032 COMMUNICATION ERROR BCS-243
U1038 DIAGNOSTIC CAN COMMUNICATION LAN-211
U1041 COMM WITH ENGINE CAN BUS.... EC-254
U1043 CHASSIS CAN BUS OFF MALFUNCTION . DAS-157
U105B STEERING COLUMN CONTROL MODULE LAN-212
U1082 SIG PRK POS WS RCVD ELCTRNC IGN LCK ECU TM-193
U108B SIG PARK POSI WAS RECEIVED E-PKB ECU. TM-194
U1093 COMMUNICATION ERROR BCS-198
U1110 CAN COMMUNICATION (ELECTRONIC STABILITY PROGRAM CONTROL UNIT)..... EC-256
U1110 VEHICLE SPEED SIGNAL..... SRC-168
U111A REAR CAMERA IMAGE SIGNAL CIRCUIT. AV-322
U111B SIDE CAMERA RH IMAGE SIGNAL CIRCUIT AV-325
U111C FRONT CAMERA IMAGE SIGNAL CIRCUIT AV-328
U111D SIDE CAMERA LH IMAGE SIGNAL CIRCUIT AV-331
U112F CAN COMMUNICATION..... ADP-104
U1131 TIRE PRESSURE SENSOR WT-54
U1137 LIN COMMUNICATION..... ADP-90
U113B DIRECT SELECT LEVER HAS MALF TM-195
U113E COMMUNICATION ERROR BCS-200
U1145 INTELLIGENT KEY MWI-146
U1152 COMMUNICATION ERROR..... DLK-219
U1154 COMMUNICATION ERROR..... BCS-202
U1162 TIRE PRESSURE SENSOR WT-56
U1163 TIRE PRESSURE SENSOR WT-58
U1164 TIRE PRESSURE SENSOR WT-60
U1165 TIRE PRESSURE SENSOR WT-62
U116A TCU..... LAN-213
U1175 CAN COMMUNICATION SYSTEM (ELECTRONIC IGNITION SWITCH CONTROL UNIT) SRC-170
U118A COMMUNICATION ERROR BCS-204, EXL-275, EXL-499
U118B COMMUNICATION ERROR BCS-205, EXL-277, EXL-501
U118F TCU..... MWI-147
U1198 CAN COMMUNICATION PCS-29
U11A3 CAMERA SYSTEM..... MWI-148
U11A3 COMMUNICATION ERROR BCS-206, BCS-244, EXL-279, EXL-503
U11A4 HEADLAMP LEVEL MWI-149
U11A6 CAN COMMUNICATION (ICC SENSOR).... EC-257
U11A6 RADAR MWI-150
U11BF COMMUNICATION ERROR BCS-207
U1200 COMMUNICATION ERROR EC-258
U1201 COMMUNICATION ERROR EC-259
U1203 FUEL SYSTEM CONTROL UNIT . MWI-152
U120B COMMUNICATION ERROR BCS-209, DAS-159
U121F DISPLAY CONTROL UNIT AV-156
U1223 CONFIG UNFINISH AV-157
U1231 BOSE AMP. AV-158
U1232 STEERING ANGLE SENSOR AV-159, AV-334
U1233 NAVI CONTROL UNIT AV-160
U1234 AV CONTROL UNIT..... AV-161
U1240 SWITCH CONN AV-162
U1244 GPS ANTENNA CONN..... AV-164
U1249 AUDIO H/U CONN AV-166
U124E AMP CONN AV-168
U1258 SATELLITE RADIO ANTENNA..... AV-170

U125D NAVI CONN AV-172
U1266 TCU AV-173
U1267 CGW CONN AV-175
U12BA MULTIFUNCTION SWITCH CONN AV-177
U12BE RADIO ANTENNA CONN..... AV-179
U1300 AV COMM CIRCUIT AV-181
U1302 CAMERA POWER VOLT AV-335
U1303 LED POWER SUPPLY VOLT AV-339
U1304 CAMERA IMAGE CALIBRATION.... AV-340
U1305 CONFIG UNFINISH..... AV-341
U1310 DISPLAY CONTROL UNIT..... AV-183
U1401 SIG ENG RPM CMBSTN ENG ECU NOT RCVD.....TM-196
U1402 SIG ENG TMP CMBSTN ENG ECU NOT RCVD.....TM-197
U1403 FUEL LEVEL MWI-153
U1404 SIG ENG TRQ CMBSTN ENG ECU NOT RCVD.....TM-198
U1405 SIG ENG TRQ CMBSTN ENG ECU NOT RCVD.....TM-199
U1406 SIG ENG TRQ CMBSTN ENG ECU NOT RCVD.....TM-200
U1407 CAN COMMUNICATION (TCM).....EC-260
U1407 ENGINE TORQUE SIGNAL TM-201
U1408 BRAKE SW A/B CORRELATION TM-202
U1409 AN IMPLAUSIBLE FL WHL SPD SIG WS RCVD.....TM-203
U140A AN IMPLAUSIBLE FR WHL SPD SIG WS RCVD.....TM-204
U140B AN IMPLAUSIBLE RL WHL SPD SIG WS RCVD.....TM-205
U140C AN IMPLAUSIBLE RR WHL SPD SIG WS RCVD.....TM-206
U140D WHEEL SPEED SIGNAL. EC-261, PB-127, TM-207
U140D WHEEL SPEED SIGNAL IS IMPLAUSIBLE DAS-161
U140F CAN COMMUNICATION PCS-31
U141D CAN COMMUNICATION ADP-107
U141E COMMUNICATION ERROR EXL-282, EXL-506
U1420 IMPLSBL SIG WS RCVD FRM ELC SLCTR LVR MDL.....TM-208
U1425 ACL PD SN SIG CMBSN ENG CU WS NT RCVD.....TM-209
U1433 SIG 'STATUS OF CIRCUIT 15'.....TM-210
U1442 COMMUNICATION ERROR.....BCS-246
U1444 CAN COMMUNICATION (ICC SENSOR) ... EC-262
U144D TRQ RQST CMBSTN ENG ECU WS NT RCVD.....TM-211
U144E COMMUNICATION ERROR DAS-163
U1459 IMPLAUSIBLE DATA RECEIVED FROM H/L DAS-165
U1502 RADAR SENSOR 8 COMM HAS MALFUNCTION DAS-167
U1503 RADAR SENSOR 8 COMM HAS MALFUNCTION DAS-169
U1504 RADAR SENSOR 8 COMM HAS MALFUNCTION DAS-171
U1601, U1603, U1609, U160B FRONT DOOR SPEAKER/TWEETER..... AV-184
U1606 AIR BAG DIAGNOSIS SENSER UNIT SRC-172
U1607 AIR BAG DIAGNOSIS SENSER UNIT SRC-173
U162A CENTER SQUAWKER..... AV-190
U1708, U1710 REAR DOOR SPEAKER AV-192
U1752, U175A REAR PILLAR SQUAWKERAV-196
U175D, U1765 WOOFER AV-199
U1900 MULTIFUNCTION MEDIA CAN COMMUNICATION LAN-215
U1901 AV COMMUNICATION LAN-216
U1A00 TCU AV-441
U1A01 TCU AV-442
U1A02 TCU AV-443
U1A03 TCU AV-444
U1A04 TCU AV-445
U1A06 TEL ANTENNA..... AV-446
U1A09 GPS ANTENNA..... AV-447
U1A0A TCU..... AV-448
U1A0B MICROPHONE AV-449
U1A0C MICROPHONE AV-451
U1A0E SOS SWITCH AV-453
U1A10 TCU AV-454
U3003 BATTERY VOLTAGE EC-263
U300E CAN COMMUNICATION.....EC-264
U3011 CAN COMMUNICATION.....EC-265
UPPER CONTROL PANEL CONTROL UNIT BCS-62, BCS-252, SE-25
UPPER LINK..... RSU-21

V

VACUUM LINES.....BR-32, EC-962
VACUUM PUMP..... EM-39
VANITY MIRROR LAMP INL-116
VEHICLE HANDOVER PROCEDURE..... MWI-101
VEHICLE SPEED SIGNAL CIRCUIT AV-208
VENTILATION SYSTEM EM-34, VTL-3
VIN REGISTRATION..... BRC-87, EC-196, PB-35
VOICE GUIDANCE SIGNAL CIRCUIT AV-220

W

WARNING CHIME..... WCS-5
WATER PUMP CO-18
WHEEL ALIGNMENT.....FSU-8, RSU-7
WHEEL SENSOR BRC-967
WINDSHIELD GLASS.....GW-13
WIPER AND WASHER SWITCH WW-83
WIPER AND WASHER SYSTEM..... WW-24
WOOFER AV-252

WRITE IDENTIFICATION NUMBERS OF TIRE PRESSURE SENSORS WT-32

Z

ZERO POINT RESET SRC-60