

SECTION **IDX**
ALPHABETICAL INDEX

A
B
C
D
E
F
G
H
I
J
K
L

ALPHABETICAL INDEX

A

A/C - Wiring diagram [MTC-22](#)
 A/C component layout [MTC-57](#)
 A/C compressor clutch removal and installation
[MTC-58](#)
 A/C compressor precaution [MTC-6](#)
 A/C compressor special service tool [MTC-10](#)
 A/C HFC134a (R134a) system precaution [MTC-3](#)
 A/C HFC134a (R134a) system service tools .. [MTC-10](#)
 A/C HFC134a system service equipment precaution ...
[MTC-6](#)
 A/C lubricant (R134a) [MTC-71](#)
 A/C service data specification [MTC-71](#)
 A/C trouble diagnoses (manual A/C) [MTC-17](#)
 A/C, M - Wiring diagram [MTC-22](#)
 A/T - Wiring diagram - AT - FTS [AT-119](#)
 A/T - Wiring diagram - AT - MAIN [AT-355](#)
 A/T - Wiring diagram - AT - PNP/SW [AT-113](#)
 A/T - Wiring diagram - AT - VSS A/T . [AT-125](#), [AT-360](#)
 A/T fluid checking [AT-12](#), [MA-24](#)
 A/T fluid replacement [AT-12](#), [MA-24](#)
 A/T fluid temperature sensor [AT-122](#)
 A/T shift lock system [AT-411](#)
 A/T shift lock system - Wiring diagram [AT-412](#)
 A/T trouble diagnoses [AT-55](#), [AT-259](#)
 A/T Wiring diagram - AT - ENG SS .. [AT-129](#), [AT-398](#)
 A/T Wiring diagram AT - 1ST [AT-135](#)
 A/T Wiring diagram AT - 2ND [AT-141](#)
 A/T Wiring diagram AT - 3RD [AT-147](#)
 A/T Wiring diagram AT - 4TH [AT-153](#)
 A/T Wiring diagram AT - BA/FTS [AT-195](#), [AT-393](#)
 A/T Wiring diagram AT - CAN [AT-409](#)
 A/T Wiring diagram AT - LPSV [AT-165](#), [AT-403](#)
 A/T Wiring diagram AT - OVRCSV [AT-187](#), [AT-383](#)
 A/T Wiring diagram AT - SSV/A [AT-172](#), [AT-374](#)
 A/T Wiring diagram AT - SSV/B [AT-177](#), [AT-379](#)
 A/T Wiring diagram AT - TCV [AT-160](#), [AT-388](#)
 A/T Wiring diagram AT - TPS [AT-182](#), [AT-369](#)
 A/T Wiring diagram AT - VSSMTR .. [AT-201](#), [AT-365](#)
 A/WIP - Wiring diagram [WW-44](#)
 ABS - Wiring diagram [BRC-11](#)
 ABS input/output signal inspection [BRC-14](#)
 ABS sensor rotor [RAX-5](#)
 Accelerator pedal position (APP) sensor [EC-213](#),
[EC-222](#), [EC-351](#), [EC-548](#), [EC-557](#), [EC-638](#)
 Accelerator pedal released position learning [EC-34](#),
[EC-435](#)
 Air bag [SRS-3](#), [SRS-36](#), [SRS-40](#), [SRS-42](#), [SRS-43](#)
 Air bag disposal [SRS-49](#)
 Air bleeding (hydraulic clutch) [CL-7](#)
 Air bleeding for brake system [BR-10](#)
 Air conditioner - Wiring diagram [MTC-22](#)
 Air conditioner cut control [EC-26](#), [EC-427](#)
 Air mix door control linkage adjustment [MTC-50](#)
 Alternator [SC-14](#)
 Antenna [AV-13](#)
 AP/SEN - Wiring diagram .. [EC-137](#), [EC-323](#), [EC-509](#),
[EC-610](#)

APPS1 - Wiring diagram [EC-224](#), [EC-559](#)
 APPS2 - Wiring diagram [EC-353](#), [EC-640](#)
 APPS3 - Wiring diagram [EC-215](#), [EC-550](#)
 Audio [AV-3](#)
 AUDIO - Wiring diagram [AV-4](#)
 Auto wiper [WW-37](#)
 Automatic transaxle number [GI-46](#)
 Automatic transmission fluid replacement [MA-24](#)
 Axle [MA-27](#)

B

Back door trim [EI-19](#)
 Back door window [GW-10](#)
 Back window [GW-10](#)
 BACK/L - Wiring diagram [LT-98](#)
 Back-up lamp [LT-98](#), [LT-101](#)
 Basic inspection [EC-68](#), [EC-454](#)
 Battery [SC-4](#)
 BCM (Body control module) [BCS-3](#)
 Blower motor [MTC-25](#), [MTC-45](#)
 Blower resistor [MTC-46](#)
 Board computer [DI-29](#)
 Board-on lift [GI-39](#)
 Bose speaker amp. [AV-3](#)
 Brake booster [BR-17](#)
 Brake fluid change [BR-9](#)
 Brake fluid level [MA-25](#)
 Brake fluid level and line check [BR-9](#)
 Brake hydraulic line [BR-11](#)
 Brake inspection [MA-26](#)
 Brake lines and cables inspection [MA-25](#)
 Brake master cylinder [BR-14](#)
 Brake pedal [BR-6](#)
 Brake switch [EC-370](#), [EC-651](#)
 BRK/SW - Wiring diagram [EC-372](#), [EC-653](#)
 Bulb specifications [LT-138](#)
 Bumper, front [EI-4](#)
 Bumper, rear [EI-7](#)

C

Cabin air filter [MTC-47](#)
 Camshaft position sensor (PHASE) .. [EC-247](#), [EC-577](#)
 CAN - Wiring diagram [EC-121](#), [EC-506](#), [LAN-12](#),
[LAN-38](#), [LAN-62](#), [LAN-86](#)
 CAN (Controller Area Network) [LAN-5](#), [LAN-11](#),
[LAN-37](#), [LAN-61](#), [LAN-85](#)
 CAN communication [EC-120](#), [EC-429](#), [EC-505](#),
[AT-108](#), [AT-311](#), [AT-408](#), [BRC-22](#), [LAN-5](#), [LAN-11](#),
[LAN-37](#), [LAN-61](#), [LAN-85](#)
 Canister-See EVAP canister [EC-408](#), [EC-734](#)
 CD/CHG - Wiring diagram [AV-4](#)
 CHARGE - Wiring diagram [SC-15](#)
 Charging system [SC-14](#)
 Chassis and body maintenance [MA-23](#)
 CHIME - Wiring diagram [DI-65](#)
 CIGAR - Wiring diagram [WW-79](#)
 Circuit breaker [PG-17](#)

ALPHABETICAL INDEX

Closed loop control [EC-24](#), [EC-425](#)
 Clutch cover [CL-10](#), [CL-11](#)
 Clutch disc [CL-10](#)
 Clutch master cylinder [CL-8](#)
 Clutch pedal [CL-5](#)
 Coil spring (front) [FSU-8](#)
 Coil spring (rear) [RSU-8](#)
 Collision diagnosis [SRS-56](#)
 Combination meter [DI-5](#)
 Combination switch [LT-102](#), [LT-104](#)
 COMBSW - Wiring diagram [LT-107](#)
 COMM - Wiring diagram [DI-40](#)
 Component Location (manual A/C) [MTC-20](#)
 Compressor clutch removal and installation .. [MTC-58](#)
 Compressor precaution [MTC-6](#)
 Compressor special service tool [MTC-10](#)
 Condenser [MTC-64](#)
 CONSULT for ABS [BRC-15](#)
 CONSULT for engine [EC-91](#), [EC-477](#)
 CONSULT general information [GI-34](#)
 Control unit [MTC-38](#)
 Control units (terminal arrangement) [PG-83](#)
 Controller Area Network (CAN) [LAN-5](#), [LAN-11](#),
[LAN-37](#), [LAN-61](#), [LAN-85](#)
 Converter housing installation [AT-424](#), [AT-520](#)
 COOL/F - Wiring diagram [EC-331](#), [EC-618](#)
 Coolant mixture ratio [MA-13](#)
 Cooling circuit (engine)(QG) [CO-6](#)
 Cooling fan motor [EC-340](#), [EC-627](#)
 Cowl top [EI-11](#)
 Crankcase ventilation system - See Positive crankcase
 ventilation [EC-409](#), [EC-735](#)
 Crankshaft position sensor (POS) [EC-241](#), [EC-570](#)
 Crash zone sensor [SRS-45](#)

D

Data link connector [EC-403](#), [EC-729](#)
 Data link connector for Consult [EC-94](#), [EC-480](#)
 Daytime light system [LT-32](#)
 DEF - Wiring diagram [GW-21](#)
 Diagnosis sensor unit [SRS-48](#)
 Diagnostic trouble code (DTC) for OBD system [EC-10](#),
[EC-42](#), [EC-413](#), [EC-440](#)
 Diagnostic trouble code (DTC) inspection priority chart
[EC-65](#), [EC-451](#)
 Dimensions [GI-47](#)
 DLC - Wiring diagram [EC-403](#), [EC-729](#)
 Door glass [GW-4](#), [GW-56](#), [GW-59](#)
 Door mirror [GW-62](#)
 Door trim [EI-17](#)
 Drive computer [DI-28](#), [DI-40](#)
 Drive shaft (front) [FAX-10](#)
 Driver air bag [SRS-36](#)
 Dropping resistor (A/T) [AT-169](#), [AT-407](#)
 DTC work support [EC-101](#)
 Duct and grilles [MTC-52](#)

E

ECM input/output signal [EC-84](#), [EC-470](#)
 ECM power supply [EC-115](#), [EC-268](#), [EC-500](#), [EC-587](#)
 ECM/PW - Wiring diagram [EC-269](#), [EC-588](#)
 ECTS - Wiring diagram [EC-148](#), [EC-515](#)
 Electric throttle control actuator [EC-276](#), [EC-278](#),
[EC-289](#), [EC-591](#), [EC-593](#), [EC-604](#)
 Electrical diagnoses [GI-10](#)
 Electrical load signal circuit [EC-401](#), [EC-727](#)
 Electrical unit [PG-83](#)
 Electrical units location [PG-78](#)
 Electronic ignition (EI) system [EC-25](#), [EC-426](#)
 Engine control circuit diagram [EC-82](#), [EC-468](#)
 Engine control component parts location [EC-77](#),
[EC-463](#)
 Engine control module (ECM) [EC-265](#), [EC-584](#)
 Engine control system diagram and chart [EC-21](#),
[EC-422](#)
 Engine coolant temperature sensor (ECTS) ... [EC-146](#),
[EC-513](#)
 Engine fail-safe system [EC-66](#), [EC-452](#)
 Engine oil precautions [GI-7](#)
 Engine serial number [GI-46](#)
 ETC1 - Wiring diagram [EC-279](#), [EC-594](#)
 ETC2 - Wiring diagram [EC-286](#), [EC-601](#)
 ETC3 - Wiring diagram [EC-290](#), [EC-605](#)
 EVAP canister purge volume control solenoid valve
[EC-257](#), [EC-405](#), [EC-692](#), [EC-731](#)
 EVAP vapor lines inspection(QG) [MA-22](#)
 EVAP vapor lines inspection(QR) [MA-22](#)
 Evaporative emission (EVAP) system [EC-405](#), [EC-731](#)
 Evaporator [MTC-66](#)
 Exhaust system inspection [EX-3](#), [MA-23](#)
 Expansion valve [MTC-67](#)

F

F/FOG - Wiring diagram [LT-50](#)
 F/PUMP - Wiring diagram [EC-392](#), [EC-718](#)
 Final drive (FF M/T) [MT-19](#)
 Floor trim [EI-23](#)
 Flow charts [GI-24](#)
 Fluid temperature sensor (A/T) [AT-122](#)
 Fluids [MA-12](#)
 Fluorescent leak detector [MTC-68](#)
 Flywheel (clutch) [CL-11](#)
 Freeze frame data [EC-43](#), [EC-441](#)
 FRO2 - Wiring diagram [EC-658](#), [EC-672](#)
 Front axle [FAX-6](#)
 Front bumper [EI-4](#)
 Front disc brake [BR-20](#)
 Front fog lamp [LT-48](#)
 Front passenger air bag [SRS-40](#)
 Front seat [SE-7](#)
 Front seat belt [SB-3](#)
 Front seat belt pre-tensioner [SB-2](#), [SB-3](#), [SRS-3](#)
 Front side air bag [SRS-42](#)
 Front suspension [FSU-5](#)

ALPHABETICAL INDEX

Front washer [WW-4](#), [WW-37](#)
 Front wiper [WW-4](#), [WW-37](#)
 FUEL - Wiring diagram [EC-190](#), [EC-197](#)
 Fuel check valve [EC-405](#), [EC-731](#)
 Fuel cut control (at no load high engine speed) [EC-27](#),
[EC-428](#)
 Fuel gauge [DI-5](#)
 Fuel injection system [EC-188](#), [EC-195](#)
 Fuel line inspection [FL-3](#)
 Fuel line inspection(QG) [MA-19](#)
 Fuel line inspection(QR) [MA-19](#)
 Fuel precautions [GI-5](#)
 Fuel pressure check [EC-36](#), [EC-437](#)
 Fuel pressure release [EC-36](#), [EC-437](#)
 Fuel pump [EC-391](#), [EC-717](#)
 Fuse [PG-17](#)
 Fuse and fusible link box [PG-88](#)
 Fusible link [PG-17](#)

G

Garage jack and safety stand [GI-37](#)
 Generator [SC-14](#)
 Generator - See Alternator [SC-14](#)
 Generic scan tool (GST) [EC-102](#)
 Grease [MA-12](#)
 Grille - See Exterior [EI-9](#)
 Ground distribution [PG-42](#)

H

H/AIM - Wiring diagram [LT-45](#)
 H/LAMP - Wiring diagram [LT-12](#)
 Harness connector [PG-81](#)
 Harness layout [PG-54](#)
 Hazard warning lamp [LT-67](#), [LT-103](#)
 Headlamp [LT-5](#)
 Headlamp aiming control [LT-45](#)
 Headlamp washer [WW-73](#)
 Headlining - See Roof trim [EI-25](#)
 Heated oxygen sensor 1 [EC-151](#), [EC-157](#), [EC-167](#),
[EC-294](#), [EC-300](#), [EC-518](#), [EC-524](#), [EC-671](#)
 Heated oxygen sensor 1 heater [EC-126](#), [EC-657](#)
 Heated oxygen sensor 2 [EC-174](#), [EC-180](#), [EC-306](#),
[EC-314](#), [EC-530](#), [EC-677](#)
 Heated oxygen sensor 2 heater [EC-131](#), [EC-662](#)
 Heated seat [SE-4](#)
 HEATER - Wiring diagram [MTC-21](#), [MTC-23](#)
 Heater system - Wiring diagram [MTC-21](#), [MTC-23](#)
 Heater unit (heater core) [MTC-44](#)
 Height (Dimensions) [GI-47](#)
 HFC134a (R134a) system precaution [MTC-3](#)
 HFC134a (R134a) system service procedure [MTC-56](#)
 HFC134a (R134a) system service tools [MTC-10](#)
 HFC134a system service equipment precaution [MTC-6](#)
 HLC - Wiring diagram [WW-74](#), [WW-77](#)
 HO2S1 - Wiring diagram [EC-153](#), [EC-160](#), [EC-170](#),
[EC-520](#), [EC-526](#)
 HO2S1H - Wiring diagram [EC-128](#)

HO2S2 - Wiring diagram [EC-176](#), [EC-183](#), [EC-309](#),
[EC-317](#), [EC-532](#)
 HO2S2H - Wiring diagram [EC-133](#)
 Horn [WW-77](#)
 HORN - Wiring diagram [WW-77](#)
 How to erase DTC for OBD system [EC-51](#), [EC-442](#)
 HSEAT - Wiring diagram [SE-5](#)

I

IATS - Wiring diagram [EC-143](#)
 IATSEN - Wiring diagram [EC-668](#)
 Identification [MTC-9](#)
 Identification plate [GI-46](#)
 Idle air volume learning [EC-34](#), [EC-435](#)
 Idle speed [EC-68](#), [EC-454](#)
 Ignition coil [EC-376](#), [EC-683](#)
 Ignition control system [EC-376](#), [EC-683](#)
 Ignition timing [EC-68](#), [EC-454](#)
 IGNSYS - Wiring diagram [EC-377](#), [EC-684](#)
 ILL - Wiring diagram [LT-132](#)
 Illumination [LT-129](#)
 INJECT - Wiring diagram [EC-386](#), [EC-712](#)
 Injector [EC-385](#), [EC-711](#)
 Instrument panel [IP-4](#)
 INT/L - Wiring diagram [LT-117](#)
 Intake air system [EC-322](#), [EC-609](#)
 Intake air temperature sensor [EC-141](#), [EC-667](#)
 Intake door control linkage adjustment [MTC-48](#)
 Intake valve timing control [EC-123](#), [EC-700](#)
 Intake valve timing control solenoid valve [EC-272](#),
[EC-700](#)
 Interior lamp [LT-114](#)
 IPDM (Intelligent power distribution module engine
 room) [PG-18](#)
 ISO 15031-2 Terminology [GI-48](#)
 ISO 15031-5 Mode 1 - 9 [EC-39](#), [EC-440](#)
 IVC - Wiring diagram [EC-273](#)
 IVC/V - Wiring diagram [EC-702](#)

K

Keyless entry system - See Multi-remote control system
[BL-110](#)
 Knock sensor (KS) [EC-237](#), [EC-566](#)
 Knuckle spindle [FAX-6](#)
 KS - Wiring diagram [EC-238](#), [EC-567](#)

L

Length (Dimensions) [GI-47](#)
 License lamp [LT-82](#)
 Line pressure solenoid valve [AT-157](#)
 Line pressure test (A/T) [AT-66](#), [AT-269](#)
 Location of electrical units [PG-78](#)
 Lubricant (R134a) A/C [MTC-4](#), [MTC-15](#), [MTC-71](#)
 Lubricants [MA-12](#)
 Lubrication circuit (engine)(QG) [LU-3](#)
 Lubrication oil A/C [MTC-71](#)

ALPHABETICAL INDEX

Lubrication-locks, hinges and hood latches [MA-28](#)
Luggage compartment trim [EI-27](#)

M

M/T oil replacement [MT-6](#)
Magnet clutch [MTC-27](#)
MAIN - Wiring diagram [EC-115](#), [EC-500](#)
Mainshaft (M/T) [MT-17](#), [MT-31](#), [MT-34](#)
Malfunction indicator (MI) [EC-52](#), [EC-443](#)
Manifold absolute pressure (MAP) sensor [EC-136](#), [EC-508](#)
Manual air conditioner - Wiring diagram [MTC-22](#)
Master cylinder (brake) [BR-14](#)
Meter [DI-5](#)
METER - Wiring diagram [DI-15](#)
Mirror, door [GW-62](#)
Mirror, out side [GW-62](#)
Misfire [EC-231](#)
Mode door control linkage adjustment [MTC-49](#)
Model variation [GI-43](#)
Molding - See Exterior [EI-13](#), [EI-14](#), [EI-16](#)
Multiport fuel injection (MFI) system [EC-23](#), [EC-424](#)
Multiport fuel injection precautions [GI-6](#)
Multi-remote control system [BL-110](#)

N

NATS - Wiring diagram [BL-204](#)
NATS (Nissan anti-theft system) precautions [GI-3](#)
NAVI - Wiring diagram [AV-16](#)
Navigation system [AV-15](#)
NVH troubleshooting (BR) [BR-5](#), [PB-2](#)
NVH troubleshooting (CL) [CL-4](#)
NVH troubleshooting (EM)(QG) [EM-8](#)
NVH troubleshooting (FAX) [FAX-5](#)
NVH troubleshooting (FSU) [FSU-4](#)
NVH troubleshooting (M/T) [MT-5](#)
NVH troubleshooting (RAX) [RAX-4](#)
NVH troubleshooting (RSU) [RSU-3](#)
NVH troubleshooting (ST) [PS-4](#)
NVH troubleshooting (WT) [WT-3](#)

O

On board diagnostic system [EC-39](#), [EC-440](#)
Out side mirror [GW-62](#)
Overdrive control switch [AT-247](#), [AT-354](#)
Overheat [EC-326](#), [EC-613](#)

P

Park/Neutral position switch [EC-364](#), [EC-706](#)
Park/neutral position switch (A/T) [AT-111](#)
Park/neutral position switch (M/T) [MT-8](#)
Parking brake control [PB-3](#)
Parking lamp [LT-82](#)
PCV (positive crankcase ventilation) . [EC-409](#), [EC-735](#)
PGC/V - Wiring diagram [EC-259](#)

PHASE - Wiring diagram [EC-248](#), [EC-579](#)
PNP/SW - Wiring diagram [EC-366](#)
PNPSW1 - Wiring diagram [EC-707](#)
POS - Wiring diagram [EC-242](#), [EC-572](#)
POWER - Wiring diagram [PG-5](#)
Power door lock [BL-14](#)
Power socket [WW-79](#)
Power steering gear [PS-9](#)
Power supply routing [PG-4](#)
Power window [GW-40](#), [GW-56](#), [GW-59](#)
Precations for Leak detection dye [MTC-9](#)
Precautions (General) [GI-4](#)
PRGVLV - Wirng diagram [EC-693](#)

R

R/FOG - Wiring diagram [LT-60](#)
Radiator(QG) [CO-16](#)
Radio - See Audio [AV-3](#)
Rain sensor [WW-37](#)
Rear axle [RAX-5](#)
Rear bumper [EI-7](#)
Rear drum brake [BR-26](#)
Rear fog lamp [LT-59](#), [LT-101](#)
Rear seat [SE-11](#)
Rear seat belt [SB-4](#)
Rear side window [GW-8](#)
Rear suspension [RSU-4](#)
Rear washer [WW-58](#)
Rear window defogger [GW-14](#)
Rear wiper [WW-58](#)
Refrigerant connection precaution [MTC-4](#)
Refrigerant general precaution [MTC-3](#)
Refrigerant lines [MTC-56](#)
Refrigerant pressure sensor [EC-396](#), [EC-722](#), [MTC-14](#), [MTC-64](#)
Refrigeration cycle [MTC-14](#)
Removal and installation (A/T) [AT-423](#)
Reverse lamp switch (M/T) - See Back-up lamp switch (M/T) [MT-8](#)
Road wheel size [GI-47](#)
Roof trim [EI-25](#)
RP/SEN - Wiring diagram [EC-397](#), [EC-723](#)
RRO2 - Wiring diagram [EC-663](#), [EC-678](#)

S

S/LOCK - Wiring diagram [BL-23](#), [BL-29](#), [BL-68](#), [BL-75](#)
Seat belt inspection [SB-4](#), [MA-28](#)
Seat belt pre-tensioner [SB-3](#)
Seat belt pre-tensioner disposal [SRS-49](#)
Seat belt, front [SB-3](#)
Seat belt, rear [SB-4](#)
Seat, front [SE-7](#)
Seat, rear [SE-11](#)
SEN/PW - Wiring diagram [EC-361](#), [EC-648](#)
Sheft warning system [BL-200](#)
SHIFT - Wiring diagram [AT-412](#)
Shift control components (M/T) [MT-18](#)

ALPHABETICAL INDEX

Shift fork (M/T) [MT-36](#)
Shift lock system [AT-411](#)
Shift schedule [AT-527](#)
Shift solenoid valve A (A/T) .. [AT-132](#), [AT-137](#), [AT-149](#)
Shift solenoid valve B (A/T) [AT-132](#), [AT-137](#)
Shock absorber (front) [FSU-8](#)
Shock absorber (rear) [RSU-6](#)
Side air bag [SRS-42](#), [SRS-43](#)
Side air bag (satellite) sensor [SRS-46](#)
Side curtain air bag [SRS-43](#)
Side trim [EI-20](#)
Side window - See Rear side window [GW-8](#)
SMJ (super multiple junction) [PG-84](#)
Spare tire size [GI-47](#)
Specification value [EC-109](#), [EC-494](#)
Speedometer [DI-5](#)
Spiral cable [SRS-38](#)
SROOF - Wiring diagram [RF-4](#)
SRS - See Supplemental Restraint System [SRS-6](#)
SRS - Wiring diagram [SRS-11](#), [SRS-12](#)
SRS Trouble diagnoses [SRS-8](#)
Stabilizer bar (front) [FSU-11](#)
Stall test (A/T) [AT-63](#), [AT-266](#)
Standardized relay [PG-85](#)
START - Wiring diagram [SC-28](#)
Starter [SC-27](#)
Starting system [SC-27](#)
Steering gear and linkage inspection [MA-27](#)
Steering linkage [PS-9](#)
Steering wheel and column [PS-5](#), [PS-7](#)
Steering wheel play [PS-5](#)
Steering wheel turning force [PS-5](#)
Stop lamp [LT-96](#), [LT-101](#)
Stop lamp switch [EC-370](#), [EC-651](#)
STOP/L - Wiring diagram [LT-96](#)
Striking rod (M/T) [MT-36](#)
Sunroof [RF-2](#)
Super lock [BL-60](#)
Supplemental Restraint System [SRS-6](#)
Supplemental restraint system - Wiring diagram
[SRS-11](#), [SRS-12](#)
Suspension [MA-27](#)
Symbols and abbreviations [GI-10](#), [GI-22](#)
Symptom matrix chart [EC-72](#), [EC-458](#)
Synchronizer (M/T) [MT-34](#)
SYSTEM [BRC-4](#)
System readiness test (SRT) code [EC-43](#)

T

Tachometer [DI-5](#)
Tail lamp [LT-82](#), [LT-101](#)
TAIL/L - Wiring diagram [LT-85](#)
TCM circuit diagram [AT-14](#)
TCM inspection table [AT-105](#), [AT-308](#)
THEFT - Wiring diagram [BL-200](#)
Thermo control amp [MTC-51](#)
Three way catalyst function [EC-253](#)
Three way catalyst precautions [GI-5](#)

Throttle control motor relay [EC-284](#), [EC-599](#)
Throttle position sensor (TPS) [EC-201](#), [EC-207](#),
[EC-341](#), [EC-347](#), [EC-349](#), [EC-536](#), [EC-542](#), [EC-628](#),
[EC-634](#), [EC-636](#)
Tie-rod [PS-9](#)
Tie-rod ball joints [PS-9](#)
Tightening torque of standard bolts [GI-42](#)
Tire size [GI-47](#)
Torque converter installation [AT-424](#), [AT-520](#)
Tow truck towing [GI-40](#)
TPS1 - Wiring diagram [EC-209](#), [EC-544](#)
TPS2 - Wiring diagram [EC-343](#), [EC-630](#)
TPS3 - Wiring diagram [EC-203](#), [EC-538](#)
Transmission case (M/T) [MT-15](#)
Tread-FR&RR (Dimensions) [GI-47](#)
Trouble diagnoses [GI-10](#)
Turbocharger precautions [GI-6](#)
TURN - Wiring diagram [LT-70](#)
Turn signal lamp [LT-67](#), [LT-101](#)
Two trip detection logic [EC-39](#), [EC-440](#)
Two-pole lift [GI-38](#)

V

Vacuum hose (brake system) [BR-19](#)
Vacuum hose drawing (Engine control) [EC-22](#), [EC-423](#)
Vehicle identification number [GI-45](#)
Vehicle recovery (freeing a stuck vehicle) [GI-41](#)
Vehicle speed sensor (VSS) [EC-263](#), [EC-699](#)
Viscosity number (SAE) [MA-13](#)

W

WARN - Wiring diagram [DI-49](#)
Warning chime [DI-58](#)
Warning lamps [DI-48](#)
Water temperature (High) warning lamp [DI-5](#)
Water temperature (Low) indicator lamp [DI-5](#)
Wheel alignment (front) [FSU-6](#)
Wheel alignment (rear) [RSU-5](#)
Wheel bearing (front) [FAX-6](#)
Wheel bearing (rear) [RAX-5](#)
Wheel hub (front) [FAX-6](#)
Wheel hub (rear) [RAX-5](#)
Wheel sensors (ABS) [BRC-36](#)
Wheel size [GI-47](#)
Wheelbase (Dimensions) [GI-47](#)
Width (Dimensions) [GI-47](#)
WINDOW - Wiring diagram [GW-43](#)
Window antenna [AV-13](#)
Window, back [GW-10](#)
Window, back door [GW-10](#)
Window, door [GW-56](#), [GW-59](#)
Window, rear side [GW-8](#)
Window, side - See Rear side window [GW-8](#)
Windshield [GW-4](#)
WIP/R - Wiring diagram [WW-62](#)
WIPER - Wiring diagram [WW-15](#)
Wiring Diagram (Cell code) list [PG-75](#)

ALPHABETICAL INDEX

Wiring diagrams [GI-14](#)

A

B

C

D

E

F

G

H

I

J

K

L

IDX