

SECTION **IDX**
ALPHABETICAL INDEX

A
B
C
D
E
F
G
H
I
J
K
L

ALPHABETICAL INDEX

A

A/C - Wiring diagram [MTC-24](#), [MTC-26](#)
 A/C component layout [MTC-62](#)
 A/C compressor clutch removal and installation
[MTC-64](#)
 A/C compressor precaution [ATC-6](#), [MTC-6](#)
 A/C compressor special service tool [MTC-10](#)
 A/C HFC134a (R134a) system precaution [ATC-3](#),
[MTC-3](#)
 A/C HFC134a (R134a) system service tools .. [MTC-10](#)
 A/C HFC134a system service equipment precaution ...
[ATC-6](#), [MTC-6](#)
 A/C lubricant (R134a) [MTC-79](#)
 A/C service data specification [MTC-79](#)
 A/C trouble diagnoses (manual A/C) [MTC-17](#)
 A/C, M - Wiring diagram [MTC-24](#), [MTC-26](#)
 A/T fluid checking [AT-12](#), [MA-37](#)
 A/T fluid replacement [AT-12](#), [MA-37](#)
 A/T fluid temperature sensor [AT-125](#)
 A/T shift lock system [AT-418](#)
 A/T shift lock system - Wiring diagram [AT-419](#)
 A/T trouble diagnoses [AT-54](#), [AT-262](#)
 A/T Wiring diagram AT - 1ST [AT-138](#)
 A/T Wiring diagram AT - 2ND [AT-144](#)
 A/T Wiring diagram AT - 3RD [AT-150](#)
 A/T Wiring diagram AT - 4TH [AT-156](#)
 A/T Wiring diagram AT - BA/FTS [AT-198](#), [AT-397](#)
 A/T Wiring diagram AT - CAN [AT-413](#)
 A/T Wiring diagram AT - ENG SS [AT-132](#), [AT-402](#)
 A/T Wiring diagram AT - FTS [AT-122](#)
 A/T Wiring diagram AT - LPSV [AT-168](#), [AT-407](#)
 A/T Wiring diagram AT - MAIN [AT-415](#)
 A/T Wiring diagram AT - OVRCSV [AT-190](#), [AT-387](#)
 A/T Wiring diagram AT - PNP/SW [AT-116](#)
 A/T Wiring diagram AT - SSV/A [AT-175](#), [AT-378](#)
 A/T Wiring diagram AT - SSV/B [AT-180](#), [AT-383](#)
 A/T Wiring diagram AT - TCV [AT-163](#), [AT-392](#)
 A/T Wiring diagram AT - TPS [AT-185](#), [AT-373](#)
 A/T Wiring diagram AT - VSS A/T [AT-128](#), [AT-364](#)
 A/T Wiring diagram AT - VSSMTR [AT-204](#), [AT-369](#)
 A/WIP - Wiring diagram [WW-68](#)
 ABS - Wiring diagram [BRC-13](#), [BRC-16](#)
 ABS input/output signal inspection [BRC-19](#)
 ABS sensor rotor [RAX-5](#)
 Accelerator pedal position (APP) sensor [EC-233](#),
[EC-242](#), [EC-376](#), [EC-402](#), [EC-411](#), [EC-426](#), [EC-621](#),
[EC-630](#), [EC-713](#), [EC-733](#), [EC-742](#), [EC-757](#)
 Accelerator pedal released position learning [EC-42](#),
[EC-503](#)
 Air bag [SRS-3](#), [SRS-36](#), [SRS-40](#), [SRS-41](#), [SRS-43](#)
 Air bag disposal [SRS-49](#)
 Air bleeding (hydraulic clutch) [CL-7](#)
 Air bleeding for brake system [BR-10](#)
 Air cleaner and air duct [EM-123](#)
 Air cleaner filter [EM-124](#)
 Air cleaner filter replacement [MA-33](#)
 Air conditioner - Wiring diagram [MTC-24](#), [MTC-26](#)
 Air conditioner cut control [EC-27](#), [EC-487](#)

Air mix door control linkage adjustment [MTC-55](#)
 Alternator [SC-15](#)
 Angular tightening application [EM-105](#)
 Antenna [AV-15](#)
 AP/SEN - Wiring diagram .. [EC-149](#), [EC-347](#), [EC-576](#),
[EC-684](#)
 APPS1 - Wiring diagram [EC-244](#), [EC-404](#), [EC-632](#),
[EC-735](#)
 APPS2 - Wiring diagram [EC-378](#), [EC-413](#), [EC-715](#),
[EC-744](#)
 APPS3 - Wiring diagram [EC-235](#), [EC-428](#), [EC-623](#),
[EC-759](#)
 Audio [AV-3](#)
 AUDIO - Wiring diagram [AV-4](#)
 Auto wiper [WW-48](#)
 Automatic transaxle number [GI-48](#)
 Automatic transmission fluid replacement [MA-37](#)
 Axle [MA-40](#)

B

Back door trim [EI-18](#)
 Back door window [GW-10](#)
 Back window [GW-10](#)
 BACK/L - Wiring diagram [LT-183](#)
 Back-up lamp [LT-183](#), [LT-186](#)
 Basic inspection [EC-77](#), [EC-522](#)
 Battery [SC-5](#)
 BCM (Body control module) [BCS-3](#)
 Blower motor [MTC-29](#), [MTC-50](#)
 Blower resistor [MTC-51](#)
 Board computer [DI-37](#)
 Board-on lift [GI-40](#)
 Bose speaker amp. [AV-3](#)
 Brake booster [BR-17](#)
 Brake fluid change [BR-9](#)
 Brake fluid level [MA-38](#)
 Brake fluid level and line check [BR-9](#)
 Brake hydraulic line [BR-11](#)
 Brake inspection [MA-39](#)
 Brake lines and cables inspection [MA-38](#)
 Brake master cylinder [BR-14](#)
 Brake pedal [BR-6](#)
 Brake switch [EC-395](#), [EC-726](#)
 BRK/SW - Wiring diagram [EC-397](#), [EC-728](#)
 Bulb specifications [LT-255](#)
 Bumper, front [EI-4](#)
 Bumper, rear [EI-6](#)

C

Camshaft inspection [EM-195](#)
 Camshaft position sensor (PHASE) .. [EC-267](#), [EC-650](#)
 CAN - Wiring diagram [EC-131](#), [EC-573](#), [LAN-21](#),
[LAN-53](#), [LAN-83](#), [LAN-113](#), [LAN-141](#), [LAN-173](#),
[LAN-203](#), [LAN-233](#), [LAN-261](#), [LAN-291](#)
 CAN (Controller Area Network) [BRC-54](#), [LAN-6](#),
[LAN-20](#), [LAN-52](#), [LAN-82](#), [LAN-112](#), [LAN-140](#),
[LAN-172](#), [LAN-202](#), [LAN-232](#), [LAN-260](#), [LAN-290](#)

ALPHABETICAL INDEX

CAN communication [EC-29](#), [EC-130](#), [EC-489](#), [EC-572](#),
[AT-107](#), [AT-314](#), [AT-412](#), [BRC-54](#), [LAN-6](#), [LAN-20](#),
[LAN-52](#), [LAN-82](#), [LAN-112](#), [LAN-140](#), [LAN-172](#),
[LAN-202](#), [LAN-232](#), [LAN-260](#), [LAN-290](#)
Canister-See EVAP canister [EC-467](#), [EC-843](#)
CD/CHG - Wiring diagram [AV-4](#)
CHARGE - Wiring diagram [SC-16](#), [SC-17](#)
Charging system [SC-15](#)
Chassis and body maintenance [MA-36](#)
CIGAR - Wiring diagram [WW-116](#)
Circuit breaker [PG-17](#)
Closed loop control [EC-25](#), [EC-485](#)
Clutch cover [CL-10](#), [CL-12](#)
Clutch disc [CL-10](#)
Clutch master cylinder [CL-8](#)
Clutch pedal [CL-5](#)
Coil spring (front) [FSU-8](#)
Coil spring (rear) [RSU-8](#)
Collision diagnosis [SRS-56](#)
Combination meter [DI-5](#)
Combination switch [LT-187](#)
COMBSW - Wiring diagram [LT-192](#)
COMM - Wiring diagram [DI-57](#)
Component Location (manual A/C) [MTC-20](#)
Compressor clutch removal and installation ... [MTC-64](#)
Compressor precaution [ATC-6](#), [MTC-6](#)
Compressor special service tool [MTC-10](#)
Condenser [MTC-71](#), [MTC-72](#)
Connecting rod [EM-197](#)
CONSULT for ABS [BRC-20](#)
CONSULT for engine [EC-101](#), [EC-546](#)
CONSULT for VDC [BRC-74](#)
CONSULT general information [GI-34](#)
Control unit [MTC-43](#)
Control units (terminal arrangement) [PG-102](#)
Controller Area Network (CAN) [BRC-54](#), [LAN-6](#),
[LAN-20](#), [LAN-52](#), [LAN-82](#), [LAN-112](#), [LAN-140](#),
[LAN-172](#), [LAN-202](#), [LAN-232](#), [LAN-260](#), [LAN-290](#)
Converter housing installation [AT-431](#), [AT-527](#)
COOL/F - Wiring diagram [EC-356](#), [EC-693](#)
Coolant mixture ratio [MA-20](#)
Coolant replacement [MA-30](#)
Cooling circuit (engine)(QG) [CO-7](#)
Cooling fan [CO-36](#)
Cooling fan motor [EC-365](#), [EC-702](#)
Cowl top [EI-10](#)
Crankcase ventilation system - See Positive crankcase
ventilation [EC-468](#), [EC-844](#)
Crankshaft [EM-198](#)
Crankshaft position sensor (POS) [EC-261](#), [EC-643](#)
Cylinder block [EM-199](#)
Cylinder head [EM-144](#)
Cylinder head bolt tightening [EM-145](#), [EM-191](#)

D

Data link connector [EC-462](#), [EC-838](#)
Data link connector for Consult [EC-104](#), [EC-548](#)
Daytime light system [LT-42](#)

Diagnosis sensor unit [SRS-48](#)
Diagnostic trouble code (DTC) for OBD system [EC-11](#),
[EC-50](#), [EC-472](#), [EC-508](#)
Diagnostic trouble code (DTC) inspection priority chart
[EC-73](#), [EC-519](#)
Dimensions [GI-48](#)
Door glass [GW-4](#), [GW-69](#), [GW-72](#)
Door mirror [GW-75](#)
Door trim [EI-16](#)
Drive belt [EM-121](#)
Drive belt inspection [MA-30](#)
Drive computer [DI-36](#), [DI-57](#)
Drive shaft (front) [FAX-10](#)
Driver air bag [SRS-36](#)
Dropping resistor (A/T) [AT-172](#), [AT-411](#)
DTC work support [EC-110](#)
DTRL - Wiring diagram [LT-59](#)
Duct and grilles [MTC-57](#)

E

ECM input/output signal [EC-94](#), [EC-539](#)
ECM power supply [EC-125](#), [EC-289](#), [EC-567](#), [EC-660](#)
ECM/PW - Wiring diagram [EC-290](#), [EC-661](#)
ECTS - Wiring diagram [EC-160](#), [EC-582](#)
Electric throttle control actuator [EC-297](#), [EC-299](#),
[EC-310](#), [EC-664](#), [EC-667](#), [EC-678](#)
Electrical diagnoses [GI-10](#)
Electrical load signal circuit [EC-460](#), [EC-836](#)
Electrical unit [PG-102](#)
Electrical units location [PG-95](#)
Electronic ignition (EI) system [EC-26](#), [EC-486](#)
Engine control circuit diagram [EC-92](#), [EC-537](#)
Engine control component parts location [EC-87](#),
[EC-532](#)
Engine control module (ECM) [EC-286](#), [EC-657](#)
Engine control system diagram and chart [EC-22](#),
[EC-482](#)
Engine coolant [CO-31](#)
Engine coolant temperature sensor (ECTS) ... [EC-158](#),
[EC-580](#)
Engine fail-safe system [EC-75](#), [EC-520](#)
Engine oil [LU-12](#)
Engine oil filter replacement [MA-35](#)
Engine oil precautions [GI-7](#)
Engine oil replacement [MA-34](#)
Engine removal [EM-147](#)
Engine room cover [EM-119](#)
Engine serial number [GI-47](#)
ETC1 - Wiring diagram [EC-300](#), [EC-668](#)
ETC2 - Wiring diagram [EC-307](#), [EC-675](#)
ETC3 - Wiring diagram [EC-311](#), [EC-679](#)
EVAP canister [EC-467](#), [EC-843](#)
EVAP canister purge volume control solenoid valve
[EC-278](#), [EC-464](#), [EC-801](#), [EC-840](#)
EVAP vapor lines inspection(QG) [MA-29](#)
EVAP vapor lines inspection(QR) [MA-29](#)
Evaporative emission (EVAP) system [EC-464](#), [EC-840](#)
Evaporator [MTC-74](#)

ALPHABETICAL INDEX

Exhaust manifold [EM-129](#)
 Exhaust system inspection [EX-3](#), [MA-36](#)
 Expansion valve [MTC-75](#)

F

F/FOG - Wiring diagram [LT-89](#)
 F/PUMP - Wiring diagram [EC-451](#), [EC-827](#)
 Floor trim [EI-22](#)
 Flow charts [GI-24](#)
 Fluid temperature sensor (A/T) [AT-125](#)
 Fluids [MA-18](#)
 Fluorescent leak detector [MTC-76](#)
 Flywheel (clutch) [CL-12](#)
 Freeze frame data [EC-51](#), [EC-509](#)
 FRO2 - Wiring diagram [EC-767](#), [EC-781](#)
 Front axle [FAX-6](#)
 Front bumper [EI-4](#)
 Front disc brake [BR-21](#)
 Front fog lamp [LT-74](#)
 Front passenger air bag [SRS-40](#)
 Front seat [SE-7](#)
 Front seat belt [SB-3](#)
 Front seat belt pre-tensioner [SB-2](#), [SB-3](#), [SRS-3](#)
 Front side air bag [SRS-41](#)
 Front suspension [FSU-5](#)
 Front washer [WW-5](#), [WW-48](#)
 Front wiper [WW-5](#), [WW-48](#)
 FUEL - Wiring diagram [EC-210](#), [EC-217](#)
 Fuel check valve [EC-464](#), [EC-840](#)
 Fuel cut control (at no load high engine speed) [EC-28](#),
[EC-488](#)
 Fuel filter replacement [FL-14](#)
 Fuel gauge [FL-17](#), [DI-5](#)
 Fuel injection system [EC-208](#), [EC-215](#)
 Fuel line inspection [FL-3](#), [MA-33](#)
 Fuel line inspection(QG) [MA-26](#)
 Fuel line inspection(QR) [MA-26](#)
 Fuel precautions [GI-5](#)
 Fuel pressure check [EC-44](#), [EC-505](#)
 Fuel pressure release [EC-44](#), [EC-505](#)
 Fuel pump [EC-450](#), [EC-826](#)
 Fuel system [FL-13](#)
 Fuel tank [FL-19](#)
 Fuse [PG-17](#)
 Fuse and fusible link box [PG-107](#)
 Fusible link [PG-17](#)

G

Garage jack and safety stand [GI-38](#)
 Generator [SC-15](#)
 Generator - See Alternator [SC-15](#)
 Generic scan tool (GST) [EC-112](#)
 Glow plug [EM-136](#)
 Grease [MA-18](#)
 Grille - See Exterior [EI-8](#)
 Ground distribution [PG-54](#)

H

H/AIM - Wiring diagram [LT-71](#)
 H/LAMP - Wiring diagram [LT-22](#)
 Harness connector [PG-99](#)
 Harness layout [PG-67](#)
 Hazard warning lamp [LT-121](#), [LT-188](#)
 Headlamp [LT-6](#)
 Headlamp aiming control [LT-71](#)
 Headlamp washer [WW-110](#)
 Headlining - See Roof trim [EI-24](#)
 Heated oxygen sensor 1 [EC-169](#), [EC-175](#), [EC-185](#),
[EC-315](#), [EC-321](#), [EC-591](#), [EC-597](#), [EC-780](#)
 Heated oxygen sensor 1 heater [EC-136](#), [EC-766](#)
 Heated oxygen sensor 2 [EC-192](#), [EC-199](#), [EC-327](#),
[EC-337](#), [EC-603](#), [EC-786](#)
 Heated oxygen sensor 2 heater [EC-142](#), [EC-771](#)
 Heated seat [SE-4](#)
 HEATER - Wiring diagram [MTC-22](#)
 Heater system - Wiring diagram [MTC-22](#)
 Heater unit (heater core) [MTC-49](#)
 Height (Dimensions) [GI-48](#)
 HFC134a (R134a) system precaution . [ATC-3](#), [MTC-3](#)
 HFC134a (R134a) system service procedure . [MTC-61](#)
 HFC134a (R134a) system service tools [MTC-10](#)
 HFC134a system service equipment precaution
[ATC-6](#), [MTC-6](#)
 HLC - Wiring diagram [WW-111](#), [WW-114](#)
 HO2S1 - Wiring diagram [EC-171](#), [EC-178](#), [EC-188](#),
[EC-593](#), [EC-599](#)
 HO2S1H - Wiring diagram [EC-138](#)
 HO2S2 - Wiring diagram [EC-194](#), [EC-202](#), [EC-331](#),
[EC-340](#), [EC-605](#)
 HO2S2H - Wiring diagram [EC-144](#)
 Horn [WW-114](#)
 HORN - Wiring diagram [WW-114](#)
 How to erase DTC for OBD system [EC-59](#), [EC-510](#)
 HSEAT - Wiring diagram [SE-5](#)

I

IATS - Wiring diagram [EC-155](#)
 IATSEN - Wiring diagram [EC-777](#)
 Identification [ATC-9](#), [MTC-9](#)
 Identification plate [GI-47](#)
 Idle air volume learning [EC-42](#), [EC-503](#)
 Idle speed [EC-77](#), [EC-522](#)
 Ignition coil [EC-435](#), [EC-792](#)
 Ignition control system [EC-435](#), [EC-792](#)
 Ignition timing [EC-77](#), [EC-522](#)
 IGNSYS - Wiring diagram [EC-436](#), [EC-793](#)
 ILL - Wiring diagram [LT-247](#)
 Illumination [LT-230](#)
 INJECT - Wiring diagram [EC-445](#), [EC-821](#)
 Injector [EC-444](#), [EC-820](#)
 Instrument panel [IP-4](#)
 INT/L - Wiring diagram [LT-217](#)
 Intake air system [EC-346](#), [EC-683](#)
 Intake air temperature sensor [EC-153](#), [EC-776](#)

ALPHABETICAL INDEX

Intake door control linkage adjustment [MTC-53](#)
 Intake valve timing control [EC-133](#), [EC-809](#)
 Intake valve timing control solenoid valve [EC-293](#),
[EC-809](#)
 Interior lamp [LT-200](#)
 IPDM (Intelligent power distribution module engine
 room) [PG-18](#)
 ISO 15031-2 Terminology [GI-49](#)
 ISO 15031-5 Mode 1 - 9 [EC-47](#)
 IVC - Wiring diagram [EC-294](#)
 IVC/V - Wiring diagram [EC-811](#)

K

Keyless entry system - See Multi-remote control system
[BL-131](#)
 Knock sensor (KS) [EC-257](#), [EC-639](#)
 Knuckle spindle [FAX-6](#)
 KS - Wiring diagram [EC-258](#), [EC-640](#)

L

Length (Dimensions) [GI-48](#)
 License lamp [LT-152](#)
 Line pressure solenoid valve [AT-160](#)
 Line pressure test (A/T) [AT-65](#), [AT-272](#)
 Liquid gasket application [EM-106](#)
 Location of electrical units [PG-95](#)
 Lubricant (R134a) A/C [ATC-4](#), [MTC-4](#), [MTC-15](#),
[MTC-79](#)
 Lubricants [MA-18](#)
 Lubrication circuit (engine)(QG) [LU-3](#)
 Lubrication oil A/C [MTC-79](#)
 Lubrication-locks, hinges and hood latches [MA-41](#)
 Luggage compartment trim [EI-26](#)

M

Magnet clutch [MTC-31](#)
 MAIN - Wiring diagram [EC-125](#), [EC-567](#)
 Malfunction indicator (MI) [EC-60](#), [EC-511](#)
 Manifold absolute pressure (MAP) sensor [EC-148](#),
[EC-575](#)
 Manual air conditioner - Wiring diagram [MTC-24](#),
[MTC-26](#)
 Master cylinder (brake) [BR-14](#)
 Meter [DI-5](#)
 MIL/DL - Wiring diagram [EC-462](#), [EC-838](#)
 Mirror, door [GW-75](#)
 Mirror, out side [GW-75](#)
 Misfire [EC-251](#)
 Mode door control linkage adjustment [MTC-54](#)
 Model variation [GI-44](#)
 Molding - See Exterior [EI-12](#), [EI-13](#), [EI-15](#)
 Multiport fuel injection (MFI) system [EC-24](#), [EC-484](#)
 Multiport fuel injection precautions [GI-6](#)
 Multi-remote control system [BL-131](#)

N

NATS - Wiring diagram [BL-226](#)
 NATS (Nissan anti-theft system) precautions [GI-3](#)
 NAVI - Wiring diagram [AV-18](#)
 Navigation system [AV-17](#)
 NVH troubleshooting (BR) [BR-5](#), [PB-2](#)
 NVH troubleshooting (RSU) [RSU-3](#)
 NVH troubleshooting (ST) [PS-4](#)

O

Oil cooler (engine) [LU-16](#)
 Oil filter [LU-14](#)
 Oil pan (engine) [EM-133](#)
 Oil pressure (engine) [LU-12](#)
 Oil pump (engine) [LU-15](#)
 On board diagnostic system [EC-47](#), [EC-508](#)
 Out side mirror [GW-75](#)
 Overdrive control switch [AT-250](#), [AT-361](#)
 Overheat [EC-352](#), [EC-689](#)

P

Park/Neutral position switch [EC-389](#), [EC-815](#)
 Park/neutral position switch (A/T) [AT-114](#)
 Parking brake control [PB-3](#)
 Parking lamp [LT-152](#)
 PCV (positive crankcase ventilation) . [EC-468](#), [EC-844](#)
 PGC/V - Wiring diagram [EC-280](#)
 PHASE - Wiring diagram [EC-268](#), [EC-652](#)
 Piston assembly [EM-196](#)
 Piston pin inspection [EM-196](#)
 Piston ring inspection [EM-197](#)
 PNP/SW - Wiring diagram [EC-391](#)
 PNPSW1 - Wiring diagram [EC-816](#)
 POS - Wiring diagram [EC-262](#), [EC-645](#)
 POWER - Wiring diagram [PG-5](#)
 Power door lock [BL-15](#)
 Power socket [WW-116](#)
 Power steering gear [PS-9](#)
 Power supply routing [PG-4](#)
 Power window [GW-52](#), [GW-69](#), [GW-72](#)
 Precations for Leak detection dye [ATC-9](#), [MTC-9](#)
 Precautions (General) [GI-4](#)
 PRGVLV - Wirng diagram [EC-802](#)

R

R/FOG - Wiring diagram [LT-115](#)
 Radiator [CO-34](#)
 Radiator fan - See Cooling fan [CO-36](#)
 Radiator(QG) [CO-17](#)
 Radio - See Audio [AV-3](#)
 Rain sensor [WW-48](#)
 Rear axle [RAX-5](#)
 Rear bumper [EI-6](#)
 Rear drum brake [BR-27](#)
 Rear fog lamp [LT-100](#), [LT-186](#)

ALPHABETICAL INDEX

Rear seat [SE-11](#)
 Rear seat belt [SB-4](#)
 Rear side window [GW-8](#)
 Rear suspension [RSU-4](#)
 Rear washer [WW-82](#)
 Rear window defogger [GW-14](#)
 Rear wiper [WW-82](#)
 Refrigerant connection precaution [ATC-4](#), [MTC-4](#)
 Refrigerant general precaution [ATC-3](#), [MTC-3](#)
 Refrigerant lines [MTC-61](#)
 Refrigerant pressure sensor [EC-455](#), [EC-831](#), [MTC-14](#),
[MTC-71](#)
 Refrigeration cycle [MTC-14](#)
 Removal and installation (A/T) [AT-430](#)
 Road wheel size [GI-48](#)
 Rocker cover [EM-138](#)
 Roof trim [EI-24](#)
 RP/SEN - Wiring diagram [EC-456](#), [EC-832](#)
 RRO2 - Wiring diagram [EC-772](#), [EC-787](#)

S

S/LOCK - Wiring diagram [BL-33](#), [BL-39](#), [BL-87](#), [BL-94](#)
 Seat belt inspection [SB-4](#), [MA-41](#)
 Seat belt pre-tensioner [SB-3](#)
 Seat belt pre-tensioner disposal [SRS-49](#)
 Seat belt, front [SB-3](#)
 Seat belt, rear [SB-4](#)
 Seat, front [SE-7](#)
 Seat, rear [SE-11](#)
 SEN/PW - Wiring diagram [EC-386](#), [EC-723](#)
 Sheft warning system [BL-222](#)
 SHIFT - Wiring diagram [AT-419](#)
 Shift lock system [AT-418](#)
 Shift schedule [AT-534](#)
 Shift solenoid valve A (A/T) .. [AT-135](#), [AT-140](#), [AT-152](#)
 Shift solenoid valve B (A/T) [AT-135](#), [AT-140](#)
 Shock absorber (front) [FSU-8](#)
 Shock absorber (rear) [RSU-6](#)
 Side air bag [SRS-41](#), [SRS-43](#)
 Side air bag (satellite) sensor [SRS-46](#)
 Side curtain air bag [SRS-43](#)
 Side trim [EI-19](#)
 Side window - See Rear side window [GW-8](#)
 SMJ (super multiple junction) [PG-103](#)
 Spare tire size [GI-48](#)
 Specification value [EC-119](#), [EC-561](#)
 Speedometer [DI-5](#)
 Spiral cable [SRS-38](#)
 SROOF - Wiring diagram [RF-4](#)
 SRS - See Supplemental Restraint System [SRS-6](#)
 SRS - Wiring diagram [SRS-11](#), [SRS-12](#)
 SRS Trouble diagnoses [SRS-8](#)
 Stabilizer bar (front) [FSU-11](#)
 Stall test (A/T) [AT-62](#), [AT-269](#)
 Standardized relay [PG-104](#)
 START - Wiring diagram [SC-40](#), [SC-42](#)
 Starter [SC-39](#)
 Starting system [SC-39](#)

Steering gear and linkage inspection [MA-40](#)
 Steering linkage [PS-9](#)
 Steering wheel and column [PS-5](#), [PS-7](#)
 Steering wheel play [PS-5](#)
 Steering wheel turning force [PS-5](#)
 Stop lamp [LT-181](#), [LT-186](#)
 Stop lamp switch [EC-395](#), [EC-726](#)
 STOP/L - Wiring diagram [LT-181](#)
 Sunroof [RF-2](#)
 Super lock [BL-70](#)
 Supplemental Restraint System [SRS-6](#)
 Supplemental restraint system - Wiring diagram
[SRS-11](#), [SRS-12](#)
 Suspension [MA-40](#)
 Symbols and abbreviations [GI-10](#), [GI-22](#)
 Symptom matrix chart [EC-82](#), [EC-527](#)
 SYSTEM [BRC-6](#)
 System readiness test (SRT) code [EC-51](#)

T

Tachometer [DI-5](#)
 Tail lamp [LT-152](#), [LT-186](#)
 TAIL/L - Wiring diagram [LT-169](#)
 TCM circuit diagram [AT-14](#)
 TCM inspection table [AT-104](#), [AT-311](#)
 THEFT - Wiring diagram [BL-222](#)
 Thermo control amp [MTC-56](#)
 Three way catalyst function [EC-273](#)
 Three way catalyst precautions [GI-5](#)
 Throttle control motor relay [EC-305](#), [EC-673](#)
 Throttle position sensor (TPS) [EC-163](#), [EC-221](#),
[EC-227](#), [EC-366](#), [EC-372](#), [EC-374](#), [EC-420](#), [EC-585](#),
[EC-609](#), [EC-615](#), [EC-703](#), [EC-709](#), [EC-711](#), [EC-751](#)
 Throttle valve closed position learning [EC-42](#), [EC-503](#)
 Tie-rod [PS-9](#)
 Tie-rod ball joints [PS-9](#)
 Tightening torque of standard bolts [GI-43](#)
 Timing belt [EM-140](#)
 Tire size [GI-48](#)
 Torque converter installation [AT-431](#), [AT-527](#)
 Tow truck towing [GI-41](#)
 TPS1 - Wiring diagram [EC-229](#), [EC-617](#)
 TPS2 - Wiring diagram [EC-165](#), [EC-368](#), [EC-587](#),
[EC-705](#)
 TPS3 - Wiring diagram [EC-223](#), [EC-422](#), [EC-611](#),
[EC-753](#)
 Tread-FR&RR (Dimensions) [GI-48](#)
 Trouble diagnoses [GI-10](#)
 Turbocharger [EM-129](#)
 Turbocharger precautions [GI-6](#)
 TURN - Wiring diagram [LT-138](#)
 Turn signal lamp [LT-121](#), [LT-186](#)
 Two trip detection logic [EC-47](#), [EC-508](#)
 Two-pole lift [GI-39](#)

V

Vacuum hose (brake system) [BR-19](#)

ALPHABETICAL INDEX

Vacuum hose drawing (Engine control) [EC-23](#), [EC-483](#)
Vacuum pump [EM-137](#)
Valve clearance [EM-161](#), [EM-194](#)
Valve guide [EM-192](#)
Valve seat [EM-192](#)
Valve spring [EM-194](#)
VDC -Wiring diagram [BRC-66](#)
Vehicle identification number [GI-46](#)
Vehicle recovery (freeing a stuck vehicle) [GI-42](#)
Vehicle speed sensor (VSS) [EC-284](#), [EC-808](#)
Viscosity number (SAE) [MA-19](#)

W

WARN - Wiring diagram [DI-66](#), [DI-71](#)
Warning chime [DI-81](#)
Warning lamps [DI-65](#)
Water pump [CO-39](#)
Water temperature (High) warning lamp [DI-5](#)
Water temperature (Low) indicator lamp [DI-5](#)
Wheel alignment (front) [FSU-6](#)
Wheel alignment (rear) [RSU-5](#)
Wheel bearing (front) [FAX-6](#)
Wheel bearing (rear) [RAX-5](#)
Wheel hub (front) [FAX-6](#)
Wheel hub (rear) [RAX-5](#)
Wheel sensor (VDC) [BRC-101](#)
Wheel sensors (ABS) [BRC-44](#)
Wheel size [GI-48](#)
Wheelbase (Dimensions) [GI-48](#)
Width (Dimensions) [GI-48](#)
WINDOW - Wiring diagram [GW-55](#)
Window antenna [AV-15](#)
Window, back [GW-10](#)
Window, back door [GW-10](#)
Window, door [GW-69](#), [GW-72](#)
Window, rear side [GW-8](#)
Window, side - See Rear side window [GW-8](#)
Windshield [GW-4](#)
WIP/R - Wiring diagram [WW-100](#)
WIPER - Wiring diagram [WW-25](#)
Wiring Diagram (Cell code) list [PG-92](#)
Wiring diagrams [GI-14](#)

A

B

C

D

E

F

G

H

I

J

K

L

IDX