

SECTION **IDX**
ALPHABETICAL INDEX

A
B
C
D
E
F
G
H
I
J
K
L

ALPHABETICAL INDEX

A

A/C - Wiring diagram [MTC-24](#), [MTC-26](#), [MTC-28](#)
A/C component layout [MTC-65](#)
A/C compressor clutch removal and installation [MTC-69](#)
A/C compressor precaution [ATC-7](#), [MTC-6](#)
A/C compressor special service tool [MTC-10](#)
A/C HFC134a (R134a) system precaution [ATC-4](#), [MTC-3](#)
A/C HFC134a (R134a) system service tools .. [MTC-10](#)
A/C HFC134a system service equipment precaution ... [ATC-8](#), [MTC-7](#)
A/C lubricant (R134a) [ATC-102](#), [MTC-82](#)
A/C service data specification [ATC-102](#), [MTC-82](#)
A/C trouble diagnoses (manual A/C) [MTC-17](#)
A/C, M - Wiring diagram ... [MTC-24](#), [MTC-26](#), [MTC-28](#)
A/T fluid checking [AT-18](#), [MA-67](#)
A/T fluid replacement [AT-19](#), [MA-67](#)
A/T fluid temperature sensor [AT-119](#)
A/T shift control system [AT-334](#)
A/T shift lock system [AT-340](#)
A/T shift lock system - Wiring diagram [AT-341](#)
A/T trouble diagnoses [AT-46](#)
A/T Wiring diagram AT - BA/FTS [AT-186](#), [AT-241](#)
A/T Wiring diagram AT - CAN [AT-108](#), [AT-263](#)
A/T Wiring diagram AT - ENG SS [AT-127](#), [AT-247](#)
A/T Wiring diagram AT - FTS [AT-116](#)
A/T Wiring diagram AT - LPSV [AT-159](#), [AT-257](#)
A/T Wiring diagram AT - MAIN [AT-199](#), [AT-266](#)
A/T Wiring diagram AT - NONDTC [AT-299](#)
A/T Wiring diagram AT - OVRCSV [AT-177](#), [AT-231](#)
A/T Wiring diagram AT - PNP/SW [AT-111](#)
A/T Wiring diagram AT - PT/SEN [AT-192](#), [AT-251](#)
A/T Wiring diagram AT - SSV/A [AT-165](#), [AT-221](#)
A/T Wiring diagram AT - SSV/B [AT-170](#), [AT-226](#)
A/T Wiring diagram AT - TCV [AT-148](#), [AT-236](#)
A/T Wiring diagram AT - VSS A/T [AT-122](#), [AT-210](#)
A/T Wiring diagram AT - VSSMTR [AT-182](#), [AT-215](#)
A/WIP - Wiring diagram [WW-68](#)
ABS - Wiring diagram [BRC-13](#), [BRC-17](#)
ABS input/output signal inspection [BRC-21](#)
ABS sensor rotor [RAX-5](#)
Accelerator pedal position (APP) sensor [EC-380](#), [EC-389](#), [EC-405](#), [EC-696](#), [EC-705](#), [EC-721](#), [EC-1172](#), [EC-1181](#), [EC-1197](#), [EC-1495](#), [EC-1504](#), [EC-1519](#)
Accelerator pedal released position learning [EC-49](#), [EC-479](#), [EC-858](#), [EC-1283](#)
Air bag [SRS-3](#), [SRS-37](#), [SRS-41](#), [SRS-42](#), [SRS-44](#)
Air bag disposal [SRS-50](#)
Air bleeding (hydraulic clutch) [CL-9](#)
Air bleeding for brake system [BR-10](#)
Air cleaner and air duct [EM-119](#), [EM-247](#)
Air cleaner filter [EM-120](#), [EM-249](#)
Air cleaner filter replacement(CR) [MA-45](#)
Air cleaner filter replacement(HR) [MA-55](#)
Air cleaner filter replacement(K9K) [MA-63](#)
Air conditioner - Wiring diagram [MTC-24](#), [MTC-26](#), [MTC-28](#)

Air conditioner cut control [EC-36](#), [EC-467](#), [EC-819](#), [EC-1256](#)
Air flow meter - See Mass air flow sensor [EC-935](#), [EC-1359](#)
Air mix door control linkage adjustment [MTC-58](#)
Alternator [SC-16](#)
Angular tightening application [EM-106](#), [EM-227](#)
Antenna [AV-18](#)
AP/SEN - Wiring diagram .. [EC-152](#), [EC-335](#), [EC-554](#), [EC-653](#)
APPS1 - Wiring diagram .. [EC-382](#), [EC-698](#), [EC-1174](#), [EC-1497](#)
APPS2 - Wiring diagram .. [EC-391](#), [EC-707](#), [EC-1183](#), [EC-1506](#)
APPS3 - Wiring diagram .. [EC-407](#), [EC-723](#), [EC-1199](#), [EC-1521](#)
Audio [AV-4](#)
AUDIO - Wiring diagram [AV-5](#), [AV-9](#)
Auto wiper [WW-51](#)
Autolamp [LT-72](#)
Automatic transaxle number [GI-50](#)
Automatic transmission fluid replacement [MA-67](#)
Axle [MA-70](#)

B

Back door trim [EI-22](#)
Back door window [GW-12](#)
Back window [GW-12](#)
BACK/L - Wiring diagram [LT-205](#)
Back-up lamp [LT-205](#), [LT-208](#)
Basic inspection [EC-83](#), [EC-497](#), [EC-852](#), [EC-1277](#)
Battery [SC-6](#)
BCM (Body control module) [BCS-3](#)
Blower motor [MTC-32](#), [MTC-53](#)
Blower resistor [MTC-54](#)
Board computer [DI-38](#)
Board-on lift [GI-40](#)
Bose speaker amp. [AV-4](#)
Brake booster [BR-17](#)
Brake fluid change [BR-9](#)
Brake fluid level [MA-68](#)
Brake fluid level and line check [BR-9](#)
Brake hydraulic line [BR-11](#)
Brake inspection [MA-69](#)
Brake lines and cables inspection [MA-68](#)
Brake master cylinder [BR-14](#)
Brake pedal [BR-6](#)
Brake switch [EC-374](#), [EC-690](#), [EC-1167](#), [EC-1490](#)
BRK/SW - Wiring diagram [EC-376](#), [EC-692](#), [EC-1168](#), [EC-1491](#)
Bulb specifications [LT-280](#)
Bumper, front [EI-5](#)
Bumper, rear [EI-8](#)

C

Camshaft [EM-152](#)
Camshaft inspection [EM-158](#), [EM-328](#)

ALPHABETICAL INDEX

Camshaft position sensor (PHASE) . [EC-254](#), [EC-611](#),
[EC-1050](#), [EC-1417](#)
CAN - Wiring diagram [EC-133](#), [EC-546](#), [EC-927](#),
[EC-1350](#), [LAN-21](#), [LAN-52](#), [LAN-81](#), [LAN-110](#),
[LAN-137](#), [LAN-166](#), [LAN-193](#), [LAN-224](#), [LAN-253](#),
[LAN-282](#), [LAN-309](#), [LAN-338](#), [LAN-365](#), [LAN-394](#)
CAN (Controller Area Network) [AT-39](#), [BRC-55](#),
[WW-113](#), [LAN-7](#), [LAN-20](#), [LAN-51](#), [LAN-80](#), [LAN-109](#),
[LAN-136](#), [LAN-165](#), [LAN-192](#), [LAN-223](#), [LAN-252](#),
[LAN-281](#), [LAN-308](#), [LAN-337](#), [LAN-364](#), [LAN-393](#)
CAN communication [EC-38](#), [EC-132](#), [EC-469](#), [EC-545](#),
[EC-820](#), [EC-926](#), [EC-929](#), [EC-1257](#), [EC-1349](#),
[EC-1352](#), [AT-39](#), [AT-107](#), [BRC-55](#), [WW-113](#), [LAN-7](#),
[LAN-20](#), [LAN-51](#), [LAN-80](#), [LAN-109](#), [LAN-136](#),
[LAN-165](#), [LAN-192](#), [LAN-223](#), [LAN-252](#), [LAN-281](#),
[LAN-308](#), [LAN-337](#), [LAN-364](#), [LAN-393](#)
Canister-See EVAP canister [EC-447](#), [EC-799](#), [EC-828](#),
[EC-1265](#)
CD/CHG - Wiring diagram [AV-5](#), [AV-9](#)
CHARGE - Wiring diagram [SC-17](#), [SC-18](#), [SC-19](#)
Charging system [SC-16](#)
Chassis and body maintenance [MA-66](#)
CIGAR - Wiring diagram [WW-136](#)
Circuit breaker [PG-18](#)
Closed loop control [EC-34](#), [EC-465](#), [EC-816](#), [EC-1253](#)
Clutch cover [CL-12](#), [CL-13](#)
Clutch disc [CL-12](#)
Clutch master cylinder [CL-10](#)
Clutch pedal [CL-6](#)
Coil spring (front) [FSU-8](#)
Coil spring (rear) [RSU-9](#)
Collision diagnosis [SRS-57](#)
Combination switch [LT-210](#)
COMBSW - Wiring diagram [LT-215](#)
COMM - Wiring diagram [DI-55](#)
Component Location (manual A/C) [MTC-20](#)
Compression pressure [EM-174](#)
Compressor clutch removal and installation ... [MTC-69](#)
Compressor precaution [ATC-7](#), [MTC-6](#)
Compressor special service tool [MTC-10](#)
Condenser [MTC-74](#)
Connecting rod [EM-208](#), [EM-330](#)
Connecting rod bearing clearance [EM-211](#)
Connecting rod bushing clearance [EM-208](#)
CONSULT for ABS [BRC-22](#)
CONSULT for engine [EC-104](#), [EC-518](#)
CONSULT for VDC [BRC-74](#)
CONSULT general information [GI-34](#)
CONSULT-II for engine [EC-891](#), [EC-1316](#)
Control unit [MTC-46](#)
Control units (terminal arrangement) [PG-122](#)
Controller Area Network (CAN) [AT-39](#), [BRC-55](#),
[WW-113](#), [LAN-7](#), [LAN-20](#), [LAN-51](#), [LAN-80](#), [LAN-109](#),
[LAN-136](#), [LAN-165](#), [LAN-192](#), [LAN-223](#), [LAN-252](#),
[LAN-281](#), [LAN-308](#), [LAN-337](#), [LAN-364](#), [LAN-393](#)
Converter housing installation [AT-359](#), [AT-466](#)
COOL/F - Wiring diagram . [EC-345](#), [EC-662](#), [EC-1139](#),
[EC-1462](#)
Coolant mixture ratio [MA-37](#)

Coolant replacement [MA-60](#)
Cooling circuit (engine) [CO-8](#), [CO-33](#)
Cooling fan [CO-16](#), [CO-41](#), [CO-66](#)
Cooling fan motor [EC-355](#), [EC-672](#), [EC-1134](#),
[EC-1149](#), [EC-1457](#), [EC-1472](#)
Cooling fan relay [EC-1134](#), [EC-1457](#)
Cowl top [EI-13](#)
Crankcase ventilation system - See Positive crankcase
ventilation [EC-448](#), [EC-800](#), [EC-830](#), [EC-1267](#)
Crankshaft [EM-190](#), [EM-211](#), [EM-331](#)
Crankshaft position sensor (POS) [EC-248](#), [EC-604](#),
[EC-1042](#), [EC-1409](#)
Cylinder block [EM-190](#), [EM-332](#)
Cylinder head [EM-174](#), [EM-179](#), [EM-277](#)
Cylinder head bolt tightening [EM-177](#), [EM-278](#), [EM-324](#)

D

Data link connector [EC-442](#), [EC-794](#), [EC-893](#), [EC-901](#),
[EC-1317](#)
Data link connector for Consult [EC-106](#), [EC-520](#)
Daytime light system [LT-42](#)
Diagnosis sensor unit [SRS-49](#)
Diagnostic trouble code (DTC) for OBD system [EC-19](#),
[EC-57](#), [EC-452](#), [EC-484](#), [EC-804](#), [EC-834](#), [EC-1241](#),
[EC-1270](#)
Diagnostic trouble code (DTC) inspection priority chart
[EC-80](#), [EC-495](#), [EC-870](#), [EC-1295](#)
Dimensions [GI-50](#)
Door glass ... [GW-6](#), [GW-74](#), [GW-77](#), [GW-88](#), [GW-170](#)
Door mirror [GW-80](#), [GW-177](#)
Door trim [EI-20](#)
Drive belt [EM-115](#), [EM-244](#)
Drive belt inspection [MA-60](#)
Drive computer [DI-38](#), [DI-55](#)
Drive shaft (front) [FAX-10](#)
Driver air bag [SRS-37](#)
Dropping resistor (A/T) [AT-163](#), [AT-261](#)
DTC work support [EC-112](#), [EC-899](#)
DTRL - Wiring diagram [LT-58](#)
Duct and grilles [MTC-60](#)

E

ECM input/output signal [EC-97](#), [EC-511](#), [EC-884](#),
[EC-903](#), [EC-1309](#), [EC-1326](#)
ECM power supply [EC-126](#), [EC-276](#), [EC-539](#), [EC-621](#),
[EC-919](#), [EC-1342](#)
ECM/PW - Wiring diagram [EC-277](#), [EC-622](#)
ECTS - Wiring diagram [EC-164](#), [EC-561](#), [EC-949](#),
[EC-1368](#)
Electric throttle control actuator [EC-285](#), [EC-287](#),
[EC-299](#), [EC-631](#), [EC-634](#), [EC-646](#), [EC-1082](#), [EC-1084](#),
[EC-1434](#), [EC-1437](#)
Electrical diagnoses [GI-10](#)
Electrical load signal circuit [EC-441](#), [EC-793](#), [EC-1207](#),
[EC-1529](#)
Electrical unit [PG-122](#)
Electrical units location [PG-114](#)

ALPHABETICAL INDEX

Electronic ignition (EI) system [EC-35](#), [EC-466](#), [EC-817](#), [EC-1254](#)
Engine control circuit diagram [EC-95](#), [EC-509](#), [EC-882](#), [EC-1307](#)
Engine control component parts location [EC-90](#), [EC-504](#), [EC-876](#), [EC-1301](#)
Engine control module (ECM) [EC-273](#), [EC-618](#), [EC-929](#), [EC-1072](#), [EC-1075](#), [EC-1352](#), [EC-1424](#), [EC-1427](#)
Engine control system diagram [EC-814](#), [EC-1251](#)
Engine control system diagram and chart [EC-31](#), [EC-462](#)
Engine coolant [CO-9](#), [CO-34](#), [CO-61](#)
Engine coolant temperature sensor (ECTS) .. [EC-162](#), [EC-559](#), [EC-947](#), [EC-1366](#)
Engine fail-safe system [EC-81](#), [EC-496](#), [EC-871](#), [EC-1296](#)
Engine oil [LU-6](#), [LU-16](#), [LU-24](#)
Engine oil filter replacement(CR) [MA-46](#)
Engine oil filter replacement(HR) [MA-57](#)
Engine oil filter replacement(K9K) [MA-65](#)
Engine oil precautions [GI-7](#)
Engine oil replacement(CR) [MA-45](#)
Engine oil replacement(HR) [MA-56](#)
Engine oil replacement(K9K) [MA-64](#)
Engine removal [EM-185](#), [EM-280](#)
Engine room cover [EM-122](#), [EM-241](#)
Engine serial number [GI-49](#)
ETC1 - Wiring diagram [EC-288](#), [EC-635](#), [EC-1085](#), [EC-1438](#)
ETC2 - Wiring diagram [EC-295](#), [EC-642](#), [EC-1093](#), [EC-1446](#)
ETC3 - Wiring diagram [EC-300](#), [EC-647](#), [EC-1098](#), [EC-1451](#)
EVAP canister [EC-447](#), [EC-799](#), [EC-828](#), [EC-1265](#)
EVAP canister purge volume control solenoid valve [EC-264](#), [EC-444](#), [EC-769](#), [EC-796](#), [EC-1063](#), [EC-1531](#)
EVAP vapor lines inspection(CR) [MA-48](#)
EVAP vapor lines inspection(HR) [MA-59](#)
Evaporative emission (EVAP) system [EC-444](#), [EC-796](#), [EC-825](#), [EC-1262](#)
Evaporator [MTC-76](#)
Exhaust manifold [EM-125](#), [EM-258](#)
Exhaust system inspection [EX-4](#), [MA-66](#)
Expansion valve [MTC-78](#)

F

F/FOG - Wiring diagram [LT-112](#)
F/PUMP - Wiring diagram [EC-432](#), [EC-784](#), [EC-1216](#), [EC-1545](#)
Floor trim [EI-30](#)
Flow charts [GI-24](#)
Fluid temperature sensor (A/T) [AT-119](#)
Fluids [MA-35](#)
Fluorescent leak detector [MTC-79](#)
Flywheel (clutch) [CL-14](#)
Flywheel runout [EM-214](#)
Freeze frame data . [EC-58](#), [EC-485](#), [EC-835](#), [EC-894](#),

[EC-1271](#), [EC-1319](#)
FRO2 - Wiring diagram [EC-732](#), [EC-747](#), [EC-1551](#), [EC-1560](#)
Front axle [FAX-6](#)
Front bumper [EI-5](#)
Front disc brake [BR-21](#)
Front fog lamp [LT-98](#)
Front passenger air bag [SRS-41](#)
Front seat [SE-9](#)
Front seat belt [SB-3](#), [SB-5](#)
Front seat belt pre-tensioner [SB-2](#), [SB-3](#), [SB-5](#), [SRS-3](#)
Front side air bag [SRS-42](#)
Front suspension [FSU-5](#)
Front washer [WW-6](#), [WW-51](#)
Front wiper [WW-6](#), [WW-51](#)
FUEL - Wiring diagram [EC-219](#), [EC-227](#), [EC-1014](#), [EC-1021](#)
Fuel check valve [EC-444](#), [EC-796](#)
Fuel cut control (at no load high engine speed) [EC-37](#), [EC-468](#), [EC-818](#), [EC-1255](#)
Fuel filter replacement [FL-24](#)
Fuel gauge [FL-27](#)
Fuel injection system [EC-217](#), [EC-225](#), [EC-1012](#), [EC-1019](#)
Fuel injector [EC-1209](#), [EC-1538](#)
Fuel injector and fuel tube [EM-136](#)
Fuel line inspection [FL-3](#), [FL-13](#)
Fuel line inspection(CR) [MA-44](#)
Fuel line inspection(HR) [MA-55](#)
Fuel line inspection(K9K) [MA-63](#)
Fuel precautions [GI-5](#)
Fuel pressure check [EC-51](#), [EC-482](#), [EC-861](#), [EC-1286](#)
Fuel pressure release [EC-51](#), [EC-482](#), [EC-861](#), [EC-1286](#)
Fuel pump [EC-431](#), [EC-783](#), [EC-1215](#), [EC-1544](#)
Fuel pump and gauge [FL-4](#), [FL-14](#)
Fuel system [FL-3](#), [FL-13](#), [FL-23](#)
Fuel tank [FL-8](#), [FL-18](#), [FL-29](#)
Fuel tank vacuum relief valve [EC-828](#), [EC-1265](#)
Fuse [PG-18](#)
Fuse and fusible link box [PG-128](#)
Fusible link [PG-18](#)

G

Garage jack and safety stand [GI-38](#)
Generator [SC-16](#)
Generator - See Alternator [SC-16](#)
Generic scan tool (GST) [EC-114](#), [EC-901](#)
Glow plug [EM-268](#)
Grease [MA-35](#)
Grille - See Exterior [EI-11](#)
Ground distribution [PG-55](#)

H

H/AIM - Wiring diagram [LT-95](#)
H/LAMP - Wiring diagram [LT-22](#)
Harness connector [PG-119](#)

ALPHABETICAL INDEX

Harness layout [PG-70](#)
Hazard warning lamp [LT-141](#), [LT-211](#)
Headlamp [LT-7](#)
Headlamp aiming control [LT-95](#)
Headlamp washer [WW-112](#)
Headlining - See Roof trim [EI-33](#)
Heated oxygen sensor 1 [EC-175](#), [EC-183](#), [EC-193](#),
[EC-304](#), [EC-310](#), [EC-572](#), [EC-579](#), [EC-746](#), [EC-958](#),
[EC-965](#), [EC-975](#), [EC-1102](#), [EC-1108](#), [EC-1377](#),
[EC-1385](#), [EC-1550](#)
Heated oxygen sensor 1 heater [EC-139](#), [EC-731](#),
[EC-983](#), [EC-1559](#)
Heated oxygen sensor 2 [EC-201](#), [EC-208](#), [EC-316](#),
[EC-325](#), [EC-586](#), [EC-753](#), [EC-989](#), [EC-996](#), [EC-1114](#),
[EC-1123](#), [EC-1392](#), [EC-1565](#)
Heated oxygen sensor 2 heater [EC-145](#), [EC-736](#),
[EC-1005](#), [EC-1571](#)
Heated seat [SE-4](#)
HEATER - Wiring diagram [MTC-23](#)
Heater system - Wiring diagram [MTC-23](#)
Heater unit (heater core) [MTC-52](#)
Height (Dimensions) [GI-50](#)
HFC134a (R134a) system precaution .. [ATC-4](#), [MTC-3](#)
HFC134a (R134a) system service procedure [MTC-64](#)
HFC134a (R134a) system service tools [MTC-10](#)
HFC134a system service equipment precaution
[ATC-8](#), [MTC-7](#)
HLC - Wiring diagram [WW-126](#), [WW-134](#)
HO2S1 - Wiring diagram [EC-177](#), [EC-186](#), [EC-196](#),
[EC-574](#), [EC-581](#), [EC-960](#), [EC-968](#), [EC-978](#), [EC-1379](#),
[EC-1387](#)
HO2S1H - Wiring diagram [EC-141](#), [EC-985](#)
HO2S2 - Wiring diagram [EC-203](#), [EC-211](#), [EC-319](#),
[EC-328](#), [EC-588](#), [EC-991](#), [EC-999](#), [EC-1117](#), [EC-1126](#),
[EC-1394](#)
HO2S2H - Wiring diagram [EC-147](#), [EC-1007](#)
Horn [WW-134](#)
HORN - Wiring diagram [WW-134](#)
How to erase DTC for OBD system [EC-66](#), [EC-486](#),
[EC-842](#), [EC-1272](#)
HSEAT - Wiring diagram [SE-5](#)

I

IATS - Wiring diagram [EC-159](#), [EC-944](#)
IATSEN - Wiring diagram [EC-742](#), [EC-1578](#)
Identification [ATC-10](#), [MTC-9](#)
Identification plate [GI-48](#)
Idle air volume learning [EC-49](#), [EC-479](#), [EC-859](#),
[EC-1284](#)
Idle speed [EC-83](#), [EC-497](#), [EC-852](#), [EC-857](#), [EC-1277](#),
[EC-1282](#)
Ignition coil [EM-133](#), [EC-415](#), [EC-759](#), [EC-1221](#),
[EC-1582](#)
Ignition control system [EC-415](#), [EC-759](#), [EC-1221](#),
[EC-1582](#)
Ignition timing [EC-83](#), [EC-497](#), [EC-852](#), [EC-857](#),
[EC-1277](#), [EC-1282](#)
IGNSYS - Wiring diagram . [EC-416](#), [EC-760](#), [EC-1222](#),

[EC-1583](#)
ILL - Wiring diagram [LT-272](#)
Illumination [LT-256](#)
INJECT - Wiring diagram . [EC-426](#), [EC-778](#), [EC-1210](#),
[EC-1539](#)
Injector [EC-425](#), [EC-777](#), [EC-1209](#), [EC-1538](#)
INT/L - Wiring diagram [LT-239](#)
Intake air system [EC-334](#), [EC-651](#)
Intake air temperature sensor [EC-157](#), [EC-741](#),
[EC-942](#), [EC-1577](#)
Intake door control linkage adjustment [MTC-56](#)
Intake manifold [EM-121](#)
Intake valve timing control . [EC-135](#), [EC-548](#), [EC-931](#),
[EC-1354](#)
Intake valve timing control solenoid valve [EC-280](#),
[EC-625](#), [EC-931](#), [EC-1077](#), [EC-1354](#), [EC-1429](#)
Interior lamp [LT-223](#)
IPDM (Intelligent power distribution module engine
room) [PG-19](#)
ISO 15031-2 Terminology [GI-51](#)
ISO 15031-5 Mode 1 - 9 [EC-54](#)
ISO 15031-5 Service \$01 - 09 [EC-832](#)
IVC - Wiring diagram [EC-281](#), [EC-627](#), [EC-1078](#),
[EC-1430](#)

K

Keyless entry system - See Multi-remote control system
[BL-154](#)
Knock sensor (KS) [EC-244](#), [EC-600](#), [EC-1038](#),
[EC-1405](#)
Knuckle spindle [FAX-6](#)
KS - Wiring diagram [EC-245](#), [EC-601](#), [EC-1039](#),
[EC-1406](#)

L

Length (Dimensions) [GI-50](#)
License lamp [LT-169](#)
Line pressure test (A/T) [AT-61](#)
Liquid gasket application [EM-107](#), [EM-228](#), [LU-3](#),
[LU-13](#), [CO-3](#), [CO-28](#)
Location of electrical units [PG-114](#)
Lubricant (R134a) A/C [ATC-5](#), [ATC-102](#), [MTC-4](#),
[MTC-15](#), [MTC-82](#)
Lubricants [MA-35](#)
Lubrication circuit (engine) [LU-5](#), [LU-15](#)
Lubrication oil A/C [ATC-102](#), [MTC-82](#)
Lubrication-locks, hinges and hood latches [MA-71](#)
Luggage compartment trim [EI-40](#)

M

MAFS - Wiring diagram [EC-937](#), [EC-1361](#)
Magnet clutch [MTC-34](#)
MAIN - Wiring diagram [EC-126](#), [EC-539](#), [EC-919](#),
[EC-1342](#)
Malfunction indicator (MI) [EC-67](#), [EC-487](#), [EC-843](#),
[EC-1273](#)

ALPHABETICAL INDEX

Manifold absolute pressure (MAP) sensor [EC-151](#),
[EC-553](#)
Manual air conditioner - Wiring diagram [MTC-24](#),
[MTC-26](#), [MTC-28](#)
Mass air flow sensor (MAFS) [EC-935](#), [EC-1359](#)
Master cylinder (brake) [BR-14](#)
MI & data link connectors circuit [EC-1237](#), [EC-1599](#)
MI/DL - Wiring diagram [EC-1237](#), [EC-1599](#)
MIL/DL - Wiring diagram [EC-442](#), [EC-794](#)
Mirror, door [GW-80](#), [GW-177](#)
Mirror, out side [GW-80](#), [GW-177](#)
Misfire [EC-239](#), [EC-1032](#)
Mode door control linkage adjustment [MTC-57](#)
Model variation [GI-44](#)
Molding - See Exterior . [RF-163](#), [RF-170](#), [EI-15](#), [EI-16](#),
[EI-18](#)
Multiport fuel injection (MFI) system ... [EC-33](#), [EC-464](#),
[EC-815](#), [EC-1252](#)
Multiport fuel injection precautions [GI-6](#)
Multi-remote control system [BL-154](#)

N

NATS - Wiring diagram [BL-287](#)
NATS (Nissan anti-theft system) precautions [GI-3](#)
Navigation system [AV-20](#)
NVH troubleshooting (BR) [BR-5](#), [PB-2](#)
NVH troubleshooting (RSU) [RSU-4](#)
NVH troubleshooting (ST) [PS-4](#)

O

Oil cooler (engine) [LU-28](#)
Oil filter [LU-9](#), [LU-19](#), [LU-26](#)
Oil pan (engine) [EM-128](#), [EM-265](#)
Oil pressure (engine) [LU-6](#), [LU-16](#), [LU-24](#)
Oil pump (engine) [LU-10](#), [LU-27](#)
Oil seal replacement (engine) [EM-171](#)
On board diagnostic system [EC-54](#), [EC-484](#), [EC-832](#),
[EC-1269](#)
Out side mirror [GW-80](#), [GW-177](#)
Overdrive control switch [AT-202](#), [AT-207](#), [AT-293](#),
[AT-298](#)
Overheat [EC-341](#), [EC-658](#), [EC-1134](#), [EC-1457](#)
Oversize piston [EM-210](#)

P

Park/Neutral position switch [EC-367](#), [EC-684](#),
[EC-1161](#), [EC-1484](#)
Park/neutral position switch (A/T) [AT-110](#), [AT-202](#),
[AT-293](#)
Parking brake control [PB-3](#)
Parking lamp [LT-169](#)
PCV (positive crankcase ventilation) [EC-448](#), [EC-800](#),
[EC-830](#), [EC-1267](#)
PGC/V - Wiring diagram . [EC-266](#), [EC-1065](#), [EC-1532](#)
PHASE - Wiring diagram . [EC-255](#), [EC-613](#), [EC-1052](#),
[EC-1419](#)

Piston assembly [EM-210](#), [EM-329](#)
Piston pin inspection [EM-329](#)
Piston ring inspection [EM-207](#), [EM-330](#)
Piston to bore clearance [EM-210](#)
PNP/SW - Wiring diagram [EC-369](#), [EC-685](#), [EC-1163](#),
[EC-1486](#)
POS - Wiring diagram [EC-249](#), [EC-606](#), [EC-1044](#),
[EC-1411](#)
POWER - Wiring diagram [PG-6](#)
Power door lock [BL-16](#)
Power socket [WW-136](#)
Power steering gear [PS-9](#)
Power supply routing [PG-5](#)
Power window [GW-50](#), [GW-74](#), [GW-77](#), [GW-131](#),
[GW-170](#)
Precations for Leak detection dye [ATC-10](#), [MTC-9](#)
Precautions (General) [GI-4](#)
PRGVLV - Wirng diagram [EC-770](#)

R

R/FOG - Wiring diagram [LT-135](#)
Radiator [CO-13](#), [CO-19](#), [CO-38](#), [CO-44](#), [CO-64](#)
Radiator fan - See Cooling fan [CO-66](#)
Radio - See Audio [AV-4](#)
Rain sensor [WW-51](#)
Rear axle [RAX-5](#)
Rear bumper [EI-8](#)
Rear drum brake [BR-27](#)
Rear fog lamp [LT-121](#), [LT-208](#)
Rear seat [SE-15](#)
Rear seat belt [SB-5](#)
Rear side window [GW-10](#), [GW-174](#)
Rear suspension [RSU-5](#)
Rear washer [WW-83](#)
Rear window defogger [GW-16](#), [GW-96](#)
Rear wiper [WW-83](#)
Refrigerant connection precaution [ATC-5](#), [MTC-4](#)
Refrigerant general precaution [ATC-4](#), [MTC-3](#)
Refrigerant lines [MTC-64](#)
Refrigerant pressure sensor [EC-436](#), [EC-788](#),
[EC-1231](#), [EC-1592](#), [MTC-73](#)
Refrigeration cycle [ATC-14](#), [MTC-14](#)
Removal and installation (A/T) [AT-357](#)
Road test [AT-63](#), [AT-66](#), [AT-69](#), [AT-70](#)
Road wheel size [GI-50](#)
Rocker cover [EM-141](#), [EM-271](#)
Roof trim [EI-33](#)
RP/SEN - Wiring diagram [EC-437](#), [EC-789](#), [EC-1232](#),
[EC-1593](#)
RRO2 - Wiring diagram ... [EC-737](#), [EC-754](#), [EC-1566](#),
[EC-1572](#)

S

S/LOCK - Wiring diagram [BL-35](#), [BL-42](#), [BL-100](#),
[BL-107](#)
Seat belt inspection [SB-6](#), [MA-71](#)
Seat belt pre-tensioner [SB-3](#), [SB-5](#)

ALPHABETICAL INDEX

Seat belt pre-tensioner disposal [SRS-50](#)
 Seat belt, front [SB-3](#), [SB-5](#)
 Seat belt, rear [SB-5](#)
 Seat, front [SE-9](#)
 Seat, rear [SE-15](#)
 Self-diagnostic results [EC-894](#), [EC-1318](#)
 SEN/PW - Wiring diagram [EC-361](#), [EC-678](#), [EC-1155](#),
[EC-1478](#)
 Sheft warning system [BL-259](#)
 SHIFT - Wiring diagram [AT-341](#)
 Shift lock system [AT-340](#)
 Shift schedule [AT-72](#), [AT-475](#)
 Shock absorber (front) [FSU-8](#)
 Shock absorber (rear) [RSU-7](#)
 Side air bag [SRS-42](#), [SRS-44](#)
 Side air bag (satellite) sensor [SRS-47](#)
 Side curtain air bag [SRS-44](#)
 Side trim [EI-25](#)
 Side window - See Rear side window [GW-10](#), [GW-174](#)
 SMJ (super multiple junction) [PG-124](#)
 Spare tire size [GI-50](#)
 Spark plug [EM-134](#)
 Spark plug replacement(CR) [MA-47](#)
 Spark plug replacement(HR) [MA-58](#)
 Specification value [EC-120](#), [EC-533](#), [EC-908](#), [EC-1331](#)
 Spiral cable [SRS-39](#)
 SROOF - Wiring diagram [RF-8](#)
 SRS - See Supplemental Restraint System [SRS-5](#)
 SRS - Wiring diagram [SRS-11](#), [SRS-12](#)
 SRS Trouble diagnoses [SRS-8](#)
 Stabilizer bar (front) [FSU-11](#)
 Stall test (A/T) [AT-58](#)
 Standardized relay [PG-125](#)
 START - Wiring diagram [SC-47](#), [SC-49](#)
 Starter [SC-46](#)
 Starting system [SC-46](#)
 Steering gear and linkage inspection [MA-70](#)
 Steering linkage [PS-9](#)
 Steering wheel and column [PS-5](#), [PS-7](#)
 Steering wheel play [PS-5](#)
 Steering wheel turning force [PS-5](#)
 Stop lamp [LT-201](#), [LT-208](#)
 Stop lamp switch [EC-374](#), [EC-690](#), [EC-1167](#), [EC-1490](#)
 STOP/L - Wiring diagram [LT-201](#)
 Sunroof [RF-7](#)
 Super lock [BL-80](#)
 Supplemental Restraint System [SRS-5](#)
 Supplemental restraint system - Wiring diagram
[SRS-11](#), [SRS-12](#)
 Suspension [MA-70](#)
 Symbols and abbreviations [GI-10](#), [GI-22](#)
 Symptom matrix chart [EC-86](#), [EC-500](#), [EC-872](#),
[EC-1297](#)
 SYSTEM [BRC-6](#)
 System readiness test (SRT) code [EC-58](#), [EC-836](#)

T

Tail lamp [LT-169](#), [LT-208](#)

TAIL/L - Wiring diagram [LT-185](#)
 TCM inspection table [AT-85](#)
 THEFT - Wiring diagram [BL-264](#)
 Thermostat [CO-25](#), [CO-50](#)
 Three way catalyst function [EC-260](#), [EC-1057](#)
 Three way catalyst precautions [GI-5](#)
 Throttle control motor ... [EC-1084](#), [EC-1097](#), [EC-1437](#),
[EC-1450](#)
 Throttle control motor relay [EC-293](#), [EC-640](#), [EC-1084](#),
[EC-1091](#), [EC-1437](#), [EC-1444](#)
 Throttle position sensor (TPS) [EC-168](#), [EC-232](#),
[EC-356](#), [EC-358](#), [EC-398](#), [EC-565](#), [EC-593](#), [EC-673](#),
[EC-675](#), [EC-714](#), [EC-952](#), [EC-1026](#), [EC-1150](#),
[EC-1152](#), [EC-1191](#), [EC-1371](#), [EC-1399](#), [EC-1473](#),
[EC-1475](#), [EC-1513](#)
 Throttle valve closed position learning [EC-49](#), [EC-479](#),
[EC-858](#), [EC-1284](#)
 Tie-rod [PS-9](#)
 Tie-rod ball joints [PS-9](#)
 Tightening torque of standard bolts [GI-43](#)
 Timing belt [EM-273](#)
 Timing chain [EM-143](#)
 Tire size [GI-50](#)
 Torque converter installation [AT-359](#), [AT-466](#)
 Tow truck towing [GI-41](#)
 TPS1 - Wiring diagram ... [EC-234](#), [EC-595](#), [EC-1028](#),
[EC-1401](#)
 TPS2 - Wiring diagram [EC-170](#), [EC-567](#), [EC-954](#),
[EC-1373](#)
 TPS3 - Wiring diagram ... [EC-400](#), [EC-716](#), [EC-1193](#),
[EC-1515](#)
 Tread-FR&RR (Dimensions) [GI-50](#)
 Trouble diagnoses [GI-10](#)
 Trunk lid [BL-251](#)
 Turbocharger [EM-258](#)
 Turbocharger precautions [GI-6](#)
 TURN - Wiring diagram [LT-157](#)
 Turn signal lamp [LT-141](#), [LT-208](#)
 Two trip detection logic [EC-54](#), [EC-484](#), [EC-832](#),
[EC-1269](#)
 Two-pole lift [GI-39](#)

V

Vacuum hose (brake system) [BR-19](#)
 Vacuum hose drawing (Engine control) [EC-32](#),
[EC-463](#), [EC-881](#), [EC-1306](#)
 Vacuum pump [EM-269](#)
 Valve clearance [EM-167](#), [EM-295](#), [EM-327](#)
 Valve guide [EM-181](#), [EM-325](#)
 Valve lifter [EM-161](#)
 Valve seat [EM-183](#), [EM-325](#)
 Valve spring [EM-184](#), [EM-327](#)
 VDC -Wiring diagram [BRC-66](#)
 Vehicle identification number [GI-47](#)
 Vehicle recovery (freeing a stuck vehicle) [GI-42](#)
 Vehicle speed sensor (VSS) [EC-271](#), [EC-776](#),
[EC-1070](#), [EC-1598](#)
 Viscosity number (SAE) [MA-36](#)

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L

IDX

ALPHABETICAL INDEX

W

WARN - Wiring diagram	DI-63 , DI-69
Warning chime	DI-78
Warning lamps	DI-62
Water pump	CO-23 , CO-48 , CO-69
Wheel alignment (front)	FSU-6
Wheel alignment (rear)	RSU-6
Wheel bearing (front)	FAX-6
Wheel bearing (rear)	RAX-5
Wheel hub (front)	FAX-6
Wheel hub (rear)	RAX-5
Wheel sensor (VDC)	BRC-101
Wheel sensors (ABS)	BRC-45
Wheel size	GI-50
Wheelbase (Dimensions)	GI-50
Width (Dimensions)	GI-50
WINDOW - Wiring diagram ..	GW-54 , GW-56 , GW-145
Window antenna	AV-18
Window, back	GW-12
Window, back door	GW-12
Window, door	GW-74 , GW-77 , GW-170
Window, rear side	GW-10 , GW-174
Window, side - See Rear side window	GW-10 , GW-174
Windshield	GW-6 , GW-88
WIP/R - Wiring diagram	WW-98 , WW-101
WIPER - Wiring diagram	WW-27
Wiring Diagram (Cell code) list	PG-111
Wiring diagrams	GI-15
Wrist pin - See Piston pin inspection	EM-206