5. Oil Seal

A: INSPECTION

Check for transmission gear oil leaks at oil seal area. If there is an oil leak, replace the oil seal with new one and check the propeller shaft.

B: REPLACEMENT

1) Remove the collector cover. (turbo model)
2) Lift up the vehicle.
3) Remove the front under cover. <Ref. to EI-35, REMOVAL, Front Under Cover.>
4) Clean the transmission exterior.
5) Using the TORX® bit T70, remove the drain plug, and drain the transmission gear oil completely.
6) Using the TORX® bit T70, tighten the transmission gear oil drain plug.

NOTE:
Use a new gasket.

Tightening torque:
   44 N·m (4.5 kgf-m, 32.5 ft-lb) (Aluminum gasket silver)
   70 N·m (7.1 kgf-m, 51.6 ft-lb) (Copper gasket brown)
   70 N·m (7.1 kgf-m, 51.6 ft-lb) (Metal gasket black)

MT-01548

7) Remove the center exhaust pipe. (non-turbo model) <Ref. to EX(H4SO)-7, REMOVAL, Center Exhaust Pipe.>
8) Remove the center exhaust pipe. (turbo model) <Ref. to EX(H4DOTC)-12, REMOVAL, Center Exhaust Pipe.>
9) Remove the heat shield cover.

MT-01660

10) Remove the propeller shaft. <Ref. to DS-10, REMOVAL, Propeller Shaft.>
11) Using the ST, remove the oil seal.
ST   398527700   PULLER ASSY

(A)   Oil seal

MT-01849

(A)   Oil seal

12) Using the ST, install the oil seal.
ST   498057300   INSTALLER

MT-01850

13) Apply transmission gear oil to the oil seal lips.
14) Install the propeller shaft. <Ref. to DS-11, INSTALLATION, Propeller Shaft.>
15) Install the heat shield cover. <Ref. to EI-168, INSTALLATION, Heat Shield Cover.>
16) Install the center exhaust pipe. (non-turbo model) <Ref. to EX(H4SO)-7, INSTALLATION, Center Exhaust Pipe.>
17) Install the center exhaust pipe. (turbo model) <Ref. to EX(H4DOTC)-13, INSTALLATION, Center Exhaust Pipe.>
18) Install the front under cover. <Ref. to EI-35, INSTALLATION, Front Under Cover.>
19) Lower the vehicle.
20) Pour in transmission gear oil and check the oil level. <Ref. to 6MT-24, Transmission Gear Oil.>
21) Install the collector cover. (turbo model)