
QUARTER WHEEL HOUSING OUTER PANEL (ASSY)



F14051-A

REMOVAL
With the quarter panel removed.




F14051


POINT
1 After removing the Ⓐ, remove quarter wheel housing outer panel.
2 *1 : Reuse

PART NAME
Ⓐ Roof Side Outer Panel

〔LH〕



〔RH〕




F14052


INSTALLATION

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.

(LH)




(RH)




F14053

POINT

1 Determine the position of the new parts by assembly marks of the inner and outer panels.





F14054