

J POWER SOURCE (Current Flow Chart)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other Parts.





(LOCATION)

① : Engine Room J/B (See Page 24)

② : Driver Side J/B (See Page 28)

③ : Engine Room R/B (See Page 22)

④ : ABS R/B (See Page 23)