Engine Room J/B (See Page 24)

Fuse		System	Page
5A	ALT–S	Charging	94
10A	ETCS	Cruise Control (1MZ–FE)	258
		Cruise Control (2AZ–FE, 1AZ–FE)	264
		Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110
10A	HEAD LH UPR	Headlight	150
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
10A	HEAD RH UPR	Headlight	150
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
10A	HORN	Horn	302
10A	IG2	ABS	244
		Charging	94
		Combination Meter	324
		Cruise Control (1MZ–FE)	258
		Cruise Control (2AZ–FE, 1AZ–FE)	264
		ECT and A/T Indicator (1MZ–FE)	270
		ECT and A/T Indicator (2AZ–FE, 1AZ–FE)	278
		Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110
		Engine Immobiliser System (1MZ–FE)	122
		Engine Immobiliser System (2AZ–FE, 1AZ–FE)	124
		SRS	251
		Stop Light (RHD)	184
		Taillight (RHD)	178
		VSC	236
15A	HAZ	Turn Signal and Hazard Warning Light	172
15A	IGN	Clock	310
		Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110
		Starting and Ignition (1MZ–FE)	86
		Starting and Ignition (2AZ–FE, 1AZ–FE)	90
20A	EFI	Cruise Control (1MZ–FE)	258
		Cruise Control (2AZ–FE, 1AZ–FE)	264
		ECT and A/T Indicator (1MZ–FE)	270
		ECT and A/T Indicator (2AZ–FE, 1AZ–FE)	278
		Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110
		Engine Immobiliser System (1MZ–FE)	122
		Engine Immobiliser System (2AZ–FE, 1AZ–FE)	124
25A	A/F	Engine Control (1MZ–FE)	96

∗ These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
25A	DOOR1	Door Lock Control (LHD)	196
		Door Lock Control (RHD)	202
		Double Locking	208
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
		Wireless Door Lock Control (LHD)	216
		Wireless Door Lock Control (RHD)	222
30A	AM2	Charging	94
		Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110
		Starting and Ignition (1MZ–FE)	86
		Starting and Ignition (2AZ–FE, 1AZ–FE)	90
30A	CDS	Radiator Fan and Condenser Fan	330
30A	H–LP CLN	Headlight Cleaner (LHD)	192
30A	RDI	Radiator Fan and Condenser Fan	330
40A	ABS NO.2	ABS	244
		VSC	236
40A	ABS NO.3	ABS	244
		VSC	236
40A	MAIN	Automatic Light Control	156
		Headlight	150
		Light Auto Turn Off	158
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
50A	HTR	Automatic Air Conditioner	334

Driver Side J/B (See Page 28)

Fuse		System	Page
5A	AM1	ECT and A/T Indicator (1MZ–FE)	270
		ECT and A/T Indicator (2AZ–FE, 1AZ–FE)	278
		Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110
		Starting and Ignition (1MZ–FE)	86
		Starting and Ignition (2AZ–FE, 1AZ–FE)	90
5A	ECU–ACC	Clock	310
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
		Remote Control Mirror	296
7.5A	DOME	Clock	310
		Double Locking	208
		Interior Light	162
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138

∗ These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
7.5A	DOME	Wireless Door Lock Control (LHD)	216
		Wireless Door Lock Control (RHD)	222
7.5A	OBD	Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110
10A	ECU–B	Automatic Air Conditioner	334
		Automatic Light Control	156
		Clock	310
		Combination Meter	324
		Door Lock Control (LHD)	196
		Door Lock Control (RHD)	202
		Double Locking	208
		Headlight	150
		Interior Light	162
		Key Reminder	194
		Light Auto Turn Off	158
		Moon Roof	228
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
		Power Window	230
		Rear Fog Light	188
		VSC	236
		Wireless Door Lock Control (LHD)	216
		Wireless Door Lock Control (RHD)	222
10A	ECU–IG	ABS	244
		Automatic Light Control	156
		Door Lock Control (LHD)	196
		Door Lock Control (RHD)	202
		Double Locking	208
		Headlight	150
		Interior Light	162
		Key Reminder	194
		Light Auto Turn Off	158
		Moon Roof	228
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
		Power Window	230
		SRS	251
		VSC	236
10A	FAN RLY	Radiator Fan and Condenser Fan	330
10A	GAUGE1	Auto Antenna	322
		Charging	94
		Clock	310
		Combination Meter	324
		Key Reminder	194

∗ These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
10A	GAUGE1	Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
		Seat Belt Warning	294
		Shift Lock	286
		Stop Light (RHD)	184
		Taillight (RHD)	178
		Turn Signal and Hazard Warning Light	172
10A	GAUGE2	ABS	244
		Automatic Glare–Resistant EC Mirror	298
		Back–Up Light	186
		Cruise Control (1MZ–FE)	258
		Cruise Control (2AZ–FE, 1AZ–FE)	264
		ECT and A/T Indicator (1MZ–FE)	270
		ECT and A/T Indicator (2AZ–FE, 1AZ–FE)	278
		Moon Roof	228
		Rear Window Defogger and Mirror Heater	308
		TOYOTA Navigation System, Radio and Player	314
		VSC	236
10A	HTR	Automatic Air Conditioner	334
10A	MIR HTR	Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110
		Rear Window Defogger and Mirror Heater	308
10A	PANEL	Front Fog Light	154
		Illumination	168
		Multiplex Communication System (LHD)	126
10A	RAD NO.2	Auto Antenna	322
		Radio and Player (w/o TOYOTA Navigation System)	320
		TOYOTA Navigation System, Radio and Player	314
10A	TAIL	Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110
		Front Fog Light	154
		Taillight (LHD)	176
		Taillight (RHD)	178
15A	CIG	Power Outlet and Cigarette Lighter	300
15A	FOG	Front Fog Light	154
15A	POWER POINT	Power Outlet and Cigarette Lighter	300
15A	STOP	ABS	244
		Cruise Control (1MZ–FE)	258
		Cruise Control (2AZ–FE, 1AZ–FE)	264
		ECT and A/T Indicator (1MZ–FE)	270
		ECT and A/T Indicator (2AZ–FE, 1AZ–FE)	278
		Engine Control (1MZ–FE)	96
		Engine Control (2AZ–FE, 1AZ–FE)	110

* These are the page numbers of the first page on which the related system is shown.

J POWER SOURCE (Current Flow Chart)

Fuse		System	Page
15A	STOP	Shift Lock	286
		Stop Light (LHD)	182
		Stop Light (RHD)	184
		VSC	236
15A	WASHER	Headlight Cleaner (LHD)	192
		Wiper and Washer	304
20A	RAD NO.1	Auto Antenna	322
		Radio and Player (w/o TOYOTA Navigation System)	320
		TOYOTA Navigation System, Radio and Player	314
20A	SEAT HTR	Seat Heater	292
25A	DOOR NO.2	Door Lock Control (LHD)	196
		Door Lock Control (RHD)	202
		Double Locking	208
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
		Wireless Door Lock Control (LHD)	216
		Wireless Door Lock Control (RHD)	222
25A	WIPER	Wiper and Washer	304
30A	PWR NO.1	Moon Roof	228
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
		Power Window	230
30A	PWR SEAT	Power Seat	288
40A	DEF	Rear Window Defogger and Mirror Heater	308

Engine Room R/B (See Page 22)

Fuse		System	Page
15A	HEAD LH LWR	Headlight	150
		Headlight Beam Level Control	190
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
15A	HEAD RH LWR	Headlight	150
		Headlight Beam Level Control	190
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
100A	ALT (2AZ–FE, 1AZ–FE)	Automatic Light Control	156
		Charging	94
		ECT and A/T Indicator (2AZ–FE, 1AZ–FE)	278
		Engine Control (2AZ–FE, 1AZ–FE)	110
		Illumination	168
		Light Auto Turn Off	158
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
		Starting and Ignition (2AZ–FE, 1AZ–FE)	90

∗ These are the page numbers of the first page on which the related system is shown.

Fuse		System	Page
100A	ALT (2AZ–FE, 1AZ–FE)	Taillight (LHD)	176
		Taillight (RHD)	178
120A	ALT (1MZ–FE)	Automatic Light Control	156
		Charging	94
		ECT and A/T Indicator (1MZ–FE)	270
		Engine Control (1MZ–FE)	96
		Illumination	168
		Light Auto Turn Off	158
		Multiplex Communication System (LHD)	126
		Multiplex Communication System (RHD)	138
		Starting and Ignition (1MZ–FE)	86
		Taillight (LHD)	176
		Taillight (RHD)	178

ABS R/B (See Page 23)

Fuse		System	Page
7.5A	ABS NO.4	ABS	244
		VSC	236

* These are the page numbers of the first page on which the related system is shown.