G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980–11070
A 2	A/C Condenser Fan Motor	90980–10928
A 3	A/C Lock Sensor	90980–11016
	A/C Magnetic Clutch	
A 4	A/T Indicator Light SW	90980–12362
	Back–Up Light SW	
	Neutral Start SW	
A 5	ABS & BA & TRC & VSC Actuator	90980–12020
A 6	ABS Actuator	90980–12116
A 7	ABS Speed Sensor Front LH	90980–11002
A 8	ABS Speed Sensor Front RH	
A 9	Air Flow Meter	90980–11317
A10	Air Fuel Ratio Sensor	90980–11178
A11	Air Fuel Ratio Sensor (Bank 1 Sensor 1)	
A12	Air Fuel Ratio Sensor (Bank 2 Sensor 1)	
A13	Airbag Sensor Front LH	90980–11856
A14	Airbag Sensor Front RH	
A15	Alternator	90980–09213
A16	Alternator	90980–11964
A17	A/C Control Assembly	90980–12169
A18	A/C Room Temp. Sensor	90980–11918
A19	A/C Solar Sensor	
A20	A/C Thermistor	
A21	A/T Shift Lever Illumination	90980–12211
	O/D Main SW	
A22	Accelerator Position Sensor	90980–11144
A23	Air Inlet Control Servo Motor	90980–11909
A24	Air Mix Control Servo Motor	
A25	Air Vent Mode Control Servo Motor	
A26	Airbag Sensor Assembly	82824–50160
A27	Airbag Sensor Assembly	90980–11872
A28	Airbag Sensor Assembly	82824–50150
A29	Airbag Squib (Front Passenger Airbag Assembly)	90980–12242
A30	Airbag Squib (Front Passenger Airbag Assembly)	90980–12243
A31	Airbag Squib (Steering Wheel Pad)	90980–12160
A32	Automatic Light Control Sensor	90980–11107
A33	ABS Speed Sensor Rear LH	90980–11060
A34	ABS Speed Sensor Rear RH	
A35	Auto Antenna Control Relay	90980–10797
B 1	Back–Up Light SW	90980–11250
B 2	Brake Fluid Level Warning SW	90980–11207
B 3	Blower Motor	90980–10903
B 4	Blower Motor Controller	90980–11676
B 5	Body ECU	90980–11915
B 6	Body ECU	90980–11913
B 7	Body ECU	90980–10803
B 8	Buckle SW LH (LHD)	90980–11034
	Buckle SW LH (RHD)	90980–10795
	Occupant Detection Sensor (RHD)	
B 9	Buckle SW RH (LHD)	90980–10795
	Buckle SW RH (RHD)	90980–11034
	Occupant Detection Sensor (LHD)	90980–10795
C 1	Camshaft Position Sensor	90980–10947
C 2	Counter Gear Speed Sensor	90980–11156
C 3	Crankshaft Position Sensor	90980–10947
C 4	Cigarette Lighter	90980–11606
	Cigarette Lighter Illumination	
C 5	Clock	90980–12200
C 7	Combination Meter	90980–12170
C 8	Combination Meter	90980–12200
C 9	Combination SW	90980–11594
C10	Combination SW	90980–12183
C11	Combination SW (LH Turn Lever Type)	90980–11672
	Combination SW (RH Turn Lever Type)	90980–11671
C12	Cruise Control Clutch SW	90980–10906
C13	Curtain Shield Airbag Sensor LH	90980–12225
C14	Curtain Shield Airbag Sensor RH	
C15	Curtain Shield Airbag Squib LH	90980–12219
C16	Curtain Shield Airbag Squib RH	
D 1	Diode (A/C No.1)	90980–11071
D 2	Diode (A/C No.2)	90980–10962
D 3	DLC3	90980–11665
D 4	Double Door Lock ECU	90980–10807
D 5	Door Control Receiver	90980–11909
D 6	Door Courtesy SW Front LH	90980–10871
D 7	Door Courtesy SW Front RH	
D 8	Door Courtesy SW Rear LH	
D 9	Door Courtesy SW Rear RH	
D10	Door Key Lock and Unlock SW Front LH	90980–12226
	Door Lock Motor Front LH	
	Door Unlock Detection SW Front LH	
	Double Door Lock Motor Front LH	
	Position SW Front LH	
D11	Door Key Lock and Unlock SW Front RH	
	Door Lock Motor Front RH	
	Door Unlock Detection SW Front RH	
	Double Door Lock Motor Front RH	
	Position SW Front RH	
D12	Door Lock Control SW Front LH	90980–12122
	Power Window Master SW	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
D13	Door Lock Control SW Front RH	90980–12122
	Power Window Master SW	
D14	Door Lock Motor Rear LH	90980–12226
	Door Unlock Detection SW Rear LH	
	Double Door Lock Motor Rear LH	
	Position SW Rear LH	
D15	Door Lock Motor Rear RH	
	Door Unlock Detection SW Rear RH	
	Double Door Lock Motor Rear RH	
	Position SW Rear RH	
E 1	ECT Solenoid	90980–11658
E 2	EFI Water Temp. Sensor (1MZ–FE)	90980–10737
	EFI Water Temp. Sensor (2AZ–FE, 1AZ–FE)	90980–10735
E 3	EGR Gas Temp. Sensor	90980–10899
E 4	EGR Valve Position Sensor	90980–11143
E 5	Engine Oil Level Sensor (1MZ–FE)	90980–11235
	Engine Oil Level Sensor (2AZ–FE, 1AZ–FE)	90980–10532
E 6	Engine and ECT ECU (A/T)	90980–12142
	Engine ECU (M/T)	
E 7	Engine and ECT ECU (A/T)	90980–12146
	Engine ECU (M/T)	
E 8	Engine and ECT ECU (A/T)	90980–12143
	Engine ECU (M/T)	
E 9	Engine and ECT ECU (A/T)	90980–12145
	Engine ECU (M/T)	
E10	Engine and ECT ECU (A/T)	90980–12144
	Engine ECU (M/T)	
F 1	Front Clearance Light LH	90980–11156
F 2	Front Clearance Light RH	
F 3	Front Fog Light LH	90980–11096
F 4	Front Fog Light RH	
F 5	Front Side Turn Signal Light LH	90980–11162
F 6	Front Side Turn Signal Light RH	
F 7	Front Turn Signal Light LH	90980–11019
F 8	Front Turn Signal Light RH	
F 9	Front Wiper Motor	90980–11599
F10	Front Door Speaker LH (LHD)	82824–12260
	Front Door Speaker LH (RHD)	90980–10935
F11	Front Door Speaker RH (LHD)	82824–12260
	Front Door Speaker RH (RHD)	90980–10935
F12	Fuel Pump	90980–11077
	Fuel Sender	
G 1	Glove Box Light and SW	90980–11098
H 1	Headlight Beam Level Control Actuator LH	90980–11016
H 2	Headlight Beam Level Control Actuator RH	
H 3	Headlight Cleaner Motor	90980–11410

Code	Part Name	Part Number
H 4	Headlight Cleaner Relay	90980–10939
H 5	Headlight LH (High)	90980–11095
H 6	Headlight LH (Low)	90980–11149
H 7	Headlight RH (High)	90980–11095
H 8	Headlight RH (Low)	90980–11149
H 9	Heated Oxygen Sensor	90980–11930
H10	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980–10869
H11	Heated Oxygen Sensor (Bank 2 Sensor 1)	90980–11028
H12	Horn (High)	90980–10619
H13	Horn (Low)	
H14	Headlight Beam Level Control SW	90980–10996
H15	Headlight Cleaner SW	90980–10964
H16	High Mounted Stop Light (w/ Rear Spoiler)	90980–11060
	High Mounted Stop Light (w/o Rear Spoiler)	90980–11148
I 1	Ignition Coil and Igniter No.1	90980–11885
I 2	Ignition Coil and Igniter No.2	
I 3	Ignition Coil and Igniter No.3	
I 4	Ignition Coil and Igniter No.4	
I 5	Ignition Coil and Igniter No.5	
I 6	Ignition Coil and Igniter No.6	
I 7	Injector No.1 (1MZ–FE)	90980–11153
	Injector No.1 (2AZ–FE, 1AZ–FE)	90980–11875
I 8	Injector No.2 (1MZ–FE)	90980–11153
	Injector No.2 (2AZ–FE, 1AZ–FE)	90980–11875
I 9	Injector No.3 (1MZ–FE)	90980–11153
	Injector No.3 (2AZ–FE, 1AZ–FE)	90980–11875
I10	Injector No.4 (1MZ–FE)	90980–11153
	Injector No.4 (2AZ–FE, 1AZ–FE)	90980–11875
I11	Injector No.5	90980–11153
I12	Injector No.6	
I14	Ignition Key Cylinder Light	90980–12092
	Transponder Key Amplifier	
I15	Ignition SW	90980–11615
I16	Inner Mirror	90980–11794
I17	Interior Light	90980–10908
J 1	Junction Connector	90980–11542
J 2	Junction Connector	
J 3	Junction Connector	90980–10803
J 4	Junction Connector	90980–10976
J 5	Junction Connector	90980–11661
J 6	Junction Connector	
J 7	Junction Connector	
J 8	Junction Connector	
J11	Junction Connector	90980–10976
J12	Junction Connector	90980–11915
J13	Junction Connector	

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
K 1	Knock Sensor	90980–11166
K 2	Knock Sensor No.1	
K 3	Knock Sensor No.2	
K 4	Kick Down SW	90980–11156
L 1	License Plate Light LH	90980–11148
L 2	License Plate Light RH	
L 3	Light Failure Sensor	90980–10803
L 4	Luggage Compartment Door Opener Motor	90980–10825
	Luggage Compartment Light SW	
L 5	Luggage Compartment Light	90980–11148
M 1	Mirror Heater LH	90980–12059
	Remote Control Mirror LH	
M 2	Mirror Heater RH	
	Remote Control Mirror RH	
M 3	Moon Roof Control ECU and Motor	90980–10997
M 4	Moon Roof Control SW	90980–10789
	Personal Light	
N 1	Noise Filter (Ignition)	90980–10843
N 4	Noise Filter	90980–10860
O 1	Oil Pressure Sensor	90980–11363
P 1	Power Steering Oil Pressure SW	90980–11428
P 2	Pressure SW	90980–10943
P 3	Parking Brake SW	90980–10871
P 4	Power Outlet (Front)	90980–10760
P 5	Power Outlet (Rear)	90980–10860
P 6	Power Window Control SW Front LH	90980–10789
P 7	Power Window Control SW Front RH	82824–12230
P 8	Power Window Control SW Rear LH	90980–10789
P 9	Power Window Control SW Rear RH	82824–12230
P10	Power Window Motor Front LH (LHD)	82824–12270
	Power Window Motor Front LH (RHD)	90980–10797
P11	Power Window Motor Front RH (LHD)	82824–12270
	Power Window Motor Front RH (RHD)	90980–10797
P12	Power Window Motor Rear LH	90980–10797
P13	Power Window Motor Rear RH	
P14	Pretensioner LH	90980–12253
P15	Pretensioner RH	
P16	Power Seat Control SW (Driver's Seat)	90980–10997
P17	Power Seat Control SW (Front Passenger's Seat)	
P18	Power Seat Motor (Driver's Seat Front Vertical Control)	90980–10825
P19	Power Seat Motor (Driver's Seat Lifter Control)	
P20	Power Seat Motor (Driver's Seat Reclining Control)	
P21	Power Seat Motor (Driver's Seat Slide Control)	

Code	Part Name	Part Number
P22	Power Seat Motor (Front Passenger's Seat Front Vertical Control)	90980–10825
P23	Power Seat Motor (Front Passenger's Seat Lifter Control)	
P24	Power Seat Motor (Front Passenger's Seat Reclining Control)	
P25	Power Seat Motor (Front Passenger's Seat Slide Control)	
R 1	Radiator Fan Motor	90980–10928
R 2	Radio and Player	90980–10997
R 3	Radio and Player	90980–10996
R 4	Radio and Player	90980–10803
R 5	Radio and Player	90980–10819
R 7	Radio and Player with Display	90980–11909
R 8	Radio and Player with Display	90980–10997
R 9	Radio and Player with Display	90980–10996
R10	Rear Fog Light SW	90980–12113
R11	Rheostat	90980–10908
R12	Rain Sensor	82824–50130
R13	Rear Combination Light LH	90980–11587
R14	Rear Combination Light RH	
R15	Rear Speaker LH	90980–11060
R16	Rear Speaker RH	
R17	Rear Window Defogger (LHD)	90980–10913
	Rear Window Defogger (RHD)	90980–10914
R18	Rear Window Defogger (LHD)	90980–10914
	Rear Window Defogger (RHD)	90980–10913
R19	Remote Control Mirror SW	90980–11657
R22	Radio and Player with Display	90980–12259
S 1	Starter	90980–11400
S 2	Starter	90980–09463
S 3	Seat Heater SW LH	90980–10964
S 4	Seat Heater SW RH	90980–10933
S 5	Shift Lock Control ECU	90980–11909
S 6	Skid Control ECU	90980–11638
S 7	Skid Control ECU	90980–11637
S 8	Skid Control ECU	90980–11476
S 9	Skid Control ECU	90980–11421
S10	Skid Control ECU	90980–11392
S11	Skid Control ECU	90980–11391
S12	Skid Control ECU	90980–11390
S13	Steering Sensor	90980–12162
S14	Stop Light SW	90980–11118
S15	Side Airbag Sensor LH	90980–12241
S16	Side Airbag Sensor RH	
S17	Seat Heater LH	90980–10906
S18	Seat Heater RH	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
S19	Side Airbag Squib LH	90980–11864
S20	Side Airbag Squib RH	
T 1	Throttle Control Motor	90980–11156
T 2	Throttle Position Sensor (1MZ–FE)	90980–10711
	Throttle Position Sensor (2AZ–FE, 1AZ–FE)	90980–11858
T 3	Turbine Speed Sensor	90980–11156
T 4	TRC OFF SW	90980–11013
T 5	Turn Signal Flasher Relay	90980–10799
T 6	Tweeter LH	90980–10860
T 7	Tweeter RH	
U 1	Unlock Warning SW	
V 1	VSV (ACIS)	90980–11149
V 2	VSV (AICV)	90980–11156
V 3	VSV (EGR)	90980–11149
V 4	VSV (EVAP)	90980–11156

Code	Part Name	Part Number
V 5	VVT Solenoid	90980–11162
V 6	VSC Warning Buzzer	90980–10906
V 7	Vanity Light LH	90980–10621
V 8	Vanity Light RH	
W 1	Washer Motor	90980–10981
W 2	Water Temp. SW No.1	90980–11235
W 3	Water Temp. SW No.2	90980–11243
W 4	Wiper Relay	90980–12166
Y 1	Yaw Rate Sensor	90980–12080
Z 1	Option Connector (Engine Hood Courtesy SW)	90980–11051
Z 2	Option Connector (TVSS ECU) (LHD)	90980–10995
	Option Connector (TVSS ECU) (RHD)	90980–11915
Z 3	Option Connector (TVSS Siren)	90980–10988