## ■SYSTEM OPERATION

The Body ECU performs the following functions and system controls described in the chart.

| Function | | Body ECU | |
|---|---|---|---|
| | | LHD | RHD |
| Interior Light | Illuminated entry system control | ○ | ○ |
| Exterior Light | Light Auto turn-off system control | ○ | ○ |
| | Daytime running light system control*1 | ○ | — |
| | Automatic light control system | ○ | ○ |
| Warning Control | Key reminder warning | ○ | ○ |
| | Door ajar warning | ○ | ○ |
| Door Lock Control | Door lock control switch manual operation | ○ | ○ |
| | Key-linked lock and unlock function | ○ | ○ |
| | Manual unlock prohibition function | ○ | ○ |
| | Key confine prevention function | ○ | ○ |
| Wireless Door Lock Remote Control System | Door lock and unlock operation | ○ | ○ |
| | Answer back operation | ○ | ○ |
| | Luggage door open operation | ○ | ○ |
| Double Locking System | Double Lock Request | — | ○*2 |
| Diagnosis | Self diagnosis | ○ | ○ |

*1: Optional Equipment
*2: Only for The European Models