# BLACK SCREEN (NO IMAGE APPEARS ON NAVIGATION AND AUDIO SCREEN)

## INSPECTION PROCEDURE

| 1 | CHECK DISPLAY SETTING |
|---|---|

(a) Check that the display is not in ”Screen OFF” mode.
**Standard: The display setting is not in ”Screen OFF” mode.**

**NG** → **CHANGE SCREEN TO ”SCREEN ON” MODE**

**OK**

| 2 | CHECK IMAGE QUALITY SETTING |
|---|---|

(a) Check if screen color quality can be set.
**Standard: Screen color quality can be set.**

**OK** → **PRESS PANEL SWITCH ”DISPLAY” AND SET SCREEN COLOR QUALITY TO NORMAL**

**NG**

| 3 | CHECK CABIN |
|---|---|

(a) Check if condensation is likely to occur, or the temperature is high or low (extremely cold) in the cabin.
HINT:
This problem occurs when the cabin is humid and the temperature rapidly changes. This condition may produce condensation, resulting in a short circuit.
**Standard: The above conditions are not observed.**

**NG** → **SET CABIN TEMPERATURE TO APPROPRIATE DEGREES (20 TO 30°C) (68 TO 86°F)**

**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**
**(SEE PAGE 05–46)**