05MDK–01

DATA LIST/ACTIVE TEST

HINT:

By accessing the DATA LIST displayed by the intelligent tester ll, you can perform such functions as reading the values of switches and sensors without removing any parts. Reading the DATA LIST is the first step of troubleshooting and is one method to shorten labor time.

1. DATA LIST

(a) Connect the intelligent tester ll to the DLC3.

(b) Turn the ignition switch to the ON position.

(c) Following the display on the tester screen, read the ”DATA LIST”.

AIRBAG SENSOR ASSY CENTER

Item	Measurement Item/ Range (Display)	Normal Condition	Diagnostic Note
D Seat	Driver Seat Position/ FORWARD: Seat position is forward BKWARD: Seat position is rearward FAIL: A failure is detected	FORWARD/BKWARD	–
D Bk SW	Driver Buckle SW/ UNSET: The seat belt is not fastened SET: The seat belt is fastened NG: Data is not determined	UNSET/SET	–
Disp Typ	Display type identification information/ LR: The display is indicated by LH/RH DP: The display is indicated by Driver/Passenger	DP	–