050YH–35

PROBLEM SYMPTOMS TABLE

HINT:

Proceed to the troubleshooting of each circuit in the table below.

Symptom	Suspected Area	See page
• When the ignition switch is in the ON position, the SRS warning light sometimes comes on after approximately 6 seconds.	• SRS warning light circuit malfunction (Always comes on, when DTC is not output).	05–212
• SRS warning light always comes on even when DTC is not output.	• SRS warning light circuit malfunction (Always comes on, when DTC is not output).	05–212
• With the ignition switch in the ON position, the SRS warning light does not come on.	• SRS warning light circuit malfunction (Does not come on, when ignition switch is turned to the ON position).	05–216
• Although a SRS warning light operates normally, DTC or a normal system code is not displayed.	• TC Terminal circuit	05–218
• Although terminals TC and CG are not connected, DTC or a normal system code is displayed.	• TC Terminal circuit	05–218