0562D–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Engine does not crank (Does not start)	3. Starter 4. Starter relay	19–15 19–15
No initial combustion (Does not start)	1. ECM power source circuit 2. Fuel pump control circuit 3. ECM	05–439 05–443 01–31
No complete combustion (Does not start)	1. Fuel pump control circuit	05–443
Engine cranks normally (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	05–434 05–443 14–1
Cold engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	05–434 05–443
Hot engine (Difficult to start)	1. Starter signal circuit 2. Fuel pump control circuit	05–434 05–443
High engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. ECM power source circuit	05–741 05–439
Low engine idle speed (Poor idling)	1. A/C signal circuit (Compressor circuit) 2. Fuel pump control circuit	05–741 05–443
Rough idling (Poor idling)	1. Compression 2. Fuel pump control circuit 3. Electric throttle control system	14–1 05–443 05–387
Hunting (Poor idling)	1. ECM power source circuit 2. Fuel pump control circuit	05–439 05–443
Hesitation/Poor acceleration (Poor driveability)	1. Fuel pump control circuit 2. A/T faulty 3. Electric throttle control system	05–443 05–611 05–402
Surging (Poor driveability)	1. Fuel pump control circuit	05–443
Soon after starting (Engine stall)	1. Fuel pump control circuit	05–443
During A/C operation (Engine stall)	1. A/C signal circuit (Compressor circuit) 2. ECM	05–741 01–31
Unable to refuel/Difficult to refuel	1. ORVR system	–