ABS WITH BA & EBD SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

050YD–04

1	Vehicle Brought to Workshop

2	Customer Problem Analysis (See page 05–450)

3	Check and Clear DTCs (See page 05–451)

4	Problem Symptom Confirmation

- Symptom does not occur: Go to step 5
- Symptom occur: Go to step 6

5	Symptom Simulation (See page 01–21)

6	DTC Check (See page 05–451)

- There is no output: Go to step 7
- There is output: Go to step 8

7	Problem Symptoms Table (See page 05–463)

- Check for fluid leakage and Go to step 10

8	DTC Chart (See page 05–458)

9	Circuit Inspection (See page 05–464)

10	Identification of Problem

11	Repair

12	Comfirmation Test

End

HINT:
Step 3, 6, 9, 12:
Diagnostic steps permitting the use of the hand–held tester.
Fail safe function:
When a failure occurs in the ABS and BA system, the ABS warning light is turns on and the ABS operation is prohibited. In addition to this, when there is a failure which disables the EBD operation, the brake warning light also tuns on and the EBD operation is prohibited.