050XH–04

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

NOTICE:

When replacing Skid Control ECU, sensor or etc., turn the ignition switch OFF.

Symptom	Suspect Area	See page
ABS does not operate.	When the followings 1. to 4. are all normal and the problem is still occurring, replace the Skid Control ECU. 1. Check the DTC reconfirming that the normal code is output. 2. IG power source circuit 3. Speed sensor circuit 4. Check the brake actuator with a hand–held tester. If abnormal, check the hydraulic circuit for leakage.	 05–451 05–485 05–464 05–469 32–42
ABS does not operate efficiently.	When the following 1. to 4. are all normal and the problem is still occurring, replace the Skid Control ECU. 1. Check the DTC reconfirming that the normal code is output. 2. Speed sensor circuit 3. Stop light switch circuit 4. Check the brake actuator with a hand–held tester. If abnormal, check the hydraulic circuit for leakage.	 05–451 05–464 05–469 05–491 32–42
ABS warning light abnormality.	1. ABS warning light circuit 2. Skid Control ECU	05–498 05–500 01–31
DTC check cannot be done.	When the following 1. and 2. are all normal and the problem is still occurring, replace the Skid Control ECU. 1. ABS warning light circuit 2. Tc terminal circuit	 05–498 05–500 05–505
Speed sensor signal check cannot be done.	1. Ts terminal circuit 2. Skid Control ECU	05–503 01–31