ABS WARNING LIGHT CIRCUIT(DOES NOT LIGHT UP)

CIRCUIT DESCRIPTION

Refer to ABS Warning Light Circuit (Remains ON) on page 05–498.

WIRING DIAGRAM

Refer to ABS Warning Light Circuit (Remains ON) on page 05–498.

INSPECTION PROCEDURE

HINT:
Start the inspection from step 1 in case of using the hand–held tester and start from step 2 in case of not using hand–held tester.

1	PERFORM ACTIVE TEST BY HAND–HELD TESTER(ABS WARNING LIGHT OPERATION)

(a) Select the item ”ABS WARN LIGHT” in the ACTIVE TEST and operate the ABS warning light on the hand–held tester.
(b) Check that ”ON” and ”OFF” of the ABS warning light can be shown on the combination meter by the hand–held tester.

OK → CHECK AND REPLACE SKID CONTROL ECU ASSY

NG

2	INSPECT COMBINATION METER ASSY(ABS WARNING LIGHT CIRCUIT)

NG → REPAIR COMBINATION METER ASSY

OK

CHECK AND REPAIR HARNESS AND CONNECTOR