SUPPLEMENTAL RESTRAINT SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

050YF–05

1	Vehicle Brought to Workshop

2	Customer Problem Analysis (See page 05–757)

3	Warning Light Check (See page 05–758)

- Warning is light remains ON: Go to step 4
- Warning is light remains OFF: Go to step 5

4	DTC Check (Read Present DTC) (See page 05–758)

- Go to step 6

5	DTC Check (Read Past DTC) (See page 05–758)

6	DTC Chart (See page 05–758)

7	Circuit Inspection (See page 05–771 to 05–957)

- Malfunction code is output: Go to step 8
- Normal code is output: Go to step 14

8	Identification of Problem

9	Repair

10	Clear DTC (Present and Past DTC) (See page 05–758)

11	Warning Light Check (See page 05–758)

→ Warning light is remains OFF: Go to step 12

→ Warning light is remains ON: Go to step 13

12	DTC Check (Read Past DTC) (See page 05–758)

→ DTC code is not output: Go to step 15

→ DTC code is output: Go to step 13

13	DTC Check (See page 05–758)

→ Go to step 6

14	Symptom Simulation (See page 01–21)

→ Warning is light remains OFF: Go to step 15

→ Warning is light ON: Go to step 13

15	Confirmation Test

End

HINT:
Step 3, 4, 7, 10, 12, 13:
Diagnostic steps permitting the use of the hand–held tester.