050YH–05

PROBLEM SYMPTOMS TABLE

HINT:

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
• When the ignition switch in ON position, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed.	• SRS WARNING LIGHT CIRCUIT MALFUNCTION (ALWAYS LIGHTS UP, WHEN IGNITION SWITCH IS ACC OR LOCK POSITION).	05–963
• SRS warning light is always lit up even when ignition switch is in the ACC or LOCK position.		
• With the ignition switch in ON position, the SRS warning light does not light up.	• SRS WARNING LIGHT CIRCUIT MALFUNCTION (DOES NOT LIGHT UP, WHEN IGNITION SWITCH IS TURNED TO ON).	05–966
• DTC is not displayed.	• TC TERMINAL CIRCUIT	05–968
• SRS warning light is always lit up at the time of DTC check procedure.		
• DTC is displayed without Tc and CG terminal connection.		