0565O–01

HOW TO PROCEED WITH TROUBLESHOOTING

1	VEHICLE BROUGHT TO WORK SHOP

2	CUSTOMER PROBLEM ANALYSIS (See page 05–974)

3	CHECK BODY MULTIPLEX COMMUNICATION SYSTEM (See page 05–1274)

(a) Check that the DTC outputs.

- DTC OUTPUTS (PROCEED TO ”BODY MULTIPLEX COMMUNICATION SYSTEM”)
- DTC DOES NOT OUTPUT (GO TO STEP 4)

4	DTC CHECK (See Page 05–975)

- MALFUNCTION CODE (GO TO STEP 5)
- NORMAL CODE (GO TO STEP 6)

5	DTC CHART (See Page 05–976)

- GO TO STEP 8

6	PROBLEM SYMPTOMS TABLE (See page 05–981)

7	TERMINAL OF ECU (See page 05–979)

8	CIRCUIT INSPECTION (See Page 05–983)

9	IDENTIFICATION OF PROBLEM

10	REPAIR OR REPLACE

11	CONFIRMATION TEST

END