05664–01

PRE–CHECK

1. RAIN DROP SENSING WIPER OPERATION CHECK

(a) Check that wiper operates properly in INT, LO and HI mode depending on the amount of rain drop on windshield glass when wiper switch is at AUTO.

2. FAIL SAFE FUNCTION

(a) Wiper operates intermittently depending on the sensitivity control position in wiper switch ”AUTO” on the following condition.
  (1) Rain sensor temperature is less than –10 degrees.
  (2) Rain sensor temperature is more than 80 degrees.
  (3) Rain sensor malfunction.