05667–01

# PROBLEM SYMPTOMS TABLE

## 1. WIPER AND WASHER SYSTEM

| Symptom | Suspect Area | See page |
|---|---|---|
| Front wipers do not operate. | 1. IG1 Relay<br>2. WIPER Fuse (I/P J/B)<br>3. Front Wiper Switch<br>4. Wire Harness<br>5. Wiper Relay | –<br>–<br>66–3<br>–<br>– |
| Front wipers do not operate in LO or HI. | 1. Front Wiper Switch<br>2. Front Wiper Motor<br>3. Wire Harness<br>4. Wiper Relay | 66–3<br>66–3<br>–<br>– |
| Rain drop sensing function does not operate. | – | 05–1008 |
| Front Washer motor does not operate. | 1. WIPER Fuse (I/P J/B)<br>2. Front Washer Switch<br>3. Front Washer Motor<br>4. Wire Harness | –<br>66–3<br>66–2<br>– |
| Front Wipers do not operate when washer switch in ON. | 1. Front Wiper Switch<br>2. Front Wiper Motor<br>3. Wire Harness<br>4. Wiper Relay | 66–3<br>66–3<br>–<br>– |
| Washer fluid does not operate. | 1. Washer Hose and Nozzle | – |
| ● When the wiper switch is OFF, the wiper blade does not retract or the retract position wrong. | 1. Windshield Wiper Motor *1<br>2. Wire Harness *1 | 66–3<br>– |

*1: Inspect wiper arm and blade set position