0549M–02

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Pressing power switch does not start system.	3. Radio receiver assy power source circuit 4. Radio receiver assy	05–1031
Turning on light switch does not light up night time illumination of radio receiver.	1. Radio receiver assy ILL terminal circuit 2. Radio receiver assy	05–1033
No sound is heard from speaker in all modes.	1. Speaker circuit 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–1035
Sound quality is bad in all modes. (Volume is too low)	1. Speaker circuit 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–1038
Radio broadcast cannot be received. (Bad reception)	1. Antenna circuit 2. Radio receiver assy	05–1041
Cassette tape cannot be inserted or played.	1. Cassette tape 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–1043
Cassette tape cannot be ejected.	1. Cassette tape 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–1045
Sound quality is bad only when playing tape.	1. Cassette tape 2. Radio receiver assy	05–1048
Tape is tangled due to incorrect tape speed or auto–reverse malfunction.	1. Cassette tape 2. Radio receiver assy	05–1049
CD cannot be inserted or is ejected right after insertion.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–1050
Although system is powered, CD cannot be played.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–1053
CD cannot be taken out.	1. CD 2. Radio receiver assy power source circuit 3. Radio receiver assy	05–1056
Sound quality is bad only when CD is played.(Volume is too low)	1. CD	05–1058
CD sound skips.	1. CD 2. Radio installation	05–1059
Noise occurs.	–	05–1061