0561F–01

PROBLEM SYMPTOMS TABLE

Flow chart No.	Symptom	See page
1	Even when pressing ”PWR/VOL” switch or any audio switch, the screen remains black.	05–1090
2	Panel switch does not function.	05–1092
3	Although ”PWR/VOL” switch is pressed, no sound is heard (Display and switch operation is normal).	05–1093
4	No navigation screen displayed when ”MAP/VOICE” ”MENU” or ”DEST” switch pressed (Screen cannot be switched).	05–1096
5	Navigation screen not stabilized (Syncronous error).	05–1100
6	Color on navigation screen is unusual (RGB signal error)	05–1104
7	Black screen appears when ”MAP/VOICE”, ”MENU” or ”DEST” switch pressed.	05–1109
8	Front speaker (Driver side) only is not heard (Radio, casette tape, CD)	05–1113
9	Map disc cannot be inserted.	05–1117
10	Map screen displayed does not appear (Disc caution screen does not change).	05–1119
11	Map is displayed in white or blue screen (Switched and vehicle position mark are displayed).	05–1120
12	Screen cannot be dimmed when light control switch is turned to ”TAIL” position.	05–1121
13	Touch switch does not function (Navigation screen only)	05–1124
14	Vehicle position is deviated from correct point badly.	05–1125
15	GPS mark does not appear	05–1127
16	No voice navigation	05–1128
17	Vehicle position mark rotates without control (Map rotates without control)	05–1131
18	Driving derections opposite to moving derection of vehicle position mark	05–1134
19	CD cannot be inserted / is ejected right after insertion / cannot be played.	05–1137
20	CD cannot be ejected	05–1139
21	Cassette tape cannot be inserted or played.	05–1137
22	Cassette tape cannot be ejected	05–1139
23	CD sound skips.	05–1141
24	Noise occurs	05–1147
25	Radio broadcast cannot be received. (Bad reception)	05–1149

EXAMPLES OF MISUNDERSTANDING SYMPTOMS AS MALFUNCTIONS

Condition	Cause	Procedure to recover
Screen displays ”AUDIO OFF”, even when ”PWR/VOL” switch is turned off.	”PWR/VOL” switch turns the audio off, but not the screen. To turn off the screen, ”SCREEN OFF” switch must be pressed.	Press ”DISPLAY” switch → Press ”SCREEN OFF” switch on screen
The screen is too dark or too bright, when the screen is changed between navigation and audio.	The contrast set up of the screen between navigation and audio is different. The contrast needs to be set up for each of the navigation and audio screen.	*Navigation: Press ”DISPLAY” and adjust by ”BRIGHTNESS” switch. *AUDIO: Press ”DISPLAY” and adjust by ”CONTRAST” switch.
Present position is not displayed even when ”NAVI” switch is pressed.	Pressing ”NAVI” switch displays the previous screen. For present position, ”MAP/VOICE” switch must be pressed.	Press ”NAVI” switch → Press ”MAP/VOICE” switch.
Even when pressing the panel switch, it doesn’t function.	*Since this switch is pressure sensitive type, press the switch scurely. *The panel switch toned down does not work even if is pressed.	Press the panel switch securely, if the pressure is weak or time is insufficient, the switch does not function.