0563N–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected area	See page
Power window does not operate (ALL) (Power Door Lock does not operate)	1. Power fuse (Instrument panel J/B) 2. Power main relay (Instrument panel J/B) 3. Wire harness	68–1 70–2 —
Power window does not operate (ALL) (Power Door Lock is normal)	1. Ignition switch 2. Power window master switch 3. Wire harness 4. Power window motor	80–2 05–1154 — 70–2
”One–Touch Power Window System” does not operate	1. Power window master switch 2. Power window motor (drivers side)	05–1154 70–2
Only one window glass does not move.	1. Power window master switch 2. Power window switch 3. Power window motor 4. Wire harness	05–1154 70–2 70–2 —
”Window Lock System” does not operate	1. Power window master switch 2. Wire harness	05–1154 —