WINDOW CANNOT BE OPERATED AFTER KEY–OFF

HINT:
In the LHD vehicle, work in the same procedure as in the RHD vehicle.

CIRCUIT DISCRIPTION

Unless the driver's door is opened then closed within 43 seconds after the ignition switch is turned from ON to OFF, the instrument panel J/B (body ECU) supplies the power source to the master switch.
HINT:
If a malfunction is detected in the jam protection pulse sensor and limit switch, the operation after the ignition switch is turned OFF will be prohibited by the fail–safe function. At this time, the AUTO UP and DOWN operations will be prohibited, as well.

INSPECTION PROCEDURE

1	CHECK DRIVER'S SIDE POWER WINDOW FUNCTION (See page 70–1)

NG → GO TO PROBLEM SYMPTOMS TABLE (See page 05–1155)

OK

GO TO POWER DOOR LOCK CONTROL SYSTEM (See page 05–1224)