POWER DOOR LOCK CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

0564G–01

Troubleshoot in accordance with the procedure on the following pages.

1	VEHICLE BROUGHT IN

2	CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05–1225)

3	DIAGNOSTIC TROUBLE CODE CHECK (See page 05–1226)

(a) Check the diagnostic trouble code.
  (1) Without code outputs, proceed to A
  (2) With code outputs, proceed to B

B	Go to step 6

A

4	PROBLEM SYMPTOMS TABLE (See page 05–1232)

(a) Without applicable symptoms, proceed to ”A”.
(b) With applicable symptoms, proceed to ”B”.

B	Go to step 6

A

5	PERFORM TROUBLESHOOTING IN FOLLOWING METHOD, DEPENDING ON MALFUNCTION SYMPTOM

(a) Terminals of ECU. (See page 05–1228)
(b) Inspection. (See page 73–3)
(c) On–vehicle inspection. (See page73–1)

6	ADJUSTMENT, REPAIR OR REPLACEMENT

END