0564I–01

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below (Proceed to the page given for that circuit).

HINT:

The DTC detection method. (See page05–1274)

DTC No. (See Page)	Detection Item	Trouble Area
41 (05–1233)	Door ECU switch ON	• Power window master switch assy • Unlock warning switch assy • Front door courtesy switch assy • Rear door courtesy switch assy • Front door lock assy • Headlamp dimmer switch assy • Stop lamp switch assy • Parking brake switch assy