055VG–02

DIAGNOSTIC TROUBLE CODE CHART

DTC No. (See page)	DTC detection condition	Trouble area
B2795 (05–1269)	Unmatched key code	• Key
B2796 (05–1270)	No communication in immobiliser system	• Key • Transponder key amplifier • Wire harness • ECM
B2797 (05–1273)	Communication malfunction No.1	• Wire harness • Transponder key amplifier • Key • ECM
B2798 (05–1270)	Communication malfunction No. 2	• Key • Transponder key amplifier • Wire harness • ECM

NOTICE:

- **Codes B2795, B2797 and B2798 may remain as a record that the immobiliser system has activated in the past.**
- **The diagnosis code on the immobiliser system is specified in this chart. If any other code is output, check the diagnostic code chart on the engine control system.**
  (1AZ–FE engine: See page 05–17)
  (2AZ–FE engine: See page 05–145)
  (1MZ–FE engine: See page 05–301)

HINT:

- The ”SAE code” indicates a code output when using the hand–held tester.
- The ”lamp” indicates a code output when using the malfunction indicator lamp.
  (1AZ–FE engine: 05–17)
  (2AZ–FE engine: 05–145)
  (1MZ–FE engine: 05–301)