CRUISE CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

0563T–01

1	VEHICLE BROUGHT TO WORK SHOP

2	CUSTOMER PROBLEM ANALYSIS (See page 05–1289)

3	CHECK AND CLEAR DTC (See page 05–1290)

- DTC DOES NOT OUTPUT (PROCEED TO "BODY MULTIPLEX COMMUNICATION SYSTEM")
- DTC OUTPUTS (GO TO STEP 4)

4	PROBLEM SYMPTOM CONFIRMATION

- SYMPTOM DOES NOT OCCUR (GO TO STEP 5)
- SYMPTOM OCCURS (GO TO STEP 6)

5	SYMPTOM SIMULATION (See page 01–21)

6	DTC CHECK (See page 05–1290)

- MALFUNCTION CODE (GO TO STEP 7)
- NORMAL CODE (GO TO STEP 8)

7	DTC CHART (See page 05–1295)

GO TO STEP 9

8	PROBLEM SYMPTOMS TABLE (See page 05–1298)

9	CIRCUIT INSPECTION (See page 05–1299 – 05–1315)

10	**INDENTFICATION OF PROBLEM**

11	**REPAIR OR REPLACE**

12	**CONFIRMATION TEST**

END