0563W–01

DIAGNOSTIC TROUBLE CODE CHART

If an malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below and proceed to an appropriate page.

DTC No. (See Page)	Circuit Inspection	Trouble Area
P0500/ 21, 23 (05–1299)	Vehicle speed sensor circuit	• Vehicle speed sensor • Wire harness or connector • ECM
P1520/ 52 (05–1302)	Stop light switch circuit	• Stop light switch • Wire harness or connector • ECM
P1566/ 54 (05–1306)	Input signal circuit	• ECM